Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit AH59-02733B-ZDLMT

AH59-02733B Replacement Remote Control User Manual

Model: AH59-02733B-ZDLMT | Brand: ZdalaMit

1. Introduction

This manual provides detailed instructions for the operation and maintenance of your new ZdalaMit AH59-02733B Replacement Remote Control. Please read this manual thoroughly before using the product to ensure proper function and to prevent damage. The AH59-02733B remote control is designed to replace your original remote for various Samsung Soundbar models, offering seamless functionality without the need for complex programming.

2. Product Overview

The AH59-02733B Replacement Remote Control is a direct replacement for Samsung Soundbar remotes. It features a user-friendly layout with essential controls for your soundbar system.



Figure 2.1: Front view of the AH59-02733B Replacement Remote Control, showing power, source, volume, mute, repeat, track controls, sound effect, sound, Bluetooth power, and sound control buttons.



VOL
SOUND EFFECT
SOUND
Bluetooth POWER
SOUND CONTROL
AH59-02733B
5.31 inch
1.57 inch

Figure 2.2: Dimensions of the remote control, indicating a length of approximately 5.31 inches and a width of 1.57 inches.

3. Setup

3.1 Battery Installation

The remote control requires two (2) AAA alkaline batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Figure 3.1: Rear view of the remote control with the battery cover removed, showing the two AAA battery slots.

No programming or pairing is required for this replacement remote. It is ready to use once batteries are installed.

4. Operating Instructions

This section details the functions of each button on the AH59-02733B remote control.



Figure 4.1: An annotated diagram illustrating the function of each button on the remote control, including Power, Source, Volume, Mute, Repeat, Track, Sound Effect, Sound, Bluetooth Power, and Sound Control.

- **Power (●):** Turns the soundbar on or off.
- **SOURCE:** Selects the input source connected to the soundbar (e.g., TV, HDMI, Optical).
- **VOL (+/-):** Adjusts the volume level.
- **Mute ( ):** Mutes or unmutes the sound.
- **Repeat (↻):** Sets the repeat function during music playback from a USB device. Options include OFF, REPEAT (cancels repeat), TRACK (repeats current track), ALL (repeats all tracks), RANDOM (plays tracks in random order).
- **Track Controls (/ /):** Used for media playback control (Previous Track, Play/Pause, Next Track).
- **SOUND EFFECT:** Cycles through different sound modes (STANDARD, Original Sound, Music, Clear Voice, Sports, Movie, Night Mode).
- **SOUND ((o)):** Adjusts sound depth and spaciousness. Pressing this button cycles through Surround Sound settings (ON, SURROUND SOUND, OFF, SURROUND SOUND).
- **Bluetooth POWER:** Turns on the Bluetooth power function on the soundbar.
- **SOUND CONTROL (◀ / ▶):** Used for sound control adjustments.

Your browser does not support the video tag.

Video 4.1: Demonstration of the AH59-02733B remote control's power and source functions with a Samsung soundbar. This video shows the remote being held and then used to turn on the soundbar and switch its input source.

5. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.

- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new AAA alkaline batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage.

6. Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly installed batteries.	Replace batteries with new AAA alkaline batteries, ensuring correct polarity.
Remote range is poor.	Weak batteries or obstruction between remote and soundbar.	Replace batteries. Ensure no objects are blocking the line of sight between the remote and the soundbar's sensor.
Specific button not working.	Button stuck or internal malfunction.	Gently press the button multiple times. If issue persists, contact customer support.

7. Specifications

- **Model Number:** AH59-02733B-ZDLMT
- **Compatible Devices:** Samsung Soundbars (HW-K360, HW-KM36C, HW-KM36, HW-K450, HW-K550, HW-K551, HW-J4000, HW-JM4000, HW-KM45C, PS-WK450, HW-J6000R, HW-J6001R, HW-K430, HW-K460, HW-KM45, HW-KM45/ZA, HW-KM39, HW-KM57C, HW-KM55C, HW-KM39/ZA, HW-KM57C/ZA, HW-KM55C/ZA, HW-KM57C/ZC, HW-KM39/ZC, PS-WJM4000C)
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Dimensions:** Approximately 5 x 1 x 0.5 inches (12.7 x 2.54 x 1.27 cm)
- **Weight:** Approximately 0.317 ounces (9 grams)
- **Color:** Black
- **Special Feature:** Pre-Programmed (No pairing required)

8. Warranty and Support

For any queries or issues regarding your AH59-02733B Replacement Remote Control, please contact ZdalaMit customer support. Refer to your product packaging or purchase details for specific warranty information.
Contact: Please feel free to contact us if you have any query, thanks!

© 2025 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B072ZQB512

More documents and user manuals: **https://manuals.plus/**