Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SanDisk 2724605675439

SanDisk Ultra Plus 64GB microSDXC UHS-I Card User Manual

Model: 2724605675439

1. Product Overview

The SanDisk Ultra Plus 64GB microSDXC UHS-I Card is designed for use with Android smartphones, tablets, and cameras. It offers fast transfer speeds and is suitable for Full HD video recording and high-resolution photos. This package includes the microSDXC card and an SD adapter for broader compatibility.

Key Features:

- **Capacity:** 64GB
- **Speed Class:** UHS Speed Class 1 (U1), Video Speed Class 10 (V10)
- **Transfer Speed:** Up to 100MB/s read speed
- **Compatibility:** Ideal for Android-based smartphones, tablets, and cameras.
- **Video Support:** Optimized for Full HD video capture.
- **Included:** microSDXC card and SD adapter.



Image 1.1: Front view of the SanDisk Ultra Plus 64GB microSDXC card. This image displays the card's branding, capacity, and speed class markings.

2. Setup and Installation

This section provides general instructions for installing your SanDisk microSDXC card. Specific installation steps may vary depending on your device.

2.1. Inserting the microSDXC Card into a Device

1. **Locate the microSD slot:** Refer to your device's user manual to find the microSD card slot. This is typically on the side of smartphones/tablets or within a battery compartment.
2. **Orient the card:** Ensure the metal contacts on the microSD card are facing the correct direction as indicated by your device.
3. **Insert the card:** Gently push the microSD card into the slot until it clicks into place. Do not force the card.
4. **Verify installation:** Your device should recognize the new storage. You may receive a notification or see the card listed in your device's storage settings.

2.2. Using the SD Adapter

The included SD adapter allows you to use your microSDXC card with devices that have a standard SD card slot, such as laptops, digital cameras, and card readers.

1. **Insert microSD into adapter:** Slide the microSDXC card into the designated slot on the side of the SD adapter

until it clicks.

2. **Insert adapter into device:** Insert the SD adapter (with the microSD card inside) into the SD card slot of your compatible device.
3. **Remove adapter:** To remove, gently pull the SD adapter out of the device. To remove the microSD card from the adapter, push it slightly further in until it springs out.



Image 2.1: SanDisk Ultra Plus microSDXC cards shown with their accompanying SD adapters. This illustrates how the smaller microSD card fits into the larger SD adapter for broader device compatibility.

3. Operating Instructions

Once installed, your SanDisk microSDXC card functions as additional storage for your device. Here are common operations:

3.1. Storing Files

- **Photos and Videos:** Most cameras and smartphones can be configured to save photos and videos directly to the microSD card. Check your device's camera settings.
- **Apps and Data:** On Android devices, you can move compatible apps and their data to the microSD card via the device's "Apps" or "Storage" settings.
- **Documents and Media:** Files can be manually transferred to the card using a file manager application on your device or by connecting your device to a computer.

3.2. Formatting the Card

Formatting the card erases all data and prepares it for use with a specific device. It is recommended to format a new card in the device it will primarily be used with.

- **Backup Data:** Before formatting, ensure all important data is backed up, as formatting will permanently delete it.
- **Device Settings:** Access your device's storage settings (e.g., "Settings" > "Storage" > "SD Card") and look for an option to "Format" or "Erase SD Card."
- **Computer Formatting:** You can also format the card using a computer. Insert the card (via adapter) into your computer, right-click on the drive, and select "Format." Choose the appropriate file system (e.g., exFAT for 64GB cards).

4. Maintenance and Best Practices

Proper care ensures the longevity and reliability of your SanDisk microSDXC card.

- **Safe Removal:** Always safely eject the card from your device before physically removing it. This prevents data corruption.
- **Physical Protection:** Store the card in its protective case or a secure location when not in use to prevent damage from dust, moisture, or static electricity.
- **Avoid Extreme Conditions:** Do not expose the card to extreme temperatures, direct sunlight, or strong magnetic fields.
- **Regular Backups:** Periodically back up important data from your microSD card to another storage medium (e.g., computer hard drive, cloud storage) to prevent data loss.
- **Clean Contacts:** If necessary, gently clean the metal contacts with a soft, dry, lint-free cloth. Avoid using abrasive materials or liquids.

5. Troubleshooting

If you encounter issues with your SanDisk microSDXC card, try the following steps:

- **Card Not Recognized:**
  - Ensure the card is fully and correctly inserted into the slot.
  - Restart your device.
  - Try the card in another compatible device or with the SD adapter in a computer to rule out a device-specific issue.
  - Check your device's settings to see if the card is listed but unmounted.
- **Slow Performance:**
  - Ensure your device supports UHS-I speeds. Older devices may not fully utilize the card's speed capabilities.
  - Avoid filling the card to its maximum capacity, as this can sometimes affect performance.
  - Format the card (after backing up data) to resolve potential file system fragmentation.
- **Data Corruption/Errors:**
  - Always use the "Safely Remove Hardware" or "Eject" option before physically removing the card from a computer or device.
  - Run a disk check utility on a computer (e.g., CHKDSK on Windows, Disk Utility on macOS) to scan for and repair errors.
  - If errors persist, the card may be faulty.

6. Specifications

Brand	SanDisk
Model Name	2724605675439
Flash Memory Type	SDXC
Memory Storage Capacity	64 GB
Speed Class	UHS-I (U1), Class 10, V10
Read Speed	Up to 100 MB/s
Compatible Devices	Camera, Smartphone, Tablet
Product Dimensions	0.55 x 9.76 x 6.14 inches (*Note: These dimensions likely refer to the product packaging, not the card itself.*)
UPC	619659159375





Image 6.1: Two SanDisk Ultra Plus 64GB microSDXC cards displayed side-by-side. This image highlights the compact size and identical appearance of multiple cards.

7. Warranty and Support

For warranty information and technical support, please refer to the official SanDisk website or contact SanDisk customer service. Keep your proof of purchase for warranty claims.
SanDisk Official Website: www.sandisk.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B073CKZBBP

More documents and user manuals: **https://manuals.plus/**