Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

other KOM-W1821

KOMONO Wizard Print Series-Peacock Quartz Ladies Watch Instruction Manual

Model: KOM-W1821

1. Introduction

Welcome to the instruction manual for your new KOMONO Wizard Print Series-Peacock Quartz Ladies Watch. This manual provides essential information on how to set up, operate, maintain, and troubleshoot your watch to ensure its longevity and optimal performance. Please read this manual carefully before using your watch.

2. Product Overview

The KOMONO Wizard Print Series-Peacock watch is a stylish quartz timepiece featuring a unique peacock print strap and a light gold-toned dial. It is designed for everyday wear and combines functionality with a distinctive aesthetic.

2.1. Components

- **Watch Case:** Houses the movement and protects the dial.
- **Dial:** The face of the watch displaying the time.
- **Hands:** Hour, minute, and second hands.
- **Crown:** Small knob on the side used for setting the time.
- **Strap:** Adjustable band with peacock print design.
- **Buckle:** Secures the watch on your wrist.



Figure 1: Front view of the KOMONO Wizard Print Series-Peacock watch, showcasing the light gold dial and peacock print strap.



Figure 2: Angled view of the watch, highlighting the texture of the strap and the watch case.



Figure 3: The KOMONO watch displayed alongside its matching peacock-themed packaging box.

3. Setup

3.1. Initial Time Setting

Your watch may arrive with the crown pulled out to conserve battery life. Follow these steps to set the time:

1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch case) outwards until you feel a click. This will stop the second hand.
2. **Set the time:** Rotate the crown clockwise or counter-clockwise to move the hour and minute hands to the correct time.
3. **Push in the crown:** Once the time is set, push the crown back into its original position. The second hand will start moving again.

3.2. Wearing the Watch

Adjust the strap to fit comfortably around your wrist. The buckle should be securely fastened to prevent the watch from slipping or falling off.

4. Operating Instructions

4.1. Time Adjustment

If you need to adjust the time again (e.g., for daylight saving), simply repeat the steps outlined in Section 3.1.

4.2. Water Resistance

This watch is designed for everyday use and is resistant to minor splashes. It is not suitable for swimming, showering, or diving. Avoid exposing the watch to excessive moisture or submerging it in water to prevent damage to the movement.

5. Maintenance

5.1. Cleaning

- **Case and Dial:** Wipe gently with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the watch.
- **Strap:** For the fabric strap, gently wipe with a damp cloth and mild soap if necessary. Allow it to air dry completely before wearing. Avoid harsh chemicals.

5.2. Battery Replacement

The watch is powered by a quartz movement, which requires a battery. When the watch stops or the second hand begins to skip, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to avoid damaging the watch's internal components or compromising its water resistance.

5.3. Storage

When not in use, store your watch in a cool, dry place, away from direct sunlight, extreme temperatures, and strong magnetic fields. Keeping it in its original box or a watch case can help protect it from dust and scratches.

6. Troubleshooting

Problem	Possible Cause	Solution
Watch not running	Battery depleted	Replace battery (professional service recommended).
Time is inaccurate	Crown not fully pushed in	Push the crown fully into the watch case.

Problem	Possible Cause	Solution
Time is inaccurate	Strong magnetic field exposure	Move watch away from magnetic sources; reset time. If problem persists, seek professional service.
Condensation under crystal	Exposure to extreme temperature changes or moisture	Avoid extreme temperature changes. If condensation persists, seek professional service immediately to prevent damage.

7. Specifications

- **Model Name:** Wizard Print Series-Peacock
- **Model Number:** KOM-W1821 (Manufacturer Reference: 543524)
- **Movement:** Quartz
- **Brand:** KOMONO (other)
- **Case Material:** Not specified (typically alloy or stainless steel)
- **Strap Material:** Fabric with peacock print
- **Water Resistance:** Splash resistant (not suitable for submersion)

8. Warranty and Support

For information regarding warranty coverage and terms, please refer to the warranty card included with your purchase or contact the retailer from whom you purchased the watch. For technical support or service inquiries, please reach out to the authorized KOMONO service center or your point of purchase.

Always ensure that any repairs or battery replacements are carried out by qualified professionals to maintain the integrity and warranty of your watch.

© 2024 KOMONO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B073PQ6G8W

More documents and user manuals: **https://manuals.plus/**