Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Orbegozo VT 610

Orbegozo VT 610 Wine Cooler User Manual

Model: VT 610

1. Introduction

Thank you for purchasing the Orbegozo VT 610 Wine Cooler. This manual provides important information regarding the installation, operation, and maintenance of your appliance. Please read this manual thoroughly before use and keep it for future reference. Proper use and care will ensure optimal performance and longevity of your wine cooler.

2. Safety Instructions

To reduce the risk of fire, electric shock, or injury, follow these basic precautions:

- Read all instructions before using the appliance.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not operate the appliance with a damaged cord or plug. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Unplug from the outlet when not in use and before cleaning.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not use the appliance outdoors.
- Do not place the appliance near heat sources such as radiators, heat registers, stoves, or other appliances that produce heat.
- Ensure adequate ventilation around the appliance. Maintain specified clearances from walls and other objects.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

3. Product Components

Familiarize yourself with the main parts of your Orbegozo VT 610 Wine Cooler.



Figure 1: Front view of the Orbegozo VT 610 Wine Cooler. This image shows the sleek black exterior, glass door, and digital display panel at the top.

- **Glass Door:** Transparent door for viewing contents.
- **Digital Display and Touch Control Panel:** Located at the top, used for temperature settings and light control.
- **LED Interior Lighting:** Illuminates the interior for better visibility.
- **Removable Chrome Shelves:** Two shelves designed to hold wine bottles.
- **Adjustable Feet:** For leveling the appliance.

- **Integrated Handle:** For opening and closing the door.



Figure 2: Interior view of the wine cooler with the door open, showing the two chrome shelves and the internal LED light.

4. Setup and Installation

4.1 Unpacking

1. Carefully remove all packaging materials.
2. Check the appliance for any damage during transit. If damaged, do not operate and contact your retailer.
3. Keep packaging materials out of reach of children.

4.2 Placement

- Place the wine cooler on a flat, stable surface, away from direct sunlight and heat sources (e.g., ovens, radiators).
- Ensure there is adequate air circulation around the unit. Leave at least 10 cm (4 inches) of space at the back and

sides for proper ventilation.

- This is a freestanding appliance and should not be built-in.
- Adjust the leveling feet at the bottom of the unit to ensure it is stable and level.



Figure 3: Side view of the wine cooler, highlighting the ventilation grille. Proper clearance around these areas is crucial for efficient operation.

4.3 Initial Use

1. Before plugging in, allow the appliance to stand upright for at least 2 hours. This allows the refrigerant fluids to settle.
2. Clean the interior of the wine cooler with a damp cloth and mild detergent before first use.
3. Plug the appliance into a grounded electrical outlet.
4. Allow the wine cooler to operate empty for at least 24 hours to reach its stable operating temperature before loading bottles.

5. Operating Instructions

5.1 Control Panel

The Orbegozo VT 610 features a digital display and touch control panel for easy operation.



Figure 4: Close-up of the digital display and touch control panel, showing temperature setting buttons and light control.

- **Temperature Display:** Shows the current internal temperature or the set temperature.
- **Temperature Adjustment Buttons (Up/Down Arrows):** Used to increase or decrease the desired temperature.
- **Light Button:** Controls the internal LED lighting.
- **°C/°F Button:** Toggles between Celsius and Fahrenheit temperature display.

5.2 Setting the Temperature

1. Press the **Up** or **Down** arrow buttons on the touch panel to adjust the desired temperature.
2. The temperature range is between 8°C and 18°C (46°F and 64°F).
3. The display will flash the set temperature for a few seconds, then revert to showing the actual internal temperature.
4. The appliance will automatically adjust to reach and maintain the set temperature.

5.3 Loading Bottles

The wine cooler is designed to hold up to 6 standard wine bottles (750ml).



Figure 5: Front view of the wine cooler with bottles stored on the chrome shelves, visible through the glass door.

- Place bottles horizontally on the chrome shelves.
- Ensure bottles do not touch the back wall or obstruct the internal fan for optimal air circulation.
- Avoid overloading the shelves.

5.4 Auto-Defrost Function

The appliance features an automatic defrost function. Frost will melt and drain into a tray at the back of the unit, where it evaporates. This process is normal and does not require manual intervention.

6. Maintenance and Cleaning

6.1 Cleaning the Interior

1. Always unplug the wine cooler before cleaning.
2. Remove all bottles and shelves.
3. Wash the interior surfaces with a solution of mild detergent and warm water. Do not use abrasive cleaners or solvents.
4. Rinse thoroughly and dry with a soft cloth.
5. Clean the removable chrome shelves with warm soapy water, rinse, and dry completely before placing them back.

6.2 Cleaning the Exterior

- Wipe the exterior surfaces with a soft, damp cloth.
- For stubborn stains, use a mild, non-abrasive cleaner.
- Do not spray water directly onto the appliance.

6.3 Power Outage

In case of a power outage, the wine cooler can generally maintain the temperature for a few hours if the door remains closed. Avoid opening the door unnecessarily during a power outage.

6.4 Extended Absence

If the wine cooler will not be used for an extended period:

1. Unplug the appliance.
2. Empty all contents.
3. Clean the interior thoroughly.
4. Leave the door slightly ajar to prevent odors and mold growth.

7. Troubleshooting

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Appliance does not operate.	Not plugged in. Power outage. Circuit breaker tripped.	Ensure the plug is securely inserted into the outlet. Check the household fuse/circuit breaker. Try plugging into a different outlet.

Problem	Possible Cause	Solution
Temperature is not cold enough.	Door not closed properly. Frequent door openings. Ambient temperature too high. Ventilation blocked. Temperature setting too high.	Ensure the door is completely closed. Minimize door openings. Move the appliance to a cooler location. Ensure adequate clearance around the unit for ventilation. Lower the temperature setting.
Excessive noise.	Appliance not level. Vibrating against a wall or object.	Adjust the leveling feet. Ensure the appliance is not touching any walls or furniture.
Water on the floor.	Drainage hole blocked.	Check and clear any blockage in the drainage hole at the back of the interior.

8. Specifications

Feature	Detail
Brand	Orbegozo
Model	VT 610
Color	Black
Capacity	17 Liters (approx. 6 standard bottles)
Power	70 W
Voltage	230 Volt
Temperature Range	8°C - 18°C (46°F - 64°F)
Dimensions (L x W x H)	50.2 x 24.6 x 38.2 cm
Weight	7.6 kg
Material (Shelves)	Chrome
Energy Efficiency Class	B
Annual Energy Consumption	145 kWh
Noise Level	41 dB
Installation Type	Freestanding
Features	LED Interior Lighting, Digital Display, Touch Control Panel, Auto-Defrost Function

9. Warranty and Support

Specific warranty information is typically provided with your purchase documentation or can be found on the manufacturer's official website. Please refer to the warranty card included with your product for details on coverage and terms.

For technical support, spare parts, or service inquiries, please contact Orbegozo customer service through their official channels. Contact information can usually be found on the product packaging or the Orbegozo website.

© 2023 Orbegozo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B073QS4SVN

More documents and user manuals: **https://manuals.plus/**