Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi HFX60V20

De'Longhi HFX60V20 Ceramic Fan Heater User Manual

Introduction

This manual provides essential information for the safe and efficient operation of your De'Longhi HFX60V20 Ceramic Fan Heater. Please read these instructions carefully before using the appliance and retain them for future reference.

Important Safety Information

Always observe the following safety precautions to reduce the risk of fire, electric shock, or injury.

- Ensure the appliance is placed on a stable, flat surface to prevent tipping. The unit includes an anti-tip safety device.
- Do not cover the heater or obstruct the air inlets and outlets.
- Keep flammable materials such as furniture, pillows, bedding, papers, clothes, and curtains at least 1 meter (3 feet) from the front of the heater and away from the sides and rear.
- Do not use the heater in bathrooms, laundry areas, or similar indoor locations where it may come into contact with water.
- Unplug the heater when not in use.
- Do not operate any heater with a damaged cord or plug, or after the heater malfunctions or has been dropped or damaged in any manner.
- This appliance is equipped with a thermal safety device to prevent overheating. If the heater overheats, it will automatically shut off.

Product Overview and Components

Familiarize yourself with the main parts of your De'Longhi HFX60V20 ceramic fan heater.


ECO plus
MODE
ECO
21
h
1 2
+
−
ceramic technology
DēLonghi

Figure 1: Front view of the De'Longhi HFX60V20 Ceramic Fan Heater, showing the control panel and heating grille.

1. **Control Panel:** Features an LED display and touch buttons for various functions.
2. **Air Outlet Grille:** Where heated or cool air is expelled.
3. **Air Inlet:** Located at the rear of the unit.
4. **Base:** Provides stability for the unit.
5. **Remote Control:** Allows for convenient operation from a distance.





Figure 2: The remote control for the De'Longhi HFX60V20, featuring power, ECO, timer, mode, temperature adjustment, and oscillation buttons.

Setup

1. **Unpacking:** Carefully remove the heater from its packaging. Retain the packaging for storage or future transport.
2. **Placement:** Place the heater on a firm, level surface. Ensure there is at least 1 meter (3 feet) of clear space around the heater to allow for proper airflow and to prevent fire hazards.
3. **Power Connection:** Plug the power cord into a suitable electrical outlet (220 Volts). Ensure the outlet is in good condition and not overloaded.

Operation

The De'Longhi HFX60V20 features an intuitive electronic control panel and an LED display.

Control Panel Functions

- **Power Button ( ):** Press to turn the heater ON or OFF.
- **Mode Button:** Cycles through available operating modes:
  - **Fan Only (Summer Ventilation):** Circulates air without heating.
  - **Low Heat (1100W):** Provides gentle heating.
  - **High Heat (2000W):** Provides maximum heating power.
- **Temperature Adjustment Buttons (+ / -):** Adjust the desired room temperature. The LED display will show the set temperature.
- **ECO Function Button:** Activates the Eco-Energy function. In this mode, the heater automatically adjusts its power output to optimize energy consumption while maintaining the set temperature.

- **Timer Button ( ):** Sets the 24-hour timer for automatic shut-off. Press repeatedly to set the desired operating duration.
- **Oscillation Button (↻):** Activates or deactivates the oscillation feature, allowing the heater to rotate and distribute heat more widely.

Using the Remote Control

The remote control duplicates most functions of the main control panel, offering convenience for adjusting settings from a distance.

- Point the remote control directly at the heater's control panel.
- Ensure there are no obstructions between the remote control and the heater.
- Replace batteries when the remote control's range decreases or it stops responding.

Maintenance

Regular maintenance ensures optimal performance and longevity of your heater.

1. **Cleaning:** Before cleaning, always unplug the heater from the electrical outlet and allow it to cool down completely.
   - Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
   - Use a vacuum cleaner with a brush attachment to remove dust from the air inlet and outlet grilles.
   - Never immerse the heater in water or allow water to drip into the interior.
2. **Storage:** If the heater will not be used for an extended period, store it in its original packaging in a cool, dry place.

Troubleshooting

If you encounter issues with your De'Longhi HFX60V20, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply; Power button not pressed; Thermal safety device activated; Anti-tip switch activated.	Check if the plug is securely in the outlet. Ensure the power outlet is functional. Press the power button. If the heater overheated, unplug it, let it cool for 30 minutes, then plug it back in. Ensure the heater is on a flat surface and upright.
Heater produces cool air only.	Operating in Fan Only mode; Temperature setting is too low.	Press the Mode button to select a heat setting (Low or High). Increase the desired temperature using the '+' button.
Heater makes unusual noise.	Dust or debris in the fan; Unit not stable.	Unplug the heater and clean the air grilles. Ensure the heater is on a stable, level surface.

Problem	Possible Cause	Solution
Remote control not working.	Batteries are dead; Obstruction between remote and heater.	Replace the batteries in the remote control. Ensure a clear line of sight to the heater's control panel.

Specifications

Feature	Detail
Brand	De'Longhi
Model Number	HFX60V20
Type	Ceramic Fan Heater
Color	White/Grey
Power Output	2000 Watts (High), 1100 Watts (Low)
Voltage	220 Volts
Dimensions (L x W x H)	6.61 x 9.02 x 13.11 cm
Weight	1.8 Kilograms
Special Features	Silent Operation, 24h Timer, Anti-tip Protection, Adjustable Temperature, Electronic Thermostat, ECO Function, Summer Ventilation, Oscillation
Recommended Use	Indoor, Home

Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product or visit the official De'Longhi website. For technical support or service inquiries, please contact De'Longhi customer service through their official channels.

You can find more information and contact details on theDe'Longhi official website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B073WBL9VS

More documents and user manuals: **https://manuals.plus/**