De'Longhi EN95

De'Longhi Nespresso Essenza EN95 Series PCB Replacement Instruction Manual

Model: EN95 Series

Introduction

This instruction manual provides essential information and step-by-step guidance for the safe and correct replacement of the Printed Circuit Board (PCB) in your De'Longhi Nespresso Essenza EN95 series coffee machine. Please read this manual thoroughly before attempting any replacement procedures.
This component is an original De'Longhi Nespresso part designed for specific Essenza EN95 models. Incorrect installation or use may damage your appliance or void its warranty.

Compatibility

This PCB is compatible with the following De'Longhi Nespresso Essenza EN95 series models. Verify your machine's model number before proceeding with installation.

- EN95.M (Codes: 0132190014, 0132190015, 0132190018, 0132190016)
- EN95.W (Codes: 0132190011, 0132190013, 0132190012, 0132190017)
- EN95.P (Codes: 0132190033, 0132190035, 0132190037, 0132190039)
- EN95.S (Codes: 0132190034, 0132190036, 0132190038, 0132190040, 0132190064)
- EN95.R (Codes: 0132190054, 0132190052, 0132190053, 0132190055)
- EN95.RD (Codes: 0132190071, 0132190072)
- EN95.GY (Codes: 0132190077, 0132190076, 0132190080)

If your specific model is not listed, please contact De'Longhi customer support for compatibility verification before attempting installation.

Safety Information

Always observe the following safety precautions when handling electronic components and performing repairs:

- **Disconnect Power:** Ensure the coffee machine is unplugged from the main power supply before beginning any work.
- **Static Discharge:** Discharge any static electricity from your body before touching electronic components. This can be done by touching a grounded metal object.
- **Tools:** Use appropriate, insulated tools for the task.
- **Professional Assistance:** If you are unsure about any step or lack experience with electronic repairs, seek assistance from a qualified technician.
- **Component Handling:** Handle the PCB by its edges to avoid touching sensitive components.

Installation and Replacement Instructions

Follow these steps carefully to replace the PCB in your De'Longhi Nespresso Essenza EN95 coffee machine. Refer to your specific machine's service manual for detailed disassembly instructions if needed.

1. **Preparation:** Ensure the coffee machine is unplugged and completely cooled down. Clear a clean, well-lit workspace.
2. **Access the Existing PCB:** Carefully disassemble the coffee machine casing to gain access to the existing PCB. This typically involves removing screws and clips. Document the location of all screws and components.
3. **Disconnect Wiring:** Before removing the old PCB, take clear photos of all wire connections. Disconnect all wires and connectors from the old PCB. Note their positions for correct re-connection.
4. **Remove Old PCB:** Unscrew or unclip the old PCB from its mounting points. Carefully lift it out of the machine.
5. **Install New PCB:** Position the new De'Longhi Nespresso Essenza EN95 PCB in the same location as the old one. Secure it with the original screws or clips.
6. **Connect Wiring:** Refer to your photos and reconnect all wires and connectors to the new PCB. Ensure each connection is firm and correctly seated.
7. **Reassemble Machine:** Carefully reassemble the coffee machine casing, ensuring all components are properly aligned and secured. Do not force any parts.




Image 1: De'Longhi Nespresso Essenza EN95 Series Printed Circuit Board (PCB). This image displays the replacement PCB,

showing its main body, heat sink, and connected wiring harness with a small green circuit board at the end.

Post-Installation Check

After reassembling the machine, perform the following checks:

- **Visual Inspection:** Ensure all screws are tightened, and the casing is properly closed. Check for any loose wires or components.
- **Initial Power-Up:** Plug the machine back into the power outlet. Observe for any unusual sounds, smells, or error indicators.
- **Functionality Test:** Perform a test cycle without a coffee capsule to ensure basic functions like water heating and dispensing are operational.

Troubleshooting

If you encounter issues after replacing the PCB, consider the following:

- **Machine Not Powering On:** Double-check all power connections and ensure the machine is properly plugged in. Verify that the new PCB is correctly seated and all connectors are firm.
- **Error Lights/Codes:** Consult your coffee machine's original user manual for specific error code interpretations. This may indicate an incorrect connection or a fault with another component.
- **Incorrect Functionality:** If the machine powers on but functions incorrectly (e.g., no water flow, incorrect temperature), re-verify all wire connections to the PCB against your reference photos.
- **Persistent Issues:** If problems persist, disconnect power and carefully re-open the machine to inspect the PCB and connections. If the issue cannot be resolved, contact De'Longhi customer support or a qualified service technician.

Specifications

Feature	Detail
Brand	De'Longhi
Product Type	Printed Circuit Board (PCB)
Compatible Models	Nespresso Essenza EN95 Series (EN95.M, EN95.W, EN95.P, EN95.S, EN95.R, EN95.RD, EN95.GY)
Dimensions (L x W x H)	7.6 x 3.5 x 11 cm (approximately 3 x 1.4 x 4.3 inches)
Weight	110 grams (approximately 0.24 lbs)
Manufacturer	De'Longhi

Warranty and Support

This original De'Longhi component is covered by the manufacturer's standard warranty. For specific warranty terms and conditions, please refer to the documentation provided with your original coffee machine or contact De'Longhi customer service.

For technical support, troubleshooting assistance, or to inquire about professional repair services, please visit the official De'Longhi website or contact their customer support line.

De'Longhi Nespresso Essenza EN95 Series PCB Replacement Manual | © 2023 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question