Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi HFX30C18.AG

De'Longhi Ceramic Heater HFX30C18.AG Instruction Manual

1. Introduction

Thank you for choosing the De'Longhi Ceramic Heater HFX30C18.AG. This manual provides essential information for the safe and efficient use of your appliance. Please read these instructions carefully before operating the heater and retain them for future reference.

Important Safety Information

- Always ensure the heater is placed on a stable, level surface.
- Do not cover the heater or obstruct its air inlets/outlets.
- Keep flammable materials at least 1 meter (3 feet) away from the heater.
- Do not use the heater in bathrooms, laundry areas, or similar indoor locations where it may come into contact with water.
- Unplug the heater when not in use or before cleaning.
- This appliance is equipped with an automatic tip-over safety switch, which turns off the unit if it falls over.

2. Product Overview

The De'Longhi HFX30C18.AG is a portable ceramic fan heater designed for efficient and rapid heating of indoor spaces. It features ceramic heating technology for optimal heat distribution and a mechanical control panel for straightforward operation.





Figure 1: Angled view of the De'Longhi Ceramic Heater HFX30C18.AG, showcasing its anthracite finish and integrated carry handle.


DēLonghi
ceramic
technology

Figure 2: Front view of the De'Longhi Ceramic Heater HFX30C18.AG, highlighting the ceramic technology label and control panel area.

Main Components

- **Heating Element:** Ceramic PTC element for self-regulating heat.
- **Control Panel:** Mechanical dials for power and thermostat settings.
- **Air Inlet/Outlet Grilles:** For air circulation.
- **Carry Handle:** For easy portability.
- **Safety Switch:** Automatic tip-over shut-off.

3. Setup

Follow these steps to set up your ceramic heater:

1. **Unpack:** Carefully remove the heater from its packaging. Retain packaging for storage or transport.
2. **Placement:** Place the heater on a firm, level, and stable surface. Ensure there is at least 1 meter (3 feet) of clear space around the front and sides of the heater, and 30 cm (1 foot) at the rear. Do not place it directly under a power outlet.
3. **Power Connection:** Ensure the heater is switched off (control dial set to '0' or 'OFF'). Plug the power cord into a suitable electrical outlet (230 Volts).



Figure 3: The De'Longhi Ceramic Heater HFX30C18.AG positioned in a room, demonstrating appropriate placement away from furniture.

4. Operation

Operating your De'Longhi ceramic heater is straightforward using the mechanical control panel.

Power On/Off and Heat Settings

1. **Power On:** Turn the function selector dial to your desired heat setting. The heater has two power levels:
    - **Low Power:** For gentle, continuous heat.
    - **High Power (1800W):** For rapid heating of the room.
2. **Thermostat Control:** Use the thermostat dial to set the desired room temperature. The heater will cycle on and off to maintain this temperature.
3. **Antifreeze Function:** Set the thermostat to the snowflake symbol (❄). The heater will automatically turn on if the room temperature drops below approximately 5°C (41°F) to prevent freezing.
4. **Power Off:** Turn the function selector dial to the '0' or 'OFF' position. Unplug the heater from the wall socket when not in use.

5. Maintenance

Regular maintenance ensures the longevity and efficient operation of your heater.

Cleaning

- Always unplug the heater and allow it to cool completely before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Use a vacuum cleaner with a brush attachment to remove dust from the air inlet and outlet grilles.
- Never immerse the heater in water or allow water to drip into the interior.

Storage

When not in use, store the heater in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

6. Troubleshooting

If you encounter issues with your heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply. Tip-over safety switch activated. Thermostat set too low.	Check power cord connection and wall outlet. Ensure heater is upright on a stable surface. Increase thermostat setting.
Heater produces insufficient heat.	Low power setting selected. Room temperature already reached.	Select a higher power setting. Increase thermostat setting.
Heater turns off unexpectedly.	Overheat protection activated. Tip-over safety switch activated.	Unplug, allow to cool for 30 minutes, check for obstructions. Ensure heater is upright on a stable surface.

7. Specifications

Detailed technical specifications for the De'Longhi Ceramic Heater HFX30C18.AG:

Feature	Specification
Brand	De'Longhi
Model Number	HFX30C18.AG
Color	Anthracite
Product Dimensions (L x W x H)	13.7 x 27 x 19.2 cm
Weight	1.3 Kilograms
Power	1800 Watts
Voltage	230 Volts
Material	Plastic
Number of Power Levels	2
Noise Level	44 Decibels
Special Feature	Adjustable Thermostat, Antifreeze Function, Tip-over Safety
Recommended Room Size	Up to 55 m²
Power Source	Electric
Recommended Use	Indoor
Country of Origin	China

8. Warranty and Support

De'Longhi products are manufactured to high standards and are subject to rigorous quality control. This product comes with a manufacturer's warranty covering defects in materials and workmanship.

- **Spare Parts Availability:** Spare parts are generally available for 1 year from the date of purchase.
- **Warranty Claims:** For warranty claims or technical support, please refer to the warranty card included with your product or visit the official De'Longhi website for contact information.
- **Proof of Purchase:** Always retain your proof of purchase for warranty validation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0742H5CX6

More documents and user manuals: **https://manuals.plus/**