Nokia TA-1032

Nokia 3 TA-1032 Smartphone User Manual

Model: TA-1032

Introduction

This manual provides comprehensive instructions for the Nokia 3 TA-1032 smartphone. It covers essential information regarding setup, operation, maintenance, and troubleshooting to ensure optimal use of your device.
The Nokia 3 TA-1032 is designed with a focus on durability and user experience, featuring a sculpted 5-inch display with Corning Gorilla Glass and a precision-machined full aluminum frame.

What's in the Box

- Nokia 3 TA-1032 Smartphone
- Battery
- Charger
- USB Cable

Setup

1. Inserting the SIM Card and Memory Card

The Nokia 3 TA-1032 supports Dual SIM functionality. Locate the SIM tray on the side of the device. Use a SIM ejector tool (if provided) or a small paperclip to open the tray.
Carefully place your Nano-SIM card(s) into the designated slots. If using a microSD card for expanded storage (up to 128GB, not included), insert it into the memory card slot.
Ensure the cards are correctly oriented as indicated on the tray. Gently push the tray back into the device until it clicks into place.



Image: Nokia 3 TA-1032 displaying the side profile with the SIM/memory card tray. This image illustrates the location and appearance of the tray for inserting SIM and microSD cards.

2. Charging the Battery

Before first use, fully charge the integrated 2630 mAh battery. Connect the USB cable to the phone's charging port and the other end to the power adapter. Plug the adapter into a wall outlet.
The battery indicator on the screen will show the charging status. It is recommended to use only Nokia-approved chargers and cables.

3. Initial Power On and Setup Wizard

Press and hold the power button until the phone vibrates and the Nokia logo appears. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, Google account sign-in, and security settings.

Operating Your Device

Basic Navigation

- **Power Button:** Press to turn the screen on/off. Press and hold to power on/off or restart.
- **Volume Buttons:** Adjust media volume during playback or ringtone volume.
- **Touchscreen:** Navigate by tapping, swiping, pinching, and spreading.
- **Home Button:** Return to the home screen.
- **Back Button:** Go back to the previous screen.
- **Recent Apps Button:** View and switch between recently used applications.

Making Calls

Open the Phone app, dial the number, and tap the call icon. For dual SIM models, you may be prompted to select which SIM to use for the call.

Sending Messages

Open the Messages app, tap the new message icon, enter the recipient's number or select from contacts, type your message, and tap send.

Camera Functionality

The Nokia 3 TA-1032 features 8MP autofocus cameras on both the front and back. Open the Camera app, select your

desired mode (photo, video, panorama), frame your shot, and tap the shutter button.



Image: Multiple views of the Nokia 3 TA-1032 smartphone, showcasing its front display, rear camera, and overall design. This image provides a comprehensive visual of the device's exterior.

Internet Connectivity (4G LTE)

Your device supports 4G LTE connectivity for fast downloads and uninterrupted music and video streaming. Ensure your SIM card has an active data plan. You can also connect to Wi-Fi networks via Settings > Network & internet > Wi-Fi.

Maintenance

Software Updates

The Nokia 3 TA-1032 runs on Android Nougat and receives regular software updates. To check for updates, go to Settings > System > System update. Keeping your software up to date ensures optimal performance and security.

Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of the phone. Avoid using harsh chemicals or abrasive materials. For stubborn smudges, slightly dampen the cloth with water.

Battery Care

To prolong battery life, avoid exposing the phone to extreme temperatures. Do not fully discharge the battery regularly. For optimal performance, keep the battery charge between 20% and 80%.

Troubleshooting

Phone Not Turning On

- Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on.
- Press and hold the power button for at least 10-15 seconds to force a restart.

Poor Network Signal

- Check if your SIM card is properly inserted.
- Move to an area with better network coverage.
- Restart the phone.
- Go to Settings > Network & internet > Mobile network and ensure mobile data is enabled and preferred network type is set correctly.

Apps Crashing or Freezing

- Close the app and reopen it.
- Clear the app's cache and data (Settings > Apps & notifications > [App Name] > Storage & cache).
- Ensure the app is updated to its latest version.
- Restart your phone.

Battery Draining Quickly

- Reduce screen brightness.
- Turn off Wi-Fi, Bluetooth, and GPS when not in use.
- Limit background app refresh.
- Check battery usage in Settings > Battery to identify power-hungry apps.

Specifications

Feature	Detail
Model Name	Nokia 3
Model Number	TA-1032
Operating System	Android Nougat
Display Size	5 Inches
Resolution	720 x 1440
Processor	MTK 6737, Quad-core 1.3Ghz
RAM	2 GB
Internal Storage	16 GB (12.3 GB User Accessible)
Expandable Storage	Micro SD up to 128GB (Not included)
Rear Camera	8 MP Autofocus with Flash
Front Camera	8 MP Autofocus
Battery Capacity	Integrated 2630 mAh
Connectivity	4G LTE, Wi-Fi, Bluetooth, NFC, GPS

Feature	Detail
SIM Type	Dual SIM (Nano-SIM)
Audio Jack	3.5 mm
Dimensions (L x W x H)	5.65 x 2.81 x 0.33 inches
Weight	5 ounces

Warranty and Support

Please note that this is an International Model of the Nokia 3 TA-1032 and**does not come with a US warranty**. For support, please refer to the seller or the official Nokia support channels in your region, if applicable.
For further assistance, visit the official Nokia support website or contact their customer service.

© 2024 Nokia. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question