De'Longhi EH1140

De'Longhi Ice Cream Maker Bowl Instruction Manual

Brand: **De'Longhi** | Model: **EH1140**

1. Introduction

This manual provides essential information for the proper use and maintenance of your De'Longhi removable ice cream maker bowl. This original De'Longhi/Simac product is designed to be compatible with various Simac and De'Longhi ice cream maker models.

Compatible Models: GC5000, GC6000, GB8000, GC2000E, Personal Ice Maker 1200, ICK5000, ICK6000, ICK8000, IM6000, and other specified versions like GC2000E Family Plus, GC 5000 Basic Made in Italy S01, GC 6000 900055, GC5000 EX:3, GC6000 EX:3, GM6000.

Please verify your ice cream maker's model number against this list to ensure compatibility before use.

2. Product Overview



Figure 1: De'Longhi removable ice cream maker bowl. This image shows the stainless steel bowl with a white plastic central spindle, designed to fit into compatible ice cream machines for churning ingredients.

The removable bowl is a key component for preparing frozen desserts. Its design allows for efficient freezing and churning when used with a compatible ice cream machine.

3. Setup and Preparation

Before first use, and before each subsequent use, ensure the bowl is properly prepared.

1. **Cleaning:** Wash the bowl thoroughly with warm water and mild soap. Rinse completely and dry thoroughly. Refer to the "Maintenance" section for detailed cleaning instructions.
2. **Freezing:** For optimal results, the bowl must be completely frozen. Place the clean, dry bowl in the freezer for a minimum of 12-24 hours, or until it is thoroughly frozen. The colder the bowl, the better the ice cream will churn and freeze.
3. **Placement:** Once frozen, carefully remove the bowl from the freezer and place it into your compatible De'Longhi or Simac ice cream maker according to your machine's specific instructions. Ensure it is securely seated before adding ingredients.

4. Operating Instructions

This bowl functions as the freezing chamber for your ice cream maker. Follow these general steps for operation:

1. **Prepare Mixture:** Prepare your desired ice cream, gelato, or sorbet mixture according to your recipe. Ensure the mixture is chilled before adding it to the frozen bowl.

2. **Add Mixture:** With the frozen bowl securely in place within the ice cream maker, pour the chilled mixture into the bowl. Do not overfill; leave space for the mixture to expand as it freezes.
3. **Start Churning:** Assemble the ice cream maker's lid and paddle (if applicable) and turn on the machine. The machine will begin to churn the mixture, and the frozen bowl will gradually freeze it.
4. **Monitor Process:** Churning time will vary depending on the recipe and desired consistency, typically 20-40 minutes. The mixture will thicken as it freezes.
5. **Serve or Store:** Once the desired consistency is reached, turn off the machine. Remove the ice cream from the bowl using a plastic or wooden utensil to avoid scratching the bowl's surface. Serve immediately or transfer to an airtight container for storage in the freezer.

5. Maintenance and Care

Proper care ensures the longevity and performance of your ice cream maker bowl.

- **Cleaning:** After each use, allow the bowl to return to room temperature before cleaning. Hand wash the bowl with warm water and a mild dish soap. Use a soft sponge or cloth.
- **Drying:** Rinse the bowl thoroughly to remove all soap residue. Dry the bowl completely with a soft cloth before storing or placing it back in the freezer. Ensure no water remains, especially in crevices, to prevent ice buildup.
- **Storage:** Store the bowl in a dry place. For convenience, you may store it in the freezer so it is always ready for use.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or metal utensils on the bowl, as these can damage the surface.
- **Dishwasher:** This bowl is not dishwasher safe. Hand washing is required.

6. Troubleshooting

If you encounter issues with your ice cream maker bowl, consider the following common points:

Problem	Possible Cause	Solution
Ice cream not freezing properly.	Bowl not sufficiently frozen. Mixture not chilled enough.	Ensure bowl is frozen for 12-24 hours. Chill mixture in refrigerator for at least 2 hours before churning.
Bowl does not fit into the machine.	Incorrect model compatibility.	Double-check your ice cream maker's model number against the compatible models list in Section 1.
Scratches on the bowl's surface.	Use of metal utensils.	Always use plastic or wooden utensils when scraping ice cream from the bowl.

7. Specifications

Feature	Detail
Brand	De'Longhi
Model Number	EH1140
Product Dimensions	15 x 15 x 8.5 cm

Feature	Detail
Item Weight	250 grams
Material	Stainless Steel
Color	See images and description
Special Features	Removable
Automatic Shutoff	No
Included Components	Bowl, Container
Operation Mode	Automatic (when used with compatible machine)
Care Instructions	Hand wash with warm water and mild soap, dry thoroughly.
Recommended Uses	Ice cream making with compatible De'Longhi and Simac ice cream machines.
Manufacturer	De'Longhi

8. Warranty and Support

For specific warranty information regarding your De'Longhi ice cream maker bowl, please refer to the documentation provided with your original ice cream machine or contact De'Longhi customer support directly. Warranty terms may vary by region and purchase date.

If you require technical assistance or have questions not covered in this manual, please visit the official De'Longhi website or contact their customer service department. You may also refer to the seller for support related to your purchase.

Note: Extended protection plans may be available from your retailer. Please check with your point of purchase for details.

© 2024 De'Longhi. All rights reserved.
This manual is for informational purposes only. De'Longhi is not responsible for any damages or injuries resulting from improper use of this product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question