Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi 5512500019

De'Longhi Round Frying Basket Instruction Manual

Model: 5512500019

Introduction

This instruction manual provides essential information for the safe and effective use and maintenance of your De'Longhi Round Frying Basket. Please read this manual thoroughly before installation and use, and retain it for future reference. This round frying basket is an original De'Longhi accessory designed for use with specific Rotofry and EasyClean series fryers. Ensure compatibility with your fryer model before use.

Product Overview



Figure 1: De'Longhi Round Frying Basket. This image shows the complete round frying basket made of metal mesh, featuring a sturdy rim and a central support bar. It is designed to hold food during the frying process in compatible De'Longhi fryers.

The De'Longhi Round Frying Basket is a genuine replacement or accessory part, crafted from durable metal mesh for optimal frying performance and longevity. It features a robust circular frame and a central support structure to ensure stability and even cooking.

Compatibility

This frying basket is compatible with the following De'Longhi Rotofry / EasyClean fryer models:

- FPA series
- FP F884
- F881
- F28311
- F28211
- F28233
- D 15D (Article No: 0125250013)
- D14D (Article No: 0125270002)
- Friggimeglio FPA (Article No: 0125200018, 0125200025)

- FP103A (Article No: 0125200060)
- F895 (110V) (Article No: 0125890032)
- F28533.BK (Article No: 0125503709, 0125503720)
- D28533.UX (Article No: 0125503708)
- Friggimeglio FPEC (Article No: 0125250009)
- F28311.W1 EX:1 (Article No: 0125304705)
- F 880.WO (Article No: 0125852005)
- F 880 (Article No: 0125692008)
- F885V (Article No: 0125806013, 0125806020)
- FP100 (Article No: 0125250032)
- D 895UX (Article No: 0125890025)
- F 891 (Article No: 0125840001)
- F28311 EX:1 (Article No: 0125304704)
- D881C (Article No: 0125842001)
- Friggimeglio FPAY (Article No: 0125200032)
- F 890 (Article No: 0125850000)

Always verify compatibility with your specific fryer model number before purchase and use. If unsure, consult your fryer's original manual or contact De'Longhi customer support.

Setup and Installation

1. **Unpacking:** Carefully remove the frying basket from its packaging. Inspect for any signs of damage.
2. **Initial Cleaning:** Before first use, wash the frying basket thoroughly with warm, soapy water. Rinse completely and dry with a soft cloth. Ensure no soap residue remains.
3. **Placement in Fryer:** Refer to your specific De'Longhi fryer's instruction manual for precise placement of the frying basket. Generally, the basket is designed to fit securely within the fryer's oil reservoir. Ensure it is seated correctly and does not obstruct any heating elements or stirring mechanisms (if applicable).

Operating Instructions

This section outlines the general use of the frying basket. Always follow the operating instructions provided with your specific De'Longhi fryer model for detailed cooking procedures.

1. **Prepare Food:** Cut food items to appropriate sizes for frying. Ensure food is dry to minimize oil splattering.
2. **Load Basket:** Place the food evenly into the frying basket. Do not overfill the basket, as this can lead to uneven cooking and lower oil temperature. Leave sufficient space for oil circulation.
3. **Lower into Oil:** Carefully lower the loaded basket into the preheated oil in your fryer. Use the basket handle for safe handling.
4. **Frying:** Follow your fryer's instructions for cooking times and temperatures.
5. **Remove Basket:** Once cooking is complete, carefully lift the basket from the oil using the handle. Allow excess oil to drain back into the fryer.

6. **Serve:** Transfer the fried food to a serving dish lined with paper towels to absorb any remaining oil.

Safety Warning: Always exercise extreme caution when handling hot oil and hot fryer components. Use heat-resistant gloves if necessary.

Maintenance and Cleaning

Regular cleaning and maintenance will extend the life of your frying basket and ensure hygienic operation.

1. **After Each Use:** Allow the basket to cool completely before cleaning.
2. **Washing:** Wash the frying basket with warm water and a mild dish soap. Use a non-abrasive brush or sponge to remove food particles and oil residue.
3. **Stubborn Residue:** For stubborn, baked-on residue, soak the basket in hot, soapy water for a period before scrubbing.
4. **Rinsing:** Rinse the basket thoroughly under running water to remove all soap and food debris.
5. **Drying:** Dry the basket completely with a soft cloth or allow it to air dry before storing. Ensure no moisture remains to prevent rust.
6. **Storage:** Store the clean, dry basket in a dry place, preferably within the fryer itself or in a cabinet.

Caution: Do not use abrasive cleaners, steel wool, or harsh chemicals, as these can damage the basket's finish and material.

Troubleshooting

This section addresses common issues related to the frying basket. For fryer-specific issues, refer to your fryer's manual.

- **Basket does not fit:**
  - Ensure you have the correct model of frying basket for your De'Longhi fryer. Refer to the "Compatibility" section.
  - Check for any obstructions inside the fryer's oil reservoir.
- **Food sticks to the basket:**
  - Ensure the basket is clean before use.
  - Do not overfill the basket; allow space for food to move and oil to circulate.
  - Ensure food is dry before placing it in the basket.
- **Basket appears discolored or rusted:**
  - Discoloration can occur over time due to heat and oil, which is normal.
  - Rust indicates improper drying or storage. Ensure the basket is completely dry before storing. If rust is significant, consider replacing the basket.

Specifications

Brand:	De'Longhi
Model Number:	5512500019

Product Type:	Round Frying Basket
Material:	Metal Mesh
Color:	Silver (metal)
Compatibility:	De'Longhi Rotofry / EasyClean Fryers (various models, see "Compatibility" section)

Warranty and Support

This De'Longhi accessory is covered by the standard De'Longhi warranty policy. For specific warranty terms and conditions, please refer to the documentation included with your original De'Longhi fryer or visit the official De'Longhi website.

For technical support, replacement parts, or warranty claims, please contact De'Longhi customer service. Contact information can typically be found on the official De'Longhi website or in your fryer's original manual.

Please have your product model number (5512500019) and your fryer's model number ready when contacting support.

© 2024 De'Longhi. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B074FY3G5J

More documents and user manuals: **https://manuals.plus/**