Parkside PHD 150 D3

Parkside PHD 150 D3 Spray Gun User Manual

Model: PHD 150 D3 | Brand: Parkside

1. Introduction

This manual provides essential instructions for the safe and effective operation, setup, and maintenance of your Parkside PHD 150 D3 Spray Gun. Please read this manual thoroughly before using the product and retain it for future reference. The Parkside PHD 150 D3 is designed for use with pressure washers, featuring a robust construction and a maximum operating pressure of 150 bar.

2. Safety Information

Warning: Always observe general safety precautions when operating high-pressure equipment. Failure to follow these instructions may result in injury or damage to the product. Ensure all connections are secure before use. Keep children and pets away from the operating area. Always wear appropriate personal protective equipment (PPE), such as eye protection.

- Do not point the spray gun at people, animals, or electrical equipment.
- Ensure the child safety trigger is engaged when the spray gun is not in use.
- Never exceed the maximum operating pressure of 150 bar.
- Disconnect the spray gun from the pressure washer before performing any maintenance or when not in use.

3. Product Overview

The Parkside PHD 150 D3 Spray Gun is a durable accessory for pressure washing tasks. It features a comfortable grip, a threaded connection for secure attachment, and an integrated child safety lock on the trigger mechanism.



Image 1: The Parkside PHD 150 D3 Spray Gun. This image shows the black and yellow spray gun from a side view, highlighting its ergonomic handle, threaded connection point, and the nozzle end.

Key Features:

- **Model:** PHD 150 D3
- **Connection:** Threaded connection
- **Safety:** Trigger with child safety lock
- **Maximum Pressure:** Up to 150 bar
- **Material:** Metal components for durability

4. Setup

1. **Inspect Components:** Before assembly, ensure all parts of the spray gun are present and undamaged.
2. **Connect to Pressure Washer Hose:** Attach the high-pressure hose from your pressure washer to the threaded inlet connection on the spray gun. Ensure the connection is tight and secure to prevent leaks under pressure.
3. **Attach Nozzle/Lance (if applicable):** If your pressure washer system uses a separate lance or nozzle, attach it to the front end of the spray gun according to your pressure washer's instructions.
4. **Check for Leaks:** Before starting the pressure washer, briefly run water through the system at low pressure to check for any leaks.

5. Operating Instructions

1. **Engage Safety:** Before starting the pressure washer, ensure the child safety lock on the trigger is engaged (if not already).
2. **Start Pressure Washer:** Turn on your pressure washer according to its manufacturer's instructions.
3. **Disengage Safety:** To operate the spray gun, disengage the child safety lock.
4. **Activate Spray:** Squeeze the trigger to begin spraying. The water will be discharged at high pressure.
5. **Control Spray:** Maintain a firm grip on the spray gun. Adjust your distance from the cleaning surface to control the

intensity of the spray.

6. **Stop Spray:** Release the trigger to stop the water flow.
7. **Engage Safety After Use:** Always engage the child safety lock immediately after releasing the trigger and when the spray gun is not in active use.
8. **Shut Down:** After completing your task, turn off the pressure washer and relieve any remaining pressure in the system by briefly squeezing the spray gun trigger while the machine is off.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your spray gun.

- **Cleaning:** After each use, rinse the spray gun thoroughly with clean water to remove any detergent residues or debris.
- **Inspection:** Periodically inspect the threaded connections and the body of the spray gun for any signs of wear, cracks, or damage.
- **Storage:** Store the spray gun in a clean, dry place, protected from frost and direct sunlight. Ensure the safety lock is engaged during storage.
- **Nozzle Care:** If using a separate nozzle, ensure it is kept clean and free from blockages.

7. Troubleshooting

Problem	Possible Cause	Solution
Water leaks from connections	Loose connection, worn O-ring/seal	Tighten connections. Inspect and replace O-rings/seals if damaged.
No water flow or weak pressure	Blocked nozzle, kinked hose, pressure washer issue	Check and clear nozzle. Ensure hose is not kinked. Refer to pressure washer manual.
Trigger stuck or difficult to press	Safety lock engaged, internal debris	Ensure safety lock is disengaged. Clean the trigger mechanism if accessible, or consult a service professional.

8. Specifications

Brand: Parkside

Model Number: PHD 150 D3 (IAN 102798)

Manufacturer Reference: 91097260102798

Material: Metal

Maximum Pressure: 150 Bar

Input Connection Type: Threaded connection

Output Connection Type: Threaded connection

Certification: CE

Number of Ports: 1

9. Warranty and Support

For warranty information, please refer to the documentation provided with your original pressure washer unit or contact Parkside customer support. Information regarding the availability of spare parts for this specific spray gun is currently not

available. For technical assistance or service inquiries, please contact your retailer or the manufacturer directly.
ASIN: B074KJ6NCQ

© 2023 Parkside. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question