ONN ONA17CA010

ONN HD Camcorder User Manual

Model: ONA17CA010

Introduction

This manual provides comprehensive instructions for the operation, maintenance, and troubleshooting of your ONN HD Camcorder, Model ONA17CA010. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your recording experience. This camcorder is designed for capturing high-definition video and still images, suitable for various personal recording needs.

Product Overview

The ONN HD Camcorder is a compact and easy-to-use device featuring a 1.44-inch screen and 2X digital zoom. It records video in 720p HD resolution (up to 1280 x 720) and captures 5MP still images. Video is recorded to an SD memory card (Class 4 or higher, sold separately).

Camcorder Components

- HD Camcorder Unit
- 1.44-inch LCD Screen
- Lens with 2X Digital Zoom
- Control Buttons (Power, Record, Mode, Menu, Navigation)
- Battery Compartment
- SD Card Slot
- USB Port

Visual Guide



Figure 1: The ONN HD Camcorder as packaged, showing the device and its 1.44-inch screen feature.



Figure 2: Side view of the camcorder, highlighting the adjustable hand strap for secure grip during operation.



Figure 3: Rear view of the camcorder with the LCD screen rotated open, displaying the screen and control buttons.



Figure 4: Front view of the camcorder, focusing on the lens and its protective casing.

Setup

1. Battery Installation

The camcorder requires 2 AA batteries. Locate the battery compartment on the bottom or side of the device. Open the cover, insert the batteries according to the polarity indicators (+/-), and close the cover securely.

2. SD Card Installation

This camcorder records to an SD memory card (Class 4 or higher recommended, sold separately). Locate the SD card slot, typically near the battery compartment or on the side. Insert the SD card with the metal contacts facing down until it clicks into place. To remove, gently push the card in until it springs out.

3. Initial Power On

Press and hold the Power button (usually marked with a power symbol) to turn on the camcorder. The 1.44-inch LCD screen will illuminate. If the screen does not turn on, ensure batteries are correctly installed and charged, and an SD card is present.

Operating Instructions

Recording Video

1. Turn on the camcorder.
2. Ensure the camcorder is in video recording mode. If not, press the 'Mode' button until the video icon appears on the screen.
3. Frame your shot using the LCD screen.
4. Press the 'Record' button (often marked with a red dot) to start recording. A red indicator light or on-screen timer will confirm recording is active.
5. Press the 'Record' button again to stop recording. The video file will be saved to the SD card.

Taking Photos

1. Turn on the camcorder.
2. Press the 'Mode' button until the camera icon appears on the screen to switch to still photo mode.
3. Frame your shot.
4. Press the 'Shutter' or 'Record' button (depending on model) to capture a photo. The image will be saved to the SD card.

Playback

1. Turn on the camcorder.
2. Press the 'Mode' button to enter playback mode (usually indicated by a play icon).
3. Use the navigation buttons (up/down or left/right) to browse through your recorded videos and photos.
4. Press the 'OK' or 'Play' button to view a selected file.

Connecting to a Computer

To transfer files, connect the camcorder to your computer using the provided USB cable. The camcorder should appear as a removable disk drive on your computer. You can then drag and drop files from the SD card to your computer.

Using Video Editing Software

The camcorder includes video editing software. Install this software on your computer by following the instructions provided with the software disc or download link. This software allows you to edit, enhance, and manage your recorded videos.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the camcorder body. For the lens and screen, use a specialized lens cleaning cloth and solution. Avoid abrasive cleaners.
- **Storage:** When not in use, store the camcorder in a cool, dry place away from direct sunlight and extreme temperatures. Remove batteries if storing for extended periods to prevent leakage.
- **Battery Care:** Use only recommended AA batteries. Replace all batteries at the same time. Do not mix old and new batteries.

Troubleshooting

Problem	Possible Cause	Solution
Camcorder does not turn on.	Dead or incorrectly inserted batteries. No SD card inserted.	Replace batteries with fresh ones, ensuring correct polarity. Insert a compatible SD card.
Video quality is poor/pixelated.	Low light conditions. Dirty lens. SD card speed is too slow.	Ensure adequate lighting. Clean the lens. Use a Class 4 or higher SD card.
Cannot transfer files to computer.	Loose USB connection. Driver issue.	Ensure USB cable is securely connected to both devices. Try a different USB port. Restart computer and camcorder.
SD card error.	Incompatible or corrupted SD card.	Ensure SD card is Class 4 or higher. Try formatting the SD card (this will erase all data). Try a different SD card.

Specifications

Feature	Detail
Model Number	ONA17CA010
Video Capture Resolution	720p (Up to 1280 x 720)
Photo Sensor Technology	CMOS
Screen Size	1.44 Inches
Digital Zoom	2X
Flash Memory Type	SD (Class 4 or Higher Required)
Video Capture Format	MP4
Supported Audio Format	AAC

Feature	Detail
Connectivity Technology	USB
Batteries	2 AA batteries required
Product Dimensions	6 x 8 x 2 inches
Item Weight	6.5 ounces

What's in the Box

- ONN HD Camcorder (Model ONA17CA010)
- USB Cable
- Video Editing Software

Note: SD Memory Card and AA batteries are sold separately.

Warranty and Support

This ONN product is covered by a limited manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical support, product inquiries, or warranty claims, please contact ONN customer service through the contact information provided on the product packaging or the official ONN website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question