Tefal P4620769

Tefal ClipsoMinut Easy 6.0L Pressure Cooker

Model: P4620769

User Manual

Introduction

Welcome to the user manual for your new Tefal ClipsoMinut Easy 6.0L Pressure Cooker. This appliance is designed to make your cooking faster and more efficient, preserving nutrients and flavors. Please read this manual carefully before first use to ensure safe and optimal performance. Keep this manual for future reference.



Image: The Tefal ClipsoMinut Easy 6.0L Pressure Cooker, showcasing its sleek design and compact form factor. The main unit is silver with red accents on the handles and lid mechanism.

Important Safety Information

Always follow basic safety precautions when using electrical appliances, especially pressure cookers. Failure to do so may result in injury or damage to the product.

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- Close supervision is necessary when the pressure cooker is used near children.
- Do not place the pressure cooker on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving a pressure cooker containing hot liquids.
- Do not use the pressure cooker for purposes other than its intended use.
- This appliance cooks under pressure. Improper use may result in scalding injury. Make certain unit is properly closed before operating.
- Never force open the pressure cooker. Do not open until the unit has cooled and internal pressure has been released.
- Do not fill the unit over 2/3 full. When cooking foods that expand during cooking, such as rice or dried vegetables, do not fill

the unit over 1/2 full.

- Ensure the pressure release valve is clear before each use.

Product Components

Your Tefal ClipsoMinut Easy Pressure Cooker comes with several key components designed for efficient and safe cooking.

- **Main Pot:** The primary cooking vessel, made of durable aluminum and stainless steel.
- **Lid:** Features the unique ClipsoMinut easy opening/closing system, pressure valve, and safety mechanisms.
- **Operating Valve:** Controls pressure release and cooking settings.
- **Safety Valve:** An additional safety feature to release excess pressure.
- **Gasket:** A silicone seal located inside the lid to ensure an airtight seal during pressure cooking.
- **Steamer Basket (Optional/Included):** A perforated basket for steaming vegetables, fish, and other foods.



Image: The Tefal ClipsoMinut Easy Pressure Cooker shown alongside its included steamer basket, highlighting the versatility for various cooking methods.

Setup and First Use

Before using your pressure cooker for the first time, follow these steps:

1. **Unpack:** Carefully remove all packaging materials and inspect the pressure cooker for any damage.
2. **Wash Components:** Wash the pot, lid (without immersing the valve mechanism), gasket, and steamer basket with warm soapy water. Rinse thoroughly and dry.
3. **Gasket Placement:** Ensure the gasket is correctly seated in the lid's groove.

4. **Test Run (Optional but Recommended):** For your first use, perform a test run with water only.
    - Add 2-3 cups of water to the pot.
    - Close the lid securely (refer to "Closing the Lid" section).
    - Place on a stovetop over medium-high heat.
    - Once pressure is reached (steam escapes from the valve), reduce heat and let it cook for 5 minutes.
    - Release pressure (refer to "Releasing Pressure" section) and open the lid.

Operating Instructions

1. Filling the Pot

- Always add at least 250ml (1 cup) of liquid to the pot for pressure to build.
- Do not fill the pot more than 2/3 full with food and liquid.
- For foods that expand (e.g., rice, beans, dried vegetables), do not fill more than 1/2 full.

2. Closing the Lid

The ClipsoMinut Easy features a simple one-hand opening and closing system.

1. Place the lid on the pot, aligning the lid's handle with the pot's handle.
2. Press down on the central button/lever on the lid and rotate the handle until it clicks into place. Ensure the lid is securely locked.



Image: A diagram illustrating the one-hand opening and closing mechanism of the ClipsoMinut Easy lid, showing how the handle rotates to lock securely.

3. Cooking Under Pressure

1. Place the closed pressure cooker on a suitable heat source (gas, electric, induction).
2. Set the operating valve to the desired pressure setting (if applicable, refer to your recipe).
3. Heat on high until steam begins to escape steadily from the operating valve. This indicates pressure has been reached.
4. Reduce heat to maintain a steady, gentle release of steam. Start timing your recipe from this point.

4. Releasing Pressure

There are generally three methods to release pressure:

- **Natural Release:** Remove the pressure cooker from heat and allow it to cool down naturally. Pressure will gradually decrease. This method is ideal for foods that benefit from continued cooking, like stews and roasts.
- **Quick Release:** Carefully turn the operating valve to the steam release position. Steam will escape rapidly. Use caution to avoid scalding from hot steam. This method is suitable for delicate foods like vegetables.

- **Cold Water Release (for emergencies or specific recipes):** Place the pressure cooker under cold running water, avoiding the lid's valve mechanism, until pressure is released. Only use this method if specified by a recipe and with extreme care.

5. Opening the Lid

Only open the lid once all pressure has been released. The safety indicator will drop, and the lid will unlock easily.

1. Ensure the pressure indicator has dropped completely.
2. Press the central button/lever and rotate the handle to unlock the lid.
3. Lift the lid away from you to allow any remaining steam to escape safely.

Maintenance and Cleaning

Proper maintenance ensures the longevity and safe operation of your pressure cooker.

- **After Each Use:**
  - Wash the pot and steamer basket with warm soapy water. They are often dishwasher safe, but hand washing is recommended for longevity.
  - Remove the gasket from the lid and wash it separately. Ensure it is clean and flexible.
  - Wipe the lid with a damp cloth, paying attention to the valve area. Do not immerse the lid in water to protect the valve mechanism.
  - Ensure all parts are completely dry before reassembling or storing.
- **Gasket Care:** The gasket is crucial for sealing. Inspect it regularly for cracks, hardening, or damage. Replace it if necessary (Tefal recommends replacing gaskets every 1-2 years depending on usage).
- **Valve Cleaning:** Periodically check the operating valve and safety valve for food debris. Refer to the manual for specific instructions on disassembling and cleaning these components if needed.
- **Storage:** Store the pressure cooker with the lid inverted or slightly ajar to prevent the gasket from compressing and losing its elasticity.

Troubleshooting

Here are some common issues and their solutions:

Problem	Possible Cause	Solution
Pressure not building	Lid not properly sealed; Insufficient liquid; Gasket damaged or misplaced; Valve blocked.	Ensure lid is locked correctly; Add more liquid; Check and reposition/replace gasket; Clean valves.
Steam leaking from lid edge	Gasket dirty, damaged, or improperly seated; Lid not closed correctly.	Clean or replace gasket; Re-close lid, ensuring it clicks into place.
Lid cannot be opened after cooking	Pressure still inside the cooker.	Ensure all pressure is released (safety indicator dropped) before attempting to open. Do not force.
Food is undercooked	Insufficient cooking time; Heat too low; Pressure not maintained.	Increase cooking time; Ensure proper heat setting; Verify pressure is maintained during cooking.

Specifications

Detailed technical specifications for your Tefal ClipsoMinut Easy Pressure Cooker.

Feature	Detail
Brand	Tefal
Model	P4620769
Capacity	6 Liters
Color	Ruby Red
Material	Aluminum, Stainless Steel
Product Dimensions (L x W x H)	25 x 37 x 22 cm
Product Weight	2.3 Kilograms
Voltage	100 Volts (AC)
ASIN	B074M6Y5BY
EAN	3045380012639



Image: An illustration showing the available sizes (4.5L and 6L) of the ClipsoMinut Easy pressure cooker in Ruby Red, indicating options for different household needs.



Image: An illustration showing the available sizes (4.5L and 6L) of the ClipsoMinut Easy pressure cooker in Sax Blue, demonstrating color variations.

Warranty and Support

Tefal stands behind the quality of its products. Your ClipsoMinut Easy Pressure Cooker comes with a manufacturer's warranty.



Image: A graphic indicating a 10-year warranty, signifying long-term product support and reliability from Tefal.

For detailed warranty terms and conditions, please refer to the warranty card included with your product or visit the official Tefal website. The 10-year warranty typically covers the stainless steel pot against manufacturing defects, excluding consumable parts like gaskets and valves.

For customer support, spare parts, or service inquiries, please contact Tefal customer service through their official website or the contact information provided in your product packaging. Always have your model number (P4620769) and purchase date ready when contacting support.

Additionally, a recipe book is often included with the product to help you get started with various pressure cooking recipes.



Image: A visual representation of a recipe book, indicating that it is included with the pressure cooker to provide culinary inspiration and guidance.

© 2024 Tefal. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question