Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TASCO 119271C

Tasco 8 MP Megapixel Tan Game Trail Camera Low Glow

Model: 119271C | Brand: TASCO

Introduction

The Tasco 8MP Low Glow Trail Camera is designed for capturing high-quality images and videos of wildlife. Its robust features make it suitable for both novice and experienced users, providing reliable performance in various outdoor conditions. This manual provides essential information for setting up, operating, and maintaining your trail camera.

Product Features

- **8MP Camera & 720P Video:** Captures detailed images and videos while maintaining smaller file sizes for efficient storage.
- **Fast Trigger Speed:** Features a 1-second trigger speed and 5-second recovery time, ensuring multiple captures of moving subjects.
- **Extended Battery Life:** Offers up to 6 months of battery life, ideal for long-term deployment in the field or for security monitoring. (Requires 8 AA batteries, not included).
- **Ample Storage Support:** Compatible with SD cards up to 32GB (not included).
- **50-Foot Flash Range:** Provides clear illumination for nighttime captures.

Package Contents

Verify that all items are present in your package:

- Tasco 8 MP Trail Camera (Model: 119271C)
- Mounting Strap
- Instruction Manual



Figure 1: Tasco 8MP Trail Camera with manual and strap.

Setup

1. Battery Installation

The camera requires 8 AA batteries (not included). Ensure correct polarity when inserting the batteries into the

compartment. The battery compartment is located on the back of the camera when opened.



Figure 2: Opened camera view with battery compartment.

2. SD Card Installation

Insert an SD card (up to 32GB, not included) into the designated slot. Ensure the card is inserted correctly until it clicks into place. The SD card slot is typically located near the controls when the camera is opened.

3. Mounting the Camera

Use the provided mounting strap to secure the camera to a tree or post. Position the camera at an appropriate height to capture the desired area. Ensure the camera is stable and not prone to movement from wind or animals.



Figure 3: Front view of the camera.



Figure 4: Back view of the camera showing strap attachment points.

Operating the Camera

The Tasco 8MP Trail Camera offers both photo and video capture modes. Refer to the detailed instructions in the included manual for specific settings adjustments, such as trigger speed, recovery time, and video length.

- **Photo Mode:** Captures 8-megapixel still images.
- **Video Mode:** Records 720P high-definition video.
- **Trigger Speed:** The camera activates in 1 second when motion is detected.
- **Recovery Time:** A 5-second recovery time between captures ensures you don't miss subsequent events.
- **Flash Range:** The low glow flash has a range of up to 50 feet for clear night images.

Maintenance

- **Battery Replacement:** Replace the 8 AA batteries when the battery indicator shows low power or after approximately 6 months of use, depending on activity.
- **SD Card Management:** Regularly check the SD card capacity and transfer captured media to prevent the card from becoming full. Format the SD card periodically for optimal performance.
- **Cleaning:** Keep the camera lens and infrared sensors clean and free from dirt or debris. Use a soft, dry cloth for cleaning.
- **Weather Protection:** The camera has an IP65 rating, indicating it is protected against dust and low-pressure water jets. While durable, avoid submerging the camera in water.

Troubleshooting

If you encounter issues with your Tasco Trail Camera, consider the following common solutions:

- **Camera Not Triggering:**
  - Check battery levels and replace if necessary.
  - Ensure the camera is in the correct operating mode (Photo or Video).
  - Verify that the motion sensor is not obstructed.

- Adjust the camera's position to optimize motion detection.

- **Poor Image/Video Quality:**
  - Clean the camera lens and infrared sensors.
  - Ensure sufficient lighting for daytime captures.
  - Verify the flash range is adequate for nighttime subjects.

- **SD Card Errors:**
  - Ensure the SD card is properly inserted.
  - Try formatting the SD card (this will erase all data).
  - Test with a different, compatible SD card.

Specifications

Feature	Detail
Brand	TASCO
Model Number	119271C
Effective Still Resolution	8 MP
Video Capture Resolution	720p
Flash Range	50 feet
Trigger Speed	1 second
Recovery Time	5 seconds
Battery Life	6 months (approx.)
Power Source	8 AA Batteries (not included)
Flash Memory Type	SD (up to 32GB)
International Protection Rating	IP65
Item Weight	0.63 Pounds
Item Dimensions (L x W x H)	2.99 x 4.02 x 7.01 inches

Warranty and Support

Specific warranty information for the Tasco 8 MP Megapixel Tan Game Trail Camera Low Glow (Model: 119271C) is not provided in the available product data. Please refer to the manufacturer's official website or the product packaging for detailed warranty terms and customer support contact information.

© 2024 TASCO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B074RY4TPN

More documents and user manuals: **https://manuals.plus/**