TCL RC280

TCL Roku TV Remote Control User Manual

Model: RC280

Introduction

This manual provides instructions for the OEM TCL Roku TV Remote Control, model RC280. This remote is designed for use with compatible TCL Roku LED HDTVs, offering direct access to popular streaming services like Amazon, Netflix, HBO, and Sling.

Product Overview



Figure 1: Front View of Remote Control
This image displays the front of the remote, highlighting the power button, directional pad with OK button, rewind, play/pause, fast forward buttons, and dedicated quick-access buttons for Netflix, Amazon, HBO, and Sling.



Figure 2: Back View of Remote Control
This image shows the back of the remote control, illustrating its ergonomic shape and smooth finish.

Setup

The TCL Roku TV Remote Control is designed for immediate use with compatible TCL Roku TVs and typically requires no programming. Simply insert batteries to begin operation.

Inserting Batteries

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align with the indicators inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

Note: *Always use fresh batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.*

Operating Instructions

This remote control provides intuitive navigation and control over your TCL Roku TV. Point the remote directly at the TV's infrared sensor for optimal performance.

Key Functions

Button	Function
Power (Red)	Turns the TV on or off.
Back Arrow	Returns to the previous screen or menu.
Home (House Icon)	Navigates to the Roku Home screen.
Directional Pad (Purple)	Navigates through menus and content (Up, Down, Left, Right).
OK (Purple)	Selects an item or confirms an action.
Rewind (Double Left Arrow)	Rewinds video playback.
Play/Pause (Vertical Bars/Triangle)	Plays or pauses video playback.
Fast Forward (Double Right Arrow)	Fast forwards video playback.
Replay (Curved Arrow)	Replays the last few seconds of video.
Asterisk (*)	Accesses options or settings within an app or menu.
Netflix, Amazon, HBO, Sling (Dedicated Buttons)	Launches the respective streaming application directly.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Cleaning:** Use a soft, dry cloth to wipe the remote control. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter issues with your remote control, try the following troubleshooting steps:

Problem	Solution
Remote is not responding.	• Check if the batteries are inserted correctly with the correct polarity. • Replace the batteries with fresh ones. • Ensure there are no obstructions between the remote and the TV's infrared sensor. • Point the remote directly at the TV.
Buttons are sticky or unresponsive.	• Clean the remote control surface and around the buttons with a soft, slightly damp cloth. • Avoid spilling liquids on the remote.
Remote works intermittently.	• This often indicates low battery power; replace the batteries. • Ensure you are within the effective range of the TV's IR sensor.

Specifications

- **Model:** RC280 (Item Model Number: 4330952172)
- **Brand:** TCL
- **Compatible Devices:** TCL Roku LED HDTVs
- **Power Source:** 2 x AAA Batteries (not included)
- **Dimensions:** 8 x 2 x 0.5 inches (approximately)
- **Weight:** 1.72 ounces (approximately, without batteries)
- **Special Feature:** No Programming Required

Important Safety Information

- Do not expose the remote control to direct sunlight, heat sources, or excessive moisture.
- Do not attempt to disassemble or modify the remote control.
- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.
- Dispose of used batteries according to local regulations.

© 2024 TCL. All rights reserved.
For further assistance, please refer to your TCL Roku TV's main user manual or visit the official TCL support website.