EUREKA ERGONOMIC ERK-CV-46B

EUREKA ERGONOMIC 46 Inch Standing Desk (Model ERK-CV-46B) User Manual

Model: ERK-CV-46B

1. Product Overview

The EUREKA ERGONOMIC 46 Inch Standing Desk is a sit-stand desktop converter designed to enhance your workspace ergonomics. This unit allows for seamless transitions between sitting and standing positions, promoting a healthier work environment. It features a spacious 46-inch desktop and an extra-large keyboard tray, accommodating various setups including dual monitors.

- **Spacious Design:** 46-inch desktop with an extra-large keyboard tray, tablet/cell phone groove, and Steel Guard protection.
- **Stability and Durability:** Equipped with patented gas springs tested for over 100,000 cycles, ensuring stability and durability. Supports up to 35 pounds.
- **Effortless Adjustment:** Patented lifting and locking mechanism allows for smooth and quiet height adjustments without cranking or clicking.
- **Continuous Height Settings:** Provides continuous height adjustments for optimal ergonomic positioning.



Figure 1.1: Front view of the EUREKA ERGONOMIC 46 Inch Standing Desk, showcasing its design with two monitors, a keyboard, and a tablet.

2. Setup Instructions

The EUREKA ERGONOMIC 46 Inch Standing Desk requires no assembly. It is designed for immediate use upon unboxing.

1. **Unpack the Unit:** Carefully remove the standing desk from its packaging.
2. **Place on Existing Desk:** Position the standing desk on a stable, flat desk surface that is at least 23-5/8 inches deep. Ensure the existing desk can support the weight of the standing desk (approximately 68.3 lbs) plus any equipment placed on it (up to 35 lbs).
3. **Arrange Equipment:** Place your monitors, keyboard, mouse, and other accessories on the designated surfaces of the standing desk.
4. **Cable Management:** Route cables neatly to prevent interference with the desk's movement.



Figure 2.1: Top-down view illustrating the ample space for a monitor, laptop, keyboard, and mouse on the standing desk.

3. Operating Instructions

The standing desk features a gas spring lifting system for smooth and quiet height adjustments.

1. **Adjusting Height:** Locate the adjustment levers, typically on the sides of the desktop. Squeeze the levers to release the locking mechanism.
2. **Raising the Desk:** While holding the levers, gently lift the desktop to your desired standing height. The gas springs will assist in the upward movement. Release the levers to lock the desk in place.
3. **Lowering the Desk:** While holding the levers, gently press down on the desktop to lower it to your desired sitting height. Release the levers to lock the desk in place.
4. **Finding Your Ergonomic Fit:** Experiment with different heights to find the most comfortable and ergonomic position for both sitting and standing. Your elbows should form approximately a 90-degree angle when typing.



Figure 3.1: A user demonstrating the standing position with the EUREKA ERGONOMIC desk, highlighting ergonomic use.



Figure 3.2: Visual comparison of the EUREKA ERGONOMIC desk's smooth, continuous height adjustment mechanism versus stepped adjustments found in other models.

4. Maintenance

Regular maintenance ensures the longevity and optimal performance of your standing desk.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Inspection:** Periodically check all moving parts and connections for any signs of wear or looseness.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 35 lbs on the desktop and 5 lbs on the keyboard tray to prevent damage and ensure safe operation.

5. Troubleshooting

If you encounter issues with your standing desk, refer to the following common solutions:

Problem	Possible Cause	Solution
Difficulty lifting or lowering the desk.	Excessive weight on the desktop.	Reduce the load on the desk. Ensure total weight does not exceed 35 lbs.
Desk feels unstable or wobbly.	Uneven surface or loose components.	Ensure the base desk is level. Check all connections for tightness.
Levers are stuck or not engaging.	Obstruction or mechanism issue.	Inspect for any obstructions around the levers. If the issue persists, contact customer support.

6. Specifications

Detailed specifications for the EUREKA ERGONOMIC 46 Inch Standing Desk (Model ERK-CV-46B).

Brand: EUREKA ERGONOMIC

Model Number: ERK-CV-46B

Product Dimensions (D x W x H): 23.88" x 46" x 5.5" (60cm x 116.8cm x 14cm)

Item Dimensions (Overall): 46 x 24 x 6 inches

Adjustable Height Range: 5.5" to 20" (14cm to 50.8cm) above existing desk

Maximum Desktop Load Capacity: 35 lbs (15.88 kg)

Maximum Keyboard Tray Load Capacity: 5 lbs

Item Weight: 68.3 lbs

Material Type: Wood (Desktop), Alloy Steel (Base)

Color: Black & Blue

Assembly Required: No



Figure 6.1: Detailed diagram showing the dimensions of the EUREKA ERGONOMIC 46 Inch Standing Desk, including width, depth, and height adjustment range.




Figure 6.2: Diagram illustrating the weight capacities for the desktop (up to 30 lbs) and keyboard tray (up to 5 lbs), along with key dimensions. Note: The total load capacity is 35 lbs.

7. Warranty and Support

For warranty information or technical support, please refer to the official EUREKA ERGONOMIC website or contact their customer service directly.

- **Customer Support:** For assistance with product issues, setup, or general inquiries, please visit theEUREKA ERGONOMIC Store on Amazon or their official website.
- **Warranty Details:** Specific warranty terms and conditions may vary. Please consult the product packaging or the manufacturer's official resources for detailed warranty information.

© 2026 EUREKA ERGONOMIC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question