Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

UpStart Components ALB-6912W1Z004B-2PK-DL173

UpStart Components Replacement Light Bulb Instruction Manual

Model: ALB-6912W1Z004B-2PK-DL173

Compatible with LG LMV2031ST Microwave and LG 6912W1Z004B Light Bulb

1. Introduction

Thank you for choosing the UpStart Components Replacement Light Bulb. This manual provides essential information for the safe and effective installation and use of your new light bulbs. Please read these instructions carefully before proceeding with installation.

2. Safety Information

- **Disconnect Power:** Always disconnect power to the microwave oven at the circuit breaker before attempting any installation or maintenance. Failure to do so may result in electric shock or injury.
- **Handle with Care:** Light bulbs can be fragile. Handle them gently to avoid breakage.
- **Avoid Skin Oils:** It is recommended to handle the glass part of the bulb with a clean cloth or gloves to prevent oils from your skin from affecting its lifespan.
- **Cool Down:** If replacing a recently used bulb, allow it to cool completely before touching to prevent burns.
- **Correct Specifications:** Ensure the replacement bulb matches the voltage and wattage requirements of your appliance. Using an incorrect bulb can cause damage or create a fire hazard.

3. Product Specifications

The UpStart Components Replacement Light Bulb is designed to provide reliable illumination for your microwave oven. Key specifications are as follows:

- **Quantity:** 2 bulbs per pack
- **Replaces:** LG 6912W1Z004B Light Bulb, compatible with LG LMV2031ST Microwave
- **Light Type:** Incandescent
- **Wattage:** 30 watts

- **Voltage:** 125 Volts
- **Bulb Shape Size:** E17 (T25*65mm)
- **Bulb Base:** E17 (Intermediate Screw Base)
- **Special Feature:** Long Lasting
- **Brightness:** 450 lumen
- **Material:** Glass
- **Product Dimensions:** 1 x 2.2 x 2.75 inches

Image: Two clear glass light bulbs with brass screw bases, designed for microwave oven illumination.

Image: A single replacement light bulb, shown at an angle, highlighting its clear glass and brass screw base.

Image: A detailed close-up of the light bulb's E17 screw base, showing the electrical contact point.

4. Installation Guide

Follow these steps to safely replace the light bulb in your microwave oven:

1. **Ensure Safety:** Before beginning, ensure the microwave oven is completely disconnected from its power source by unplugging it or turning off the corresponding circuit breaker.
2. **Locate Bulb Access:** The light bulb(s) for illuminating the cooking surface below the microwave are typically located on the underside of the appliance. Identify the light bulb cover.
3. **Remove Bulb Cover:** Depending on your specific microwave model, the bulb cover may be secured by one or more screws or by a latching mechanism. Use an appropriate screwdriver to remove any screws, or gently unlatch the cover. Carefully remove the cover and set it aside in a safe place.
4. **Remove Old Bulb:** Gently unscrew the old bulb counter-clockwise from its socket. If the bulb was recently in use, it may be hot; allow it to cool down before handling.
5. **Install New Bulb:** Take one of the new UpStart Components E17 replacement bulbs. Holding it with a clean cloth or gloves, carefully screw it clockwise into the socket until it is snug. Do not overtighten, as this can damage the bulb or the socket.
6. **Replace Bulb Cover:** Once the new bulb is securely in place, reattach the light bulb cover. Ensure it is properly aligned and secure it with any screws or latches that were removed.
7. **Restore Power:** Restore power to the microwave oven by plugging it back in or turning on the circuit breaker.
8. **Test Functionality:** Turn on the microwave light to confirm that the new bulb is working correctly.

5. Operation

Once installed, the replacement light bulb operates in conjunction with your microwave oven's existing lighting controls. Refer to your microwave oven's user manual for specific instructions on how to turn the light on/off or adjust brightness settings (if applicable).

6. Maintenance

- **Cleaning:** Periodically clean the light bulb cover with a soft, damp cloth to ensure maximum light output. Ensure the microwave is unplugged before cleaning.
- **Handling:** As mentioned in the safety section, avoid touching the glass part of the bulb directly with bare hands during installation or replacement to prevent oils from shortening its lifespan.

7. Troubleshooting

If the light bulb does not function after installation, consider the following:

- **No Power:** Double-check that the microwave oven is properly plugged in and that the circuit breaker has been reset.
- **Improper Installation:** Ensure the bulb is screwed in completely and securely into the socket. Gently unscrew and re-screw the bulb to confirm proper contact.
- **Incorrect Bulb:** Verify that the installed bulb matches the voltage and wattage specifications required by your microwave oven.
- **Damaged Bulb:** Although rare, a new bulb could be faulty. If you have another bulb, try installing it to rule out a defective bulb.
- **Appliance Issue:** If all else fails, there might be an issue with the microwave oven's socket or wiring. In such cases, it is recommended to consult a qualified appliance technician.

8. Warranty and Support

Any warranties for this product are offered solely by UpStart Components. For specific warranty details, claims, or product support, please refer to the contact information provided with your purchase or visit the official UpStart Components website.

© 2023 UpStart Components. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B075B35WWQ

More documents and user manuals: **https://manuals.plus/**