Nokia TA-1036-A

Nokia 3310 TA-1036 User Manual

Model: TA-1036-A | Brand: Nokia

1. Introduction

The Nokia 3310 TA-1036 is a modern reimagining of a classic mobile phone, designed for essential communication with enhanced features. It combines a durable build with a long-lasting battery and a user-friendly interface. This manual provides comprehensive instructions for setting up, operating, and maintaining your device to ensure optimal performance.



Figure 1.1: Front view of the Nokia 3310 TA-1036, highlighting its display and classic keypad.

2. What's in the Box

Your Nokia 3310 TA-1036 package should contain the following items:

- Nokia 3310 TA-1036 Device
- Nokia MicroUSB Charger
- Charging/Data Cable
- Quick Start Guide

3. Setup

3.1 Inserting the SIM Card and Memory Card

To begin using your phone, you need to insert a SIM card. You can also insert a microSD card for additional storage.

1. Turn off the phone and disconnect any charger.
2. Carefully remove the back cover by prying it open from the notch at the bottom.
3. If the battery is in, lift it out.

4. Slide the SIM card into the SIM card slot with the gold contacts facing down. Ensure it clicks into place.
5. If using a memory card, slide the microSD card into the memory card slot.
6. Insert the battery, aligning the contacts.
7. Replace the back cover by pressing it firmly until it locks into place.



Figure 3.1: Back view of the Nokia 3310 TA-1036, illustrating the camera and removable back cover for SIM/battery access.

3.2 Charging the Battery

Your phone comes with a rechargeable battery. Before first use, it is recommended to fully charge the battery.

- Connect the MicroUSB end of the charging cable to the phone's charging port.
- Connect the other end of the cable to the Nokia MicroUSB Charger and plug it into a wall outlet.
- The battery indicator on the screen will show charging progress. A full charge takes approximately 3 hours.
- Once fully charged, disconnect the charger from the phone and the outlet.

4. Operating Instructions

4.1 Power On/Off

- To power on, press and hold the power key (usually the red end call button) until the Nokia logo appears.

- To power off, press and hold the power key until the power off options appear, then select "Power off".

4.2 Basic Navigation

Use the navigation keys (up, down, left, right) and the center select key to move through menus and make selections. The left and right soft keys perform actions displayed on the screen above them.

4.3 Making Calls

- From the home screen, dial the phone number using the keypad.
- Press the green call key to initiate the call.
- To end a call, press the red end call key.
- To answer an incoming call, press the green call key.

4.4 Sending Messages

- Go to the Messaging application from the main menu.
- Select "New message" or "Create message".
- Enter the recipient's number or select from contacts.
- Type your message using the alphanumeric keypad. The phone supports predictive text (T9) for faster typing.
- Press "Send" to deliver the message.

Your browser does not support the video tag.

Video 4.1: An overview of the Nokia 3310's features, including calling, texting, and the classic Snake game. This video demonstrates the phone's user interface and key functionalities.

4.5 Camera Functionality

The Nokia 3310 TA-1036 features a 2.0-megapixel camera for capturing basic photos.

- From the main menu, select the Camera application.
- Frame your shot using the screen as a viewfinder.
- Press the center select key to take a photo.
- Photos are saved to the phone's memory or the inserted memory card.

4.6 Classic Snake Game

Enjoy the pre-installed classic Snake game.

- Navigate to the Games folder in the main menu.
- Select "Snake" to start the game.
- Use the navigation keys to control the snake and collect items.

4.7 FM Radio

The phone includes an FM radio for listening to your favorite stations.

- Access the FM Radio application from the main menu.
- Scan for available stations and select your desired frequency.

4.8 Bluetooth Connectivity

Connect your phone to other Bluetooth-enabled devices like headsets or car kits.

- Go to Menu > Settings > Connectivity > Bluetooth.
- Turn Bluetooth on.
- Select "Paired devices" or "Search for devices" to find and connect to other devices.

5. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the phone's surface. Avoid liquid cleaners.
- **Battery Care:** To prolong battery life, avoid exposing the phone to extreme temperatures. Do not leave the battery fully discharged for extended periods.
- **Software Updates:** Periodically check for software updates through the phone's settings menu to ensure optimal performance and security.
- **Storage:** Regularly clear unnecessary files and applications to maintain sufficient storage space.

6. Troubleshooting

Problem	Solution
Phone does not turn on	Ensure the battery is charged. Press and hold the power key for several seconds. If the issue persists, remove and reinsert the battery.
Poor signal reception	Move to an area with better network coverage. Check if the SIM card is properly inserted.
Battery drains quickly	Reduce screen brightness. Close unused applications. Limit background data usage. Ensure the battery is not old or damaged.
Unable to send/receive messages	Check network signal. Verify message center number in settings. Ensure sufficient credit/plan.
Phone freezes or becomes unresponsive	Remove and reinsert the battery to perform a soft reset. If the problem continues, consider a factory reset (back up data first).

7. Specifications

Feature	Detail
Model Number	TA-1036-A
Dimensions	4.61 x 2.06 x 0.53 inches
Weight	8 ounces
Display	2.4 Inches, 240 x 320 pixels LCD
Battery Capacity	1200 mAh (1 Lithium Ion battery included)
Talk Time	Up to 6.5 Hours
Standby Time	Up to 27 Days
Charging Time	Approximately 3 Hours
Camera	2.0 Megapixels
Connectivity	3G Cellular, Bluetooth 2.1, MicroUSB 2.0
Operating System	Feature phone OS (often mislabeled as "Android" in some listings for basic functionality)
Memory Storage Capacity	32 MB internal, expandable via microSD (up to 32GB)
Human Interface Input	Keypad

Feature	Detail
Audio Jack	No headphone jack

8. Warranty and Support

For warranty information and detailed support, please refer to the official Nokia website or contact Nokia customer service. You can also find additional resources and a downloadable PDF user manual at Nokia 3310 User Manual (PDF).

© 2023 Nokia. All rights reserved. Nokia and the Nokia Logo are trademarks of Nokia Corporation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question