Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ADESSO WKB-1150CB

User Manual

Adesso WKB-1150CB Tru-Form Wireless Ergo Mini Keyboard & Mouse Combo

Model: WKB-1150CB

Introduction

The Adesso WKB-1150CB Tru-Form Wireless Ergo Mini Keyboard & Mouse Combo provides users with advanced input devices designed for ergonomic comfort and multi-functional use. This combo operates on a 2.4GHz wireless frequency, offering a range of up to 30 feet. The keyboard features a split key zone and a gently sloped design to promote natural hand, wrist, and forearm positioning, ensuring maximum comfort during extended use. Its mini-sizing design helps save desk space while maintaining ergonomic benefits. The accompanying wireless mouse is designed for comfort and includes a DPI switch for adjustable resolution (800/1200/1600) and two internet navigation buttons.



Image: Adesso WKB-1150CB Tru-Form Wireless Ergo Mini Keyboard and Vertical Mouse Combo. The image shows the black ergonomic keyboard with a split design and an integrated palm rest, alongside the black vertical ergonomic mouse.

Package Contents

- Wireless Ergonomic Mini Keyboard
- Wireless Vertical Ergonomic Mouse
- USB Receiver

- 2 x AAA Batteries (pre-installed or included)

Setup Guide

1. Installing Batteries

The keyboard and mouse require AAA batteries for operation. Locate the battery compartments on the underside of both devices. Insert the included AAA batteries, ensuring correct polarity (+/-). Close the battery covers securely.

2. Connecting the Receiver

Locate an available USB port on your computer. Insert the USB receiver into the USB port. The system will automatically detect the receiver and attempt to establish a connection with the keyboard and mouse.

3. Driver Installation (Plug & Play)

The Adesso WKB-1150CB combo is designed for plug-and-play functionality. Your operating system (Windows 2000 / XP / Vista / 7 / 8 / 10, Linux, PC) should automatically install the necessary drivers upon connecting the USB receiver. No manual driver installation is typically required.

Once the receiver is connected and drivers are installed, the keyboard and mouse should be ready for use. If the devices do not respond, ensure they are powered on and within the 30-foot wireless range of the receiver.

Operating Instructions

Keyboard Functions

- **Key Layout:** 87-key layout with an embedded numeric keypad.
- **Key Type:** Membrane switches provide a quiet and responsive typing experience with a 5 million keystroke lifecycle.
- **Indicators:** LED indicators for Caps Lock, Num Lock, and Low Battery status.
- **Multimedia Hotkeys:** Seven dedicated hotkeys for convenient control of media playback (Play/Pause, Stop, Forward, Backward) and volume (Volume Up, Volume Down, Mute).
- **Ergonomic Design:** The split key design and integrated palm rest encourage a natural hand and wrist position, reducing strain during prolonged use.

Mouse Functions

- **DPI Switch:** Adjust the cursor sensitivity with the dedicated DPI switch, cycling through 800, 1200, and 1600 DPI settings to suit your preference and task.
- **Internet Navigation Buttons:** Two side buttons provide quick access for forward and backward navigation in web browsers or file explorers.
- **Ergonomic Vertical Design:** The "hand-shake" grip of the vertical mouse helps to reduce forearm twisting and potential discomfort associated with carpal tunnel syndrome.
- **Optical Sensor:** Enhanced optical sensor ensures accurate and precise tracking on various surfaces, including marble, wood, and leather.

Key Features

- **Wireless Technology:** Operates on 2.4GHz RF wireless technology, providing a reliable connection up to 30 feet. Features 12 different channels, each with 65,536 different IDs for interference-free operation.

- **Membrane Switch:** Durable membrane switches with a 5 million keystroke lifecycle for a quiet and fast typing experience.
- **Ergonomic Contour Design:** Minimizes forearm muscle twisting and helps alleviate pains associated with carpal tunnel syndrome.
- **Split Key Design:** Encourages natural positioning of hands, wrists, and forearms for maximum comfort.
- **Integrated Palm Rest:** Keeps your wrists in the most comfortable position, reducing strain.
- **Built-in Scroll Wheel (Mouse):** Provides convenience for office applications or web browsing.
- **Compact and Portable:** Ultimate space saver and easy-to-carry on the go.
- **Ergonomic Vertical Design (Mouse):** The "hand-shake" grip helps reduce pains from carpal tunnel syndrome.
- **Enhanced Optical Sensor (Mouse):** Tracks accurately and precisely on different surfaces, such as marble, wood, and leather.
- **Adjustable DPI Switch (Mouse):** Adjustable cursor moving speed from 800, 1200 to 1600 DPI.

Specifications

Feature	Detail
Brand	ADESSO
Model Number	WKB-1150CB
Wireless Type	2.4 GHz Radio Frequency
Keyboard Key Layout	87-key with embedded numeric keypad
Keyboard Key Type	Membrane
Keyboard Dimensions	13.8″ x 9.4″ x 1.5″ (350 x 239 x 38mm)
Keyboard Weight	0.77 lbs (350g)
Mouse DPI Settings	800 / 1200 / 1600 DPI
Power Source	2 x AAA batteries (included)
Operating System Compatibility	Windows 2000 / XP / Vista / 7 / 8 / 10, Linux, PC
Color	Black
Product Dimensions (Overall)	18.1 x 9.6 x 2.55 inches
Item Weight (Overall)	4.8 ounces

Troubleshooting

- **No Response from Keyboard/Mouse:**
  - Ensure batteries are correctly installed and not depleted. Replace if necessary.
  - Verify the USB receiver is securely plugged into a working USB port on your computer.
  - Move the keyboard/mouse closer to the receiver to rule out range issues.
  - Try plugging the receiver into a different USB port.
  - Restart your computer.

- **Lagging or Intermittent Connection:**
  - Check for potential interference from other wireless devices (e.g., Wi-Fi routers, cordless phones). Try to minimize these sources or move the receiver.
  - Ensure there are no large metal objects between the devices and the receiver that could block the signal.
  - Replace batteries if they are low.
- **Mouse Cursor Jumps or is Inaccurate:**
  - Clean the optical sensor on the underside of the mouse with a soft, lint-free cloth.
  - Ensure you are using the mouse on a suitable surface. Highly reflective or transparent surfaces may cause issues. A mouse pad is recommended.
  - Adjust the DPI setting using the DPI switch on the mouse.
- **Multimedia Hotkeys Not Working:**
  - Ensure your operating system and media player software are up to date.
  - Some hotkeys may require specific software or settings within your operating system to function correctly.

Maintenance

- **Cleaning:**
  - To clean the keyboard and mouse, use a soft, slightly damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture.
  - For the keyboard, you can use compressed air to remove dust and debris from between the keys.
  - Regularly clean the mouse's optical sensor to ensure optimal tracking performance.
- **Battery Replacement:**
  - When the low battery indicator lights up or performance degrades, replace the AAA batteries in both the keyboard and mouse.
  - Dispose of used batteries according to local regulations.
- **Storage:**
  - Store the devices in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.

Warranty and Support

Adesso products are designed for reliability and performance. For information regarding warranty coverage, technical support, and frequently asked questions, please visit the official Adesso website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

Adesso Official Website: www.adesso.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B075GW5XD5

More documents and user manuals: **https://manuals.plus/**