Epson EB-X41 (V11H843040)

Epson EB-X41 Projector User Manual

Model: EB-X41 (V11H843040)

1. Introduction

This manual provides essential information for the safe and efficient operation of your Epson EB-X41 Projector. Please read it thoroughly before using the product and keep it for future reference. The Epson EB-X41 is a versatile portable projector designed for both home entertainment and professional presentations, offering bright, clear images with 3LCD technology.

2. What's in the Box

Upon unboxing your Epson EB-X41 Projector, please ensure all the following components are present:

- Epson EB-X41 Projector
- Remote control
- Carrying case
- AC power cable
- User Manual (this document)

If any items are missing or damaged, please contact your retailer or Epson customer support.

3. Product Overview

Familiarize yourself with the various parts and controls of your Epson EB-X41 Projector.



Figure 3.1: Front View. This image displays the front of the Epson EB-X41 projector, highlighting the lens, ventilation grille, and the Epson logo. The lens is centrally located, protected by a sliding cover, and the large grille on the left ensures proper airflow for cooling.



Figure 3.2: Angled Front-Right View. This perspective shows the projector from the front-right, providing a better view of its compact form factor and the side ventilation. The focus and zoom rings around the lens are visible, along with the 3LCD branding.



Figure 3.3: Top View with Control Panel. This image provides an overhead view of the projector, clearly showing the integrated control panel. Buttons for power, menu navigation, source selection, and keystone correction are visible, along with indicator lights for lamp and temperature status.



Figure 3.4: Rear View with Input Ports. The back of the projector is shown, detailing the various connectivity options. This includes ports for HDMI, VGA, USB-A, USB-B, and audio input/output, alongside the power input and an exhaust vent.



Figure 3.5: Dimensions. This image illustrates the physical dimensions of the Epson EB-X41 projector, indicating its length (30cm), width (24cm), and height (9cm). This provides a clear understanding of its compact and portable design.

4. Setup

4.1 Placement

- Place the projector on a stable, flat surface.
- Ensure adequate ventilation around the projector. Do not block air vents.
- Position the projector at an appropriate distance from the screen to achieve the desired image size.

4.2 Power Connection

1. Connect the supplied AC power cable to the projector's power inlet.
2. Plug the other end of the power cable into a grounded electrical outlet.

4.3 Connecting to Devices

The EB-X41 offers multiple connectivity options:

- **HDMI:** For high-definition video and audio. Connect an HDMI cable from your source device (e.g., laptop, Blu-ray player) to the projector's HDMI port.
- **VGA:** For computer connections. Connect a VGA cable from your computer's VGA output to the projector's VGA port.
- **USB-A:** For connecting USB storage devices or the optional Wi-Fi adapter (ELPAP10).
- **USB-B:** For connecting to a computer for display and control functions.
- **Audio In/Out:** For external audio sources or connecting to external speakers.

5. Operating Instructions

5.1 Powering On/Off

- **To Power On:** Press the power button on the projector or remote control. The power indicator light will turn blue.
- **To Power Off:** Press the power button twice. The projector will go through a cool-down cycle before shutting

down completely.

5.2 Adjusting the Image

- **Focus:** Rotate the focus ring on the lens until the image is sharp.
- **Zoom:** Adjust the zoom ring on the lens to change the image size without moving the projector.
- **Keystone Correction:** Use the keystone correction buttons on the projector or remote to correct trapezoidal distortion, ensuring a rectangular image.

5.3 Selecting Input Source

Press the "Source Search" button on the projector or the corresponding input button (e.g., HDMI, Computer) on the remote control to cycle through available input sources.

5.4 Menu Navigation

Press the "Menu" button to access the projector's on-screen display (OSD) menu. Use the arrow buttons to navigate and "Enter" to select options. Adjust settings such as image mode, color, brightness, and network settings.

6. Maintenance

6.1 Cleaning the Projector

- Wipe the exterior with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth with a mild detergent, then wipe dry.
- Do not use abrasive cleaners, waxes, or solvents.
- Clean the lens gently with a lens cleaning cloth or lens paper. Do not use liquid cleaners directly on the lens.

6.2 Lamp Replacement

The projector lamp has a finite lifespan. When the lamp indicator light turns orange or the image becomes dim, it's time to replace the lamp. Refer to the full service manual for detailed lamp replacement instructions. Always use genuine Epson replacement lamps.

6.3 Air Filter Cleaning/Replacement

Regularly clean the air filter to maintain optimal performance and prevent overheating. The air filter is typically located on the side or bottom of the projector. Clean it with a small vacuum cleaner or replace it if heavily soiled. Refer to the full service manual for location and procedure.

7. Troubleshooting

Problem	Possible Cause	Solution
No image projected	Power cable not connected Input source not selected Lens cover closed	Ensure power cable is securely connected. Select the correct input source. Open the lens cover.
Image is blurry	Focus not adjusted Projector too close/far from screen	Adjust the focus ring on the lens. Adjust projector distance or use zoom.

Problem	Possible Cause	Solution
Image is distorted (trapezoid)	Projector not perpendicular to screen	Use keystone correction.
Projector overheats and shuts down	Blocked air vents Dirty air filter	Ensure proper ventilation. Clean or replace the air filter.

For more detailed troubleshooting, please refer to the comprehensive user guide available on the Epson support website or contact customer service.

8. Specifications

Feature	Detail
Model Number	V11H843040
Projection Technology	3LCD
Native Resolution	XGA (1024x768)
Brightness	3600 ANSI lumens
Contrast Ratio	15,000:1
Lamp Life	6000 hours (Normal mode)
Lamp Type	UHE 210 W
Connectivity	HDMI, VGA, USB-A, USB-B, Audio In/Out, (Optional Wi-Fi with ELPAP10)
Dimensions (W x D x H)	30.2 x 23.7 x 8.2 cm
Weight	2.5 kg
Power Consumption	282 watts

9. Warranty and Support

Epson provides a limited warranty for the EB-X41 projector. Please refer to the warranty card included with your product for specific terms and conditions, including warranty period and coverage details. Keep your proof of purchase for warranty claims.
For technical support, product registration, or to download the latest drivers and software, please visit the official Epson support website or contact Epson customer service. Contact information can typically be found on the Epson website or in the product packaging.
Epson Support Website: https://www.epson.co.uk/support

© 2024 Epson Corporation. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question