Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JUKI A1514-535-0B0

JUKI MO-623 MO-644D Presser Foot Shank Instruction Manual

Introduction

Welcome to the instruction manual for the JUKI Presser Foot Shank, part number A1514-535-0B0. This manual provides essential information for the proper installation, operation, and maintenance of this genuine JUKI component. Please read these instructions carefully before use to ensure optimal performance and longevity of your presser foot shank.

Product Overview

The JUKI Presser Foot Shank Assembly (part number A1514-535-0B0, also known as A1514-535-0B0A) is a genuine replacement part designed for specific JUKI portable overlock machines. This component is crucial for attaching various presser feet to your sewing machine, ensuring proper fabric feeding and stitch formation.

This presser foot shank is compatible with the following JUKI portable serger models:

- JUKI MO-623
- JUKI MO-644D



Image: The JUKI Presser Foot Shank Assembly, a metal component designed for attaching presser feet to compatible JUKI sergers.

Installation Instructions

This section details the steps for correctly installing the JUKI Presser Foot Shank on your compatible serger. Ensure your machine is turned off and unplugged from the power outlet before beginning any installation or maintenance.

1. **Preparation:** Turn off and unplug your JUKI MO-623 or MO-644D serger from the power outlet.
2. **Remove Old Shank (if applicable):** If replacing an existing shank, carefully loosen the screw that secures the presser foot shank to the presser bar. Remove the old shank and any attached presser foot.
3. **Position New Shank:** Align the new JUKI Presser Foot Shank (A1514-535-0B0) with the presser bar. Ensure it is oriented correctly, with the foot attachment point facing forward.
4. **Secure Shank:** Insert the securing screw through the designated hole in the shank and tighten it firmly with a screwdriver. Do not overtighten, as this can damage the screw or the machine.
5. **Attach Presser Foot:** Once the shank is securely installed, you can attach your desired presser foot to the shank using its specific attachment mechanism.
6. **Test:** Plug in your machine and turn it on. Manually lower and raise the presser foot to ensure it moves smoothly and is securely attached. Perform a test stitch on scrap fabric before beginning your project.

Operating Instructions

The presser foot shank itself does not have operational controls. Its primary function is to securely hold the presser foot, which in turn guides the fabric and applies pressure during sewing.

Using the Presser Foot:

- **Lowering/Raising:** Use the presser foot lifter lever on your serger to raise or lower the presser foot. Ensure the foot is lowered before beginning to sew.
- **Fabric Placement:** Place your fabric under the presser foot, aligning the edge with the desired seam allowance guide.
- **Stitching:** Begin sewing, guiding the fabric smoothly. The presser foot will help maintain even pressure and feed the fabric consistently.

Maintenance

Proper maintenance of your presser foot shank ensures its longevity and optimal performance.

- **Cleaning:** Periodically inspect the presser foot shank for lint, dust, or thread buildup. Use a small brush or lint remover to clean the area around the shank and presser bar.
- **Inspection:** Check the securing screw periodically to ensure it remains tight. If the presser foot feels loose, re-tighten the screw.
- **Lubrication:** The presser foot shank typically does not require lubrication. Refer to your JUKI serger's main instruction manual for specific lubrication points on the machine itself.
- **Storage:** When not in use, ensure the machine is covered to prevent dust accumulation, which can affect all components, including the presser foot shank.

Troubleshooting

This section addresses common issues related to the presser foot shank.

Issue	Possible Cause	Solution
Presser foot is loose or wobbly.	Securing screw is loose.	Tighten the securing screw on the presser foot shank.

Issue	Possible Cause	Solution
Presser foot does not lower or raise smoothly.	Lint or debris buildup; bent presser bar.	Clean the area around the presser foot shank and presser bar. If the issue persists, consult a qualified technician.
Presser foot does not attach correctly.	Incorrect presser foot for the shank; shank not installed correctly.	Ensure you are using a compatible presser foot. Re-check the installation of the presser foot shank as per the "Installation Instructions" section.

Specifications

- **Part Number:** A1514-535-0B0 (also known as A1514-535-0B0A)
- **Brand:** JUKI
- **Material:** Metal
- **Compatibility:** JUKI MO-623, JUKI MO-644D Portable Overlock Machines
- **UPC:** 747465160701

Warranty and Support

This product is a genuine JUKI part. For specific warranty information regarding this component, please refer to the documentation provided with your original JUKI serger or contact JUKI customer support directly.

For further assistance or technical support, please visit the official JUKI website or contact an authorized JUKI service center.

JUKI Official Website

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B075HZKJJT

More documents and user manuals: **https://manuals.plus/**