Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KINYUED JYD-J014

KINYUED JYD-J014 Automatic Mechanical Wrist Watch User Manual

Model: JYD-J014

1. Introduction

Thank you for choosing the KINYUED JYD-J014 Automatic Mechanical Wrist Watch. This manual provides essential information for the proper use, care, and maintenance of your timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

This watch features an automatic mechanical movement, meaning it is powered by the motion of your wrist. It also includes a classic day and date calendar display.

2. Product Overview

The KINYUED JYD-J014 is a sophisticated automatic mechanical wrist watch designed for daily wear. It features a durable stainless steel band, a clear mineral crystal, and a multi-function dial displaying time, day, and date.



Figure 2.1: Front view of the KINYUED JYD-J014 watch, showcasing the white dial, silver stainless steel band, and visible automatic movement components.

Key components include:

- **Crown:** Used for winding the watch and setting the time and date.
- **Dial:** Displays hours, minutes, seconds, day of the week, and date.
- **Case:** Protects the internal movement.
- **Band:** Silver stainless steel bracelet for secure wearing.
- **Clasp:** Tang Buckle for securing the watch on the wrist.

3. Setup

3.1 Initial Winding

As an automatic mechanical watch, the JYD-J014 is powered by the natural motion of your wrist. However, for initial setup or if the watch has stopped due to lack of wear, manual winding is recommended.

1. Ensure the crown is in its fully pushed-in position (Position 1).
2. Rotate the crown clockwise approximately 20-30 times. This will provide sufficient power reserve to start the watch.
3. The second hand should begin to move smoothly.

3.2 Setting Time and Date

1. **Setting the Date:** Gently pull the crown out to the first click (Position 2). Rotate the crown clockwise or counter-clockwise to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this is when the date change mechanism is engaged and could be damaged. If the current time falls within this period, first set the time outside this range, then set the date, and finally reset the time.
2. **Setting the Day:** The day of the week is typically adjusted by rotating the crown in the opposite direction in Position 2, or by advancing the time past 24 hours. Refer to the specific dial markings for your model.
3. **Setting the Time:** Pull the crown out to the second click (Position 3). Rotate the crown to set the hour and minute hands. To ensure accurate time, set the minute hand a few minutes past the desired time, then turn it back to the exact time. Push the crown back into Position 1 to start the watch.
4. After setting, always push the crown back completely to Position 1 to ensure water resistance.

3.3 Adjusting the Band

The stainless steel bracelet can be adjusted by removing links. This procedure typically requires specialized tools and is best performed by a qualified watchmaker or jeweler to avoid damage to the band or clasp.

4. Operating Instructions

4.1 Automatic Movement

Your KINYUED JYD-J014 watch is equipped with an automatic mechanical movement. This means it does not require a battery. Instead, it is powered by the kinetic energy generated by the natural motion of your arm and wrist. When worn regularly (approximately 8-10 hours a day), the watch will remain wound and keep accurate time.

4.2 Power Reserve

When fully wound, the watch has a power reserve that allows it to continue running for a certain period (typically 12-36 hours) even when not being worn. If the watch is not worn for an extended period and stops, simply manually wind it as described in Section 3.1, or wear it for a few hours to restart the movement.

4.3 Water Resistance

This watch has a water resistance rating of 30 meters (3 ATM). This rating means the watch is suitable for everyday use and can withstand splashes or brief immersion in water. It is **not** suitable for swimming, showering, diving, or any prolonged water activities. Always ensure the crown is fully pushed in to maintain water resistance.

Avoid operating the crown or pushers (if any) while the watch is wet or submerged, as this can compromise the water resistance.

5. Maintenance

5.1 Cleaning

To maintain the appearance of your watch, wipe the case and crystal with a soft, dry cloth. For the stainless steel band, a slightly damp cloth can be used, followed by a dry cloth. Avoid using chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish.

5.2 Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong

magnetic fields. A watch box or pouch is ideal for protection.

5.3 Avoiding Magnetic Fields

Mechanical watches can be affected by strong magnetic fields, which can cause them to run inaccurately. Keep your watch away from devices such as speakers, refrigerators, mobile phones, and other electronic devices that generate strong magnetic fields.

5.4 Regular Servicing

Like any precision mechanical instrument, your watch benefits from periodic servicing (typically every 3-5 years) by a professional watchmaker. This includes cleaning, lubrication, and adjustment of the movement to ensure continued accuracy and performance.

6. Troubleshooting

- **Watch not running or stopping frequently:**

  This is common for automatic watches if not worn consistently. Ensure the watch is fully wound by manually rotating the crown 20-30 times (Section 3.1) or by wearing it for at least 8-10 hours daily.

- **Time is inaccurate:**

  Check if the watch has been exposed to strong magnetic fields (Section 5.3). If the inaccuracy persists after winding and avoiding magnetic fields, the watch may require professional adjustment.

- **Date or Day not changing correctly:**

  Ensure the time is not set within the "danger zone" (9 PM to 3 AM) when adjusting the date. If the issue continues, it may indicate a mechanical problem requiring professional service.

- **Condensation under the crystal:**

  This indicates a breach in water resistance. Immediately take the watch to a professional watchmaker to prevent further damage to the movement.

7. Specifications

Feature	Detail
Model Number	JYD-J014
Movement Type	Automatic, Mechanical Hand Wind
Case Material	(Not specified, assumed alloy/stainless steel based on band)
Case Diameter	1.7 inches (approx. 43mm)
Case Thickness	0.6 inches (approx. 15mm)
Band Material	Stainless Steel
Band Width	0.7 inches (approx. 18mm)
Dial Color	White
Crystal Type	Mineral

Feature	Detail
Water Resistance Depth	30 meters (3 ATM)
Clasp Type	Tang Buckle
Item Weight	4.8 ounces (approx. 136 grams)
UPC	799355735803

8. Warranty Information

KINYUED watches are manufactured to high-quality standards. This product is covered by a manufacturer's warranty against defects in materials and workmanship. The duration and terms of the warranty may vary by region and retailer. Please retain your proof of purchase for warranty claims.

The warranty typically does not cover:

- Damage resulting from improper handling, lack of care, accidents, or normal wear and tear.
- Water damage if the watch was used beyond its specified water resistance limits or if the crown was not properly secured.
- Batteries (not applicable for this mechanical watch).
- Unauthorized repairs or modifications.

For specific warranty details, please refer to the warranty card included with your purchase or contact KINYUED customer support.

9. Customer Support

If you have any questions, require assistance, or need to arrange for service, please contact KINYUED customer support. You can typically find contact information on the official KINYUED website or through the retailer where you purchased the watch.

When contacting support, please have your watch model number (JYD-J014) and proof of purchase readily available.

© 2023 KINYUED. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B075JDZV2Y

More documents and user manuals: **https://manuals.plus/**