Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hasbro E1048

Hasbro Beyblade Burst Evolution Spryzen S2 Instruction Manual

1. Introduction

Welcome to the world of Beyblade Burst Evolution! This manual provides essential information for the assembly, operation, and care of your Spryzen S2 Beyblade Burst top. Prepare for thrilling battles and strategic play.
Manufacturer Recommended Age: 8 years and up.
Safety Warning: Small parts. Not for children under 3 years. Do not lean over Beystadium when tops are in play. Do not use Beystadium on tables or other elevated surfaces. Only use BEYBLADE tops with a BEYBLADE BURST Beystadium.

2. Package Contents

Your Beyblade Burst Evolution Single Top Pack Spryzen S2 includes the following components:

- 1 Beyblade Burst right-spin top (Spryzen S2)
- Instructions

Note: A Beyblade Burst right-spin launcher and a Beyblade Burst Beystadium are required for play and are sold separately.



Image 2.1: Beyblade Burst Evolution Spryzen S2 in its original packaging, showing the top, its components, and branding.

3. Setup & Assembly

Assemble your Beyblade Burst top by combining its three core components: the Energy Layer, Forge Disc, and Performance Tip.

1. **Energy Layer (Spryzen S2):** This is the top-most part of your Beyblade, featuring the character's design.
2. **Forge Disc (D04 / Limited):** This metal disc adds weight and stability. Align the tabs on the Forge Disc with the slots on the Energy Layer and twist until it locks securely.
3. **Performance Tip (TA06 / Variable):** This is the bottom-most part that makes contact with the Beystadium. Attach the Performance Tip to the bottom of the Forge Disc by twisting until it clicks into place.

Ensure all components are securely attached before launching.





Image 3.1: An assembled Beyblade Burst Evolution Spryzen S2 top, showcasing its distinct layers and colors.

4. Operating Instructions

4.1. Launching Your Beyblade

1. Attach your assembled Beyblade Burst top to a Beyblade Burst right-spin launcher (sold separately).

2. Hold the launcher firmly over a Beyblade Burst Beystadium (sold separately).
3. Pull the ripcord to launch your Beyblade into battle.

4.2. Battling

Face off against an opponent's Beyblade Burst top in a Beyblade Burst Beystadium. The goal is to out-spin your opponent or cause their top to 'burst' into pieces.

- **Burst Finish:** If an opponent's top 'bursts' into pieces during battle, you score 2 points. (Burst rates vary).
- **Spin Finish:** If your top is still spinning in the Beystadium after your opponent's top has stopped, you score 1 point.
- **Knockout Finish:** If you knock your opponent's top out of the Beystadium, you score 1 point.

The first player to reach 3 points wins the battle.

5. Components & Compatibility

The Spryzen S2 top consists of the following specific components:

- **Energy Layer:** Spryzen S2 (also known as Storm Spryzen)
- **Forge Disc:** D04 (also known as Limited)
- **Performance Tip:** TA06 (also known as Variable)

These components are interchangeable with most Beyblade Burst tops, allowing for customization and strategic combinations. However, they are **not compatible** with Beyblade Burst Rip Fire tops.



Image 5.1: A close-up view of the Spryzen S2 Energy Layer, highlighting its intricate design and attack points.

6. Maintenance

To ensure the longevity and optimal performance of your Beyblade Burst top, follow these maintenance guidelines:

- **Cleaning:** Wipe the top with a dry, soft cloth after use to remove dust and debris. Avoid using water or harsh chemicals.
- **Storage:** Store your Beyblade top and its components in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check components for wear or damage. Replace any broken or worn parts to maintain safe and effective play.

7. Troubleshooting

If you encounter issues with your Beyblade Burst top, consider the following:

- **Top not spinning correctly:** Ensure all three components (Energy Layer, Forge Disc, Performance Tip) are securely assembled and locked into place. Check your launcher for any damage or wear.
- **Top not 'bursting':** Burst rates vary. Ensure you are using a Beyblade Burst Beystadium and a compatible launcher. The 'burst' mechanism is designed to occur under specific impact conditions.
- **Damage to components:** Discontinue use of any damaged components. Replacement parts may be available from authorized retailers.

8. Specifications

Product Dimensions	1.18 x 3.5 x 7.76 inches
Item Weight	1.06 ounces
Item Model Number	E1048
Manufacturer Recommended Age	8 years and up
Release Date	September 11, 2017
Manufacturer	Hasbro

9. App Integration

Enhance your Beyblade Burst experience by scanning the code on your Beyblade Burst top's Energy Layer. This unlocks the top within the Beyblade Burst app, allowing you to battle digitally and track your collection.
The Beyblade Burst app is available for download on compatible mobile devices.

10. Warranty & Support

For warranty information, product support, or to contact customer service, please visit the official Hasbro website or refer to the contact details provided on the product packaging.
Official Hasbro Website: Visit the Hasbro Store on Amazon

© 2026 Hasbro. All rights reserved. Beyblade Burst and all related terms are trademarks of Hasbro.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B075KH9WJT

More documents and user manuals: **https://manuals.plus/**