Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beurer HD 75 Cosy (Model 42401)

Beurer HD 75 Cosy Heated Overblanket Instruction Manual

Model: HD 75 Cosy (42401)

Introduction

This instruction manual provides important information for the safe and effective use of your Beurer HD 75 Cosy Heated Overblanket. Please read all instructions carefully before use and retain this manual for future reference.
The Beurer HD 75 Cosy Heated Overblanket is designed to provide comfortable warmth. It features six individually adjustable temperature settings, an automatic shut-off function, and is machine washable for easy maintenance. Its soft fleece material ensures a pleasant user experience.

Important Safety Information

WARNING: Failure to observe the following instructions may result in personal injury or material damage.

- Do not use the heated overblanket if it is folded, creased, or bunched up.
- Do not use for very young children (0-3 years old) or persons insensitive to heat.
- Always disconnect the power cord from the mains socket when not in use or before cleaning.
- Do not insert pins or other sharp objects into the heated overblanket.
- Keep the control unit dry and do not immerse it in water or other liquids.
- Regularly inspect the heated overblanket for signs of wear or damage. If damaged, do not use.
- This appliance is not intended for medical use in hospitals.
- Ensure the power cord is not trapped or damaged during use.

Setup and Initial Use

1. **Unpacking:** Carefully remove the heated overblanket from its packaging. Check for any signs of damage.
2. **Connecting the Control Unit:** Ensure the control unit is securely connected to the heated overblanket. The connector should click into place.
3. **Placement:** Lay the heated overblanket flat on a bed, sofa, or other suitable surface. Ensure it is not folded or creased.
4. **Power Connection:** Plug the power cord into a suitable mains socket.



Image: The Beurer HD 75 Cosy Heated Overblanket, folded, with its detachable control unit visible. The product packaging is in the background.

Operating Instructions

1. **Switching On:** Slide the ON/OFF switch on the control unit to the 'ON' position. The indicator light will illuminate.
2. **Selecting Temperature:** Use the slider switch to select one of the six temperature settings (1-6).
    - Setting 1: Minimum heat
    - Settings 2-5: Moderate heat
    - Setting 6: Maximum heat (approximately 50°C)
3. **Pre-heating:** For faster warming, select the highest temperature setting initially. The overblanket typically takes about 30 minutes to reach its full temperature.
4. **Automatic Shut-off:** The heated overblanket is equipped with an automatic shut-off function, which activates after approximately 3 hours of continuous operation. This enhances safety.
5. **Switching Off:** To turn off the overblanket, slide the ON/OFF switch to the 'OFF' position. The indicator light will extinguish. Unplug the power cord from the mains socket when not in use.



Image: A hand adjusting the slider on the control unit, showing the six temperature settings from 0 to 6.



Image: The Beurer HD 75 overblanket with an icon of a clock and text indicating safe use with automatic shut-off.

Care and Maintenance

Cleaning

1. **Preparation:** Before cleaning, always unplug the heated overblanket from the mains and detach the control unit from the blanket.
2. **Machine Washing:** The heated overblanket is machine washable at 30°C on a gentle cycle. Do not bleach, tumble dry, iron, or dry clean.
3. **Drying:** After washing, reshape the blanket to its original size and lay it flat on a clean surface to air dry. Do not use clothes pegs or hang it to dry while wet, as this may damage the internal heating elements. Ensure it is completely dry before re-use.

4. **Control Unit Cleaning:** Wipe the control unit with a slightly damp cloth. Do not immerse it in water.



Image: The Beurer HD 75 overblanket inside a washing machine, illustrating its machine washability at 30°C after detaching the control unit.

Storage

When not in use, store the heated overblanket in its original packaging or a suitable storage bag in a clean, dry place. Avoid placing heavy objects on top of it to prevent damage to the heating elements.

TROUBLESHOOTING

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Overblanket does not heat up.	Not plugged in correctly. Control unit not connected properly. Automatic shut-off activated. Internal fault/damage.	Check power plug and socket. Ensure control unit is securely attached. Switch off and on again. If it still doesn't work, let it cool down completely before trying again. Contact customer service.
Overblanket heats unevenly or too slowly.	Overblanket is folded or creased. Incorrect temperature setting.	Lay the overblanket flat and smooth. Increase the temperature setting. Allow sufficient pre-heating time.
Indicator light is not on.	Overblanket is switched off. Power supply issue.	Switch the overblanket on. Check power connection.

If the problem persists after attempting these solutions, please contact Beurer customer service.

Technical Specifications

- **Model:** HD 75 Cosy (42401)
- **Dimensions:** 180 x 130 cm
- **Material:** Soft Fleece (Polaire)
- **Power:** 100 W
- **Temperature Settings:** 6 levels
- **Automatic Shut-off:** Approximately 3 hours
- **Safety System:** Beurer Safety System (BSS)
- **Washability:** Machine washable at 30°C (detachable control unit)
- **Weight:** Approximately 1.9 kg
- **International Article Number (EAN/UPC):** 04211125424008

Warranty and Support

Beurer GmbH provides a warranty period for this product. For detailed warranty conditions and information on how to claim warranty service, please refer to the warranty card included with your product or visit the official Beurer website. For technical support, spare parts, or service inquiries, please contact your local Beurer customer service department. Contact information can typically be found on the Beurer website or in the product packaging.
Manufacturer: Beurer GmbH
Country of Origin: China

© 2023 Beurer GmbH. All rights reserved.
This manual is for informational purposes only and is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B075LG1P79

More documents and user manuals: **https://manuals.plus/**