ZdalaMit EN-22652A

ZdalaMit EN-22652A Replacement Remote Control User Manual

For Hisense LCD LED TV Models

Introduction

This document provides comprehensive instructions for the ZdalaMit EN-22652A Replacement Remote Control. This remote is designed to function as a direct replacement for original Hisense TV remotes for specific LCD LED TV models. It is important to note that this remote is **not compatible with Hisense Smart TVs**.

Compatible Hisense TV Models:

- 23A320
- 32K26
- 32K360
- 40K360
- 50K360G
- 50K362G

Setup

The ZdalaMit EN-22652A remote control requires no programming or pairing. Simply install the batteries, and it will be ready for immediate use with compatible Hisense TV models.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open.
3. Insert two (2) 1.5V AAA alkaline batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery cover by sliding it back into place until it clicks securely.



This image shows the rear of the EN-22652A remote control with the battery cover removed, illustrating the two AAA battery compartments and correct polarity markings for battery insertion.

Operating Instructions

Once batteries are installed, point the remote control directly at your Hisense TV. The remote functions are

standard for most television operations.



This image displays the front of the EN-22652A remote control, highlighting the layout of all functional buttons, including power, input selection, volume, channel, navigation, and number pad.

Key Functions:

- **Power (Red Button):** Turns the TV on or off.
- **Input/Source:** Cycles through available input sources (e.g., TV, AV, HDMI, USB, VGA, Component).
- **Number Pad (0-9):** Directly enters channel numbers.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes the television channel.
- **MUTE:** Silences or restores the TV audio.
- **MENU:** Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right, ENTER):** Used to navigate menus and confirm selections.
- **EXIT:** Exits the current menu or on-screen display.
- **DISPLAY:** Shows current channel information or other on-screen details.
- **FAV/CH:** Accesses favorite channels or channel list.
- **Picture/Sound/Aspect:** Accesses picture, sound, or aspect ratio settings directly.

Maintenance

Proper care and maintenance will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA alkaline).
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote, expose it to extreme temperatures, or immerse it in water.

Troubleshooting

If you encounter issues with your remote control, refer to the following common solutions:

Problem	Solution
Remote is not working or unresponsive.	◦ Ensure batteries are inserted correctly with the correct polarity. ◦ Replace old batteries with two new 1.5V AAA alkaline batteries. ◦ Ensure there are no obstructions between the remote and the TV's infrared sensor. ◦ Confirm the remote is pointed directly at the TV.
Remote works intermittently.	◦ Batteries may be low; replace them. ◦ Check for strong light sources (e.g., direct sunlight, fluorescent lights) that might interfere with the IR signal.

Problem	Solution
Remote does not control my TV.	◦ Verify that your Hisense TV model is listed in the 'Compatible Hisense TV Models' section of this manual. This remote is designed for specific models and does not require programming. ◦ Ensure your TV is not a 'Smart TV' model, as this remote is not compatible with them.

Specifications

- **Model:** EN-22652A
- **Brand:** ZdalaMit
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Compatible Devices:** Hisense LCD LED Televisions (specific models)
- **Dimensions:** 7 x 1.5 x 0.5 inches (approximately)
- **Item Weight:** 2.8 ounces (without batteries)
- **Color:** Black
- **Special Feature:** Ergonomic design

Support

If you have any questions or require further assistance regarding your ZdalaMit EN-22652A Replacement Remote Control, please contact the seller or manufacturer for support.