Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Oneconcept Dartmaster 180

Oneconcept Dartmaster 180 Electronic Dartboard User Manual

Model: Dartmaster 180

1. Introduction

Thank you for choosing the Oneconcept Dartmaster 180 electronic dartboard. This manual provides essential information for the safe and efficient operation of your new dartboard. Please read it thoroughly before use and retain it for future reference.
The Dartmaster 180 offers an engaging dart experience with its electronic scoring, LED display, and a wide variety of games and variants, suitable for both casual players and enthusiasts.

2. Safety Instructions

- Always use soft-tip darts with this electronic dartboard to prevent damage to the board and ensure player safety.
- Keep the dartboard away from water or other liquids to avoid electric shock.
- Ensure the power adapter is correctly connected to a suitable power outlet.
- Do not attempt to open or repair the dartboard yourself. Refer all servicing to qualified personnel.
- Keep darts out of reach of small children.
- Mount the dartboard securely to a wall to prevent it from falling during play.

3. Package Contents

Please check that all items listed below are included in your package:

- 1 x Oneconcept Dartmaster 180 Electronic Dartboard Unit
- 24 x Soft Tips
- 12 x Dart Barrels
- 12 x Dart Shafts
- 24 x Dart Flights
- 1 x Power Adapter (100-240V / 50-60 Hz)
- 1 x Set of Wall Mounting Screws and Anchors

- 1 x User Manual (English and German)

Figure 1: Included soft-tip darts, shafts, flights, and spare tips for the Oneconcept Dartmaster 180.

This image displays the various components of the dart set, including multiple soft-tip darts, spare plastic tips, and dart flights with different flag designs, indicating the accessories provided with the dartboard.

4. Setup

4.1 Wall Mounting

1. Choose a suitable location on a sturdy wall, ensuring enough space for players to throw darts safely.
2. The dartboard should be mounted at a height where the center of the bullseye is 1.73 meters (5 feet 8 inches) from the floor.
3. Mark two points on the wall, approximately 30 cm apart, where the mounting screws will be inserted.
4. Drill pilot holes, insert the wall anchors, and then screw in the mounting screws, leaving a small portion exposed for the dartboard to hang.
5. Carefully hang the dartboard unit onto the screws, ensuring it is stable and level.

Figure 2: Dartboard mounted on a wall with doors open.

This image shows the Oneconcept Dartmaster 180 electronic dartboard securely mounted on a wall. The wooden doors are open, revealing the dart target and the electronic scoring display below it. Darts are neatly stored in holders on the inside of the doors.

4.2 Dart Assembly

1. Attach the dart shafts to the dart barrels by screwing them in clockwise.
2. Insert the dart flights into the slots at the end of the shafts.
3. Screw the soft tips onto the front of the dart barrels.

4.3 Power Connection

Connect the provided power adapter to the dartboard's power input jack and then plug it into a standard electrical outlet. The dartboard will power on automatically or can be switched on using the power button.

5. Operating Instructions

5.1 Control Panel Overview

The dartboard features a control panel with 9 buttons and LED displays for scoring and game information.

Figure 3: Dartboard with control panel and LED display.

This image provides a clear view of the Oneconcept Dartmaster 180 electronic dartboard with its wooden doors open. The central dart target is visible, along with the electronic control panel located below it, featuring various buttons and LED displays for score tracking and game selection.

5.2 Basic Operation

- **Power On/Off:** Use the dedicated power switch on the front of the unit.
- **Game Selection:** Press the "Game" button to cycle through the available 27 games.
- **Variant Selection:** For games with multiple variants, use the "Variant" button to choose your preferred option (up to 150 variants).
- **Player Selection:** Use the "Player" button to select the number of players (up to 8).
- **Start/Pause:** Press "Start" to begin a game or pause it.
- **Score Display:** LED displays show scores for 1-4 players or 5-8 players, along with current player, remaining throws, and points.
- **Virtual Opponent:** If playing solo, activate the virtual opponent with 5 difficulty levels.
- **Handicap Function:** Adjust the difficulty level for individual players using the handicap function.

6. Games and Modes

The Dartmaster 180 offers a comprehensive selection of 27 games with 150 variants to keep your dart sessions exciting. Popular games include:

- Count Down 301 (and other X01 games)
- Cricket
- Shanghai
- And many more.

Refer to the detailed game explanations in the included user manual (English/German) for specific rules and gameplay instructions for each mode.

7. Maintenance

7.1 Cleaning

Wipe the dartboard and its cabinet with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these may damage the surfaces.

7.2 Dart Care

Regularly check the soft tips of your darts for wear and tear. Replace damaged or broken tips with new ones to ensure proper function and prevent damage to the dartboard segments.

7.3 Storage

When not in use, close the wooden doors of the dartboard to protect the target from dust and potential damage. The doors also feature integrated dart holders for convenient storage.

Figure 4: Dartboard with doors closed.

This image shows the Oneconcept Dartmaster 180 electronic dartboard with its wooden cabinet doors closed. The closed doors provide protection for the dart target and contribute to a neat appearance when the dartboard is not in use.

8. Troubleshooting

- **No Power:**
  - Ensure the power adapter is securely plugged into both the dartboard and the wall outlet.
  - Check if the wall outlet is functioning correctly by plugging in another device.
  - Verify the power switch on the dartboard is in the "On" position.
- **Darts Not Registering:**
  - Ensure you are using soft-tip darts. Hard-tip darts can damage the segments.
  - Check if the dart tips are bent or broken. Replace them if necessary.
  - Make sure darts are thrown with sufficient force to activate the segment sensors.
- **Incorrect Scoring:**
  - Reset the dartboard by turning it off and on again.
  - Ensure no darts are stuck in the segments, which might cause continuous scoring.

- **Buttons Unresponsive:**
  - Clean the control panel surface to remove any dust or debris.
  - Try pressing the buttons firmly.
  - If unresponsive, power cycle the device.

9. Specifications

Brand	Oneconcept
Model	Dartmaster 180
Model Number	4260457487397
Dimensions (L x H x D)	Approx. 57 cm x 51 cm x 6.5 cm
Weight	4.4 kg
Material	Wood, Plastic
Power Supply	9V DC / 500 mA (via included AC adapter 100-240V / 50-60 Hz)
Max Players	8
Number of Games	27
Number of Variants	150
Dart Type	Soft-tip
LED Display	Yes

10. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

© 2023 Oneconcept. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B075NKHZ4G

More documents and user manuals: **https://manuals.plus/**