Redragon G807

Redragon G807 Saturn Wired Computer Controller User Manual

Model: G807

Introduction Product Overview Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides comprehensive instructions for the Redragon G807 Saturn Wired Computer Controller. Please read this manual carefully before using the product to ensure proper setup, operation, and maintenance. Retain this manual for future reference.

2. Product Overview

The Redragon G807 Saturn is a wired computer controller designed for an enhanced gaming experience. It features a comfortable ergonomic design and offers broad compatibility with various gaming platforms.

Key Features:

- X-Input and D-Input technology for maximum PC gaming compatibility.
- Dual vibration system for greater realism and immersion during gameplay.
- Ergonomic design for comfortable extended use.
- USB 2.0 connection with a 1.5-meter cable for reliable wired connectivity.
- Compatible with PC (Windows 10, 8, 7, Vista, XP) and PlayStation 3.



Figure 2.1: Front view of the Redragon G807 Saturn Controller, showing the D-pad, analog sticks, action buttons, and central function buttons.



Figure 2.2: Back view of the Redragon G807 Saturn Controller, displaying product labels and the X-Input/Direct Input mode switch.



Figure 2.3: Close-up of the D-pad and Turbo button, located on the left side of the controller's face.



Figure 2.4: Close-up of the R1 and R2 trigger buttons, located on the top right shoulder of the controller.

3. Setup

1. **Connect to PC/PS3:** Insert the USB connector of the Redragon G807 Saturn controller into an available USB port on your computer or PlayStation 3 console.
2. **Driver Installation (PC):**
    - For most modern operating systems (Windows 7/8/10), the controller should be recognized automatically, and drivers will install without user intervention (Plug and Play).
    - If automatic installation fails or for older operating systems (Windows Vista/XP), you may need to install drivers manually. Refer to the included driver CD (if applicable) or download the latest drivers from the official Redragon website.
3. **Mode Selection (PC):** The controller supports both X-Input and Direct Input modes.
    - **X-Input Mode:** This is the standard for most modern PC games and is often automatically detected. It provides compatibility with games designed for Xbox controllers.
    - **Direct Input Mode:** This mode is typically used for older PC games or specific applications. The controller features a physical switch (often labeled "X" or "D" or an "Xbox switch") on its underside

to toggle between these modes. Ensure the correct mode is selected for your game.

4. **Verification:** After connecting, check your system's device manager (PC) or controller settings (PS3) to confirm the controller is recognized and functioning correctly.

4. Operating Instructions

Once connected and recognized, the Redragon G807 Saturn controller is ready for use with compatible games and applications.

Basic Controls:

- **Analog Sticks:** Use for directional movement and camera control.
- **D-Pad:** Provides precise directional input, often used for menu navigation or specific game actions.
- **Action Buttons (A, B, X, Y or 1, 2, 3, 4):**Perform in-game actions such as jumping, attacking, or interacting.
- **Shoulder Buttons (L1, R1) & Triggers (L2, R2):**Used for various functions like aiming, firing, or secondary actions.
- **START/SELECT Buttons:** Typically used for pausing games, accessing menus, or specific game functions.
- **TURBO Button:** Activates turbo function for rapid button presses. Consult your game's manual for specific turbo compatibility.
- **CLEAR Button:** Deactivates the turbo function.
- **Home Button:** Provides quick access to system menus on compatible platforms.

Dual Vibration Feedback:

The controller features a dual vibration system that provides tactile feedback during gameplay, enhancing immersion. This feature is automatically enabled in games that support it. If vibration is not desired, it may be disabled through in-game settings or system preferences, if available.

5. Maintenance

Proper care and maintenance will extend the lifespan of your Redragon G807 Saturn controller.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the controller. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures. Avoid wrapping the cable too tightly to prevent damage.
- **Handling:** Do not drop the controller or subject it to strong impacts. Avoid pulling the cable forcefully when disconnecting.

6. Troubleshooting

If you encounter issues with your Redragon G807 Saturn controller, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Controller not recognized by PC/PS3.	Loose USB connection, incorrect USB port, driver issue, incorrect mode.	Ensure the USB cable is securely plugged into both the controller and the device. Try a different USB port. Restart your computer or console. Verify that the correct X-Input/Direct Input mode is selected using the switch on the controller's underside. For PC, check Device Manager for driver status. Reinstall drivers if necessary.
Buttons are unresponsive or sticking.	Debris under buttons, mechanical wear, software conflict.	Gently clean around the affected buttons with a soft cloth or compressed air. Test the controller on another game or system to rule out software issues. If the issue persists, it may indicate mechanical wear.
Vibration feedback is not working.	Game does not support vibration, vibration disabled in game settings, driver issue.	Ensure the game you are playing supports vibration feedback. Check in-game settings to confirm vibration is enabled. Verify controller drivers are up to date.
Controller works in some games but not others (PC).	Incorrect X-Input/Direct Input mode for the specific game.	Toggle the X-Input/Direct Input switch on the underside of the controller. Many modern games require X-Input, while older titles may require Direct Input. Consult the game's documentation for controller compatibility and recommended settings.

7. Specifications

Feature	Detail
Brand	Redragon
Model Number	G807
Connectivity	Wired USB 2.0
Cable Length	1.5 meters (approximately 6 feet)
Controller Type	Wired Controller
Compatible Devices	PC (Windows 10, 8, 7, Vista, XP), PlayStation 3
Input Modes	X-Input, Direct Input
Special Features	Dual Vibration Feedback, Ergonomic Design, Turbo Function
Button Quantity	12 (excluding D-pad and analog sticks)
Color	Black

Feature	Detail
Product Dimensions	16 x 10 x 5.5 cm
Item Weight	299 g

8. Warranty and Support

Redragon products are manufactured to high-quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Redragon website. Keep your proof of purchase for warranty claims.
For further assistance, you may contact Redragon customer support through their official channels.

© 2024 Redragon. All rights reserved. Redragon G807 Saturn User Manual.