Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beurer 643.08

Beurer MG 151 Shiatsu Neck and Shoulder Massager

Model: MG 151 (643.08)

Introduction

The Beurer MG 151 Shiatsu Neck and Shoulder Massager is designed to provide a soothing and effective massage experience for your back, neck, and shoulders. Inspired by traditional Shiatsu therapy, which involves fluid pressure movements along the body's energy pathways, this device aims to promote physical, emotional, and mental well-being.

With its rotating massage heads, the MG 151 mimics the kneading and pressure movements of a professional Shiatsu application, offering relief from muscle tension, pain, and fatigue. It is particularly beneficial after strenuous physical activity or a stressful day, providing a powerful and intense massage that can have a toning effect. The design allows for effortless self-application, making it a convenient solution for targeted relief.



Figure 1: A man demonstrating the use of the Beurer MG 151 Shiatsu Neck and Shoulder Massager on his shoulders.

Key Features

- **Shiatsu Massage:** Features eight 3D rotating massage heads that mimic traditional Shiatsu kneading and pressure movements.
- **Adjustable Intensity:** Offers three selectable intensity levels to customize your massage experience.
- **Heat Function:** Includes a switchable heat function for enhanced relaxation and muscle relief.
- **Directional Rotation:** Massage heads rotate in both right and left directions for comprehensive coverage.
- **Manual Force Adjustment:** Convenient handles allow you to manually adjust the massage strength and target specific areas.
- **Automatic Shut-off:** Equipped with an automatic shut-off feature for safety and energy efficiency.
- **Versatile Design:** Universal cushion shape suitable for massaging the neck, shoulders, back, and even legs.



Figure 2: Visual representation of the key features, including massage type, number of heads, heat, intensity levels, and rotation.



Figure 3: Detailed view of the 3D rotating massage nodes.

Setup

Before using your Beurer MG 151 Shiatsu Neck and Shoulder Massager, please ensure you have read all safety instructions. The device operates with a power supply unit and cable, requiring a standard electrical outlet.

1. **Unpack the Device:** Carefully remove the massager and all accessories from its packaging. Retain the packaging for future storage or transport.
2. **Inspect for Damage:** Before first use, inspect the device for any visible damage. Do not use the massager if it appears damaged.
3. **Connect Power:** Plug the power adapter into the massager's input port, then plug the power cable into a suitable electrical outlet. Ensure the connection is secure.
4. **Positioning:** The massager is designed with a universal cushion shape. Position it comfortably around your neck, shoulders, or other desired body parts. The integrated handles allow for easy adjustment and application of pressure.



Figure 4: The massager's design, suitable for various body areas.

Operating Instructions

Follow these steps to operate your Beurer MG 151 massager:

1. **Power On:** Press the power button on the control panel to turn on the massager.
2. **Select Intensity:** Use the intensity control button to cycle through the three available intensity levels (low, medium, high). Choose the level that provides the most comfortable and effective massage for you.
3. **Activate Heat Function:** If desired, press the heat button to activate the soothing heat function. The heat will gradually warm up the massage heads.
4. **Apply to Body:** Position the massager on the desired body part, such as your neck, shoulders, back, or legs.
5. **Adjust Pressure:** Use the integrated handles to apply gentle pressure and guide the massager over your skin. Slowly move the massager to allow the rotating heads to effectively relieve tense muscles.
6. **Power Off:** Once your massage session is complete, press the power button again to turn off the device. Unplug the massager from the electrical outlet.



Figure 5: The intuitive control panel for easy operation.



Figure 6: The massager can be used on various body parts, including the lower back.

Important Safety Warning:

Always use the massager in dry conditions. Avoid using it on sore or injured muscles. When using the heat function, be particularly attentive to avoid falling asleep during use or using the device for excessively long periods, which could lead to discomfort or burns. It is recommended not to use the massager in direct contact with bare skin for extended periods.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your Beurer MG 151 massager.

- **Cleaning:** Always unplug the device before cleaning. Wipe the surface of the massager with a soft, slightly damp cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the massager in a cool, dry place, away from direct sunlight and excessive heat. Keep it out of reach of children.
- **Cable Care:** Do not wrap the power cable tightly around the device. Avoid kinking or stretching the cable, as this can cause damage.
- **Regular Inspection:** Periodically check the device and its power cable for any signs of wear or damage. If any damage is observed, discontinue use and contact customer support.

Troubleshooting

If you encounter issues with your Beurer MG 151 massager, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Device does not turn on.	Not plugged in correctly; Power outlet issue; Damaged cable.	Ensure the power cable is securely plugged into both the massager and a working electrical outlet. Test the outlet with another device. Inspect the cable for damage.
Massage heads stop rotating or slow down.	Excessive pressure applied; Overheating protection activated.	Reduce the pressure applied to the massager. If the device feels hot, turn it off and allow it to cool down for at least 30 minutes before resuming use.
Heat function is not working.	Heat function not activated; Device malfunction.	Ensure the heat button has been pressed. Allow a few minutes for the heat to become noticeable. If still not working, contact customer support.

If the problem persists after attempting these solutions, please contact Beurer customer support for further assistance.

Specifications

Specification	Detail
Product Name	Beurer Massager 24W Black, Red
Model Number	MG 151 (643.08)
Brand	Beurer
Dimensions (L x W x H)	104 x 13 x 18 cm (approx. 40.9 x 5.1 x 7.1 inches)
Weight	Approx. 1.68 kg (3.7 lbs)
Power Source	Electric (via power adapter and cable)
Massage Type	Shiatsu, 3D rotating massage heads
Intensity Levels	3
Special Features	Heat function, automatic shut-off, manual force adjustment

Specification	Detail
Color	Grey/Red
Country of Origin	China

Warranty and Support

Beurer products are manufactured to high-quality standards. For information regarding the warranty period and terms, please refer to the warranty card included with your product or visit the official Beurer website.

For technical support, troubleshooting assistance, or spare parts, please contact Beurer customer service. Contact details can typically be found on the official Beurer website or in the product packaging.

Beurer Official Website: www.beurer.com

© 2024 Beurer GmbH. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B075V9Z2M3

More documents and user manuals: **https://manuals.plus/**