X-PRO 308-999039

X-PRO 4-Stroke Vertical ATV Engine with Manual Transmission and Reverse, Electric Start for 200cc-250cc ATVs User Manual

Model: 308-999039

1. Introduction

This manual provides essential information for the safe and effective operation, installation, and maintenance of your X-PRO 4-Stroke Vertical ATV Engine. Please read this manual thoroughly before attempting any installation or operation. Proper understanding and adherence to these instructions will ensure optimal performance and longevity of the engine.

2. Safety Information

WARNING: Improper installation, operation, or maintenance can lead to serious injury or death. Always wear appropriate safety gear, including eye protection and gloves, when working with the engine.

- Ensure the engine is cool before performing any maintenance or adjustments.
- Disconnect the battery before working on electrical components.
- Work in a well-ventilated area to avoid inhaling exhaust fumes.
- Keep hands, feet, and clothing clear of moving parts.
- Use only genuine X-PRO replacement parts or approved equivalents.
- If you are unsure about any procedure, consult a qualified mechanic.

3. Product Overview

The X-PRO 4-Stroke Vertical ATV Engine (Model: 308-999039) is designed for 200cc-250cc ATVs, featuring a robust air-cooled single-cylinder design, manual transmission with reverse, and electric start capability.

Key Features:

- **Engine Type:** Single cylinder, 4-stroke, vertical

- **Displacement:** 197ml
- **Cooling System:** Air-cooled
- **Transmission:** Manual (4 forward, 1 reverse)
- **Starter:** Electric start
- **Fuel System:** Carburetor atomization

Engine Components:



Figure 1: Side view of the X-PRO 4-Stroke Vertical ATV Engine. This image shows the overall structure of the engine, including the cylinder head, cylinder block, and crankcase, with various external components such as the starter motor and wiring harness visible.




Figure 2: Opposite side view of the X-PRO 4-Stroke Vertical ATV Engine. This perspective highlights the spark plug location and cooling fins, essential for the air-cooled design, along with other engine casings.



Figure 3: Close-up view of the wiring harness connectors. This image details the electrical connectors for the engine, which are crucial for connecting to the ATV's electrical system for ignition, starting, and other functions.

4. Setup and Installation

Installation of this engine requires mechanical expertise. If you are not confident in your abilities, seek professional assistance. Incorrect installation can damage the engine or ATV and void the warranty.

General Installation Steps:

1. **Preparation:** Ensure the ATV is securely supported and the old engine (if applicable) has been safely removed. Clean the engine mounting area.
2. **Mounting:** Carefully position the new X-PRO engine into the ATV frame. Align mounting points and secure with appropriate bolts and fasteners. Do not overtighten.
3. **Electrical Connections:** Connect the engine's wiring harness to the ATV's electrical system. Refer to Figure 3 for connector identification. Ensure all connections are secure and properly insulated.
4. **Fuel System:** Connect the fuel line from the ATV's fuel tank to the carburetor. Ensure there are no leaks.
5. **Exhaust System:** Attach the exhaust pipe to the engine's exhaust port. Use new gaskets if necessary and tighten

securely to prevent leaks.

6. **Lubrication:** Fill the engine with the recommended type and quantity of engine oil. Refer to the Specifications section for details.
7. **Pre-Start Checks:** Double-check all connections, fluid levels, and ensure no tools or debris are left in the engine area.

5. Operating Instructions

Starting the Engine:

1. Ensure the ATV is in neutral.
2. Turn the ignition key to the 'ON' position.
3. If the engine is cold, engage the choke.
4. Press the electric start button. Release the button once the engine starts.
5. Allow the engine to warm up for a few minutes before riding. Disengage the choke as the engine warms.

Shifting Gears (Manual Transmission):

This engine features a manual transmission with 4 forward gears and 1 reverse gear. The clutch is a manual wet multi-plate type.

1. To shift, fully depress the clutch lever.
2. Use the gear shift lever to select the desired gear.
3. Slowly release the clutch lever while simultaneously applying throttle to engage the gear smoothly.
4. For reverse, ensure the ATV is completely stopped before shifting into reverse gear.

6. Maintenance

Regular maintenance is crucial for the performance and lifespan of your engine. Adhere to the recommended service intervals.

Maintenance Schedule (General Guidelines):

- **Engine Oil:** Check oil level before each ride. Change engine oil every 20-30 hours of operation or every 3 months, whichever comes first. Use recommended oil type (refer to Specifications).
- **Air Filter:** Clean or replace the air filter every 10-15 hours of operation, or more frequently in dusty conditions.
- **Spark Plug:** Inspect and clean the spark plug every 50 hours. Replace if electrodes are worn or fouled.
- **Fuel Filter:** Inspect and replace the fuel filter annually or if fuel flow is restricted.
- **Carburetor:** Inspect for proper operation and adjust idle speed as needed. Professional cleaning may be required periodically.
- **Clutch:** Ensure proper clutch lever free play. Adjust as necessary.

7. Troubleshooting

This section addresses common issues you might encounter. For problems not listed here, consult a qualified mechanic.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Engine does not start	No fuel, weak battery, fouled spark plug, ignition switch off, choke not set.	Check fuel level, charge/replace battery, clean/replace spark plug, turn ignition on, adjust choke.
Engine runs poorly/lacks power	Dirty air filter, clogged fuel filter, carburetor issues, incorrect spark plug gap.	Clean/replace air filter, replace fuel filter, clean/adjust carburetor, check/adjust spark plug gap.
Excessive smoke from exhaust	Incorrect oil level, worn piston rings, valve seal issues.	Check oil level and adjust. If problem persists, professional inspection is required.
Gears difficult to shift	Improper clutch adjustment, low/incorrect transmission fluid, bent shift fork.	Adjust clutch cable free play. Check transmission fluid. If problem persists, professional inspection is required.

8. Specifications

Specification	Value
Brand	X-PRO
Model Number	308-999039
Engine Type	Single cylinder, 4-stroke, vertical
Displacement	197 ml
Ignition System	CDI
Lubrication	Pressure/Splash
Cooling System	Air-cooled
Fuel Supply	Carburetor atomization
Horsepower	12.0 KW / 8500 RPM
Starter	Electric starter
Max Torque	14.5 N.m / 7500 RPM
Transmission	Manual (4 forward, 1 reverse)
Clutch	Manual wet multi-plate
Compression Ratio	9.0:1
Weight	65 pounds
Material	Metal
UPC	619315203787

9. Warranty and Support

For warranty information and technical support, please refer to the documentation provided with your purchase or contact X-PRO customer service. Keep your purchase receipt as proof of purchase.
For further assistance, please visit the official X-PRO website or contact your authorized dealer.

© 2026 X-PRO. All rights reserved.