Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi XL160.41

De'Longhi Colombina Class XL160.41 Bagged Electric Broom Vacuum Cleaner User Manual

Model: XL160.41

1. Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your De'Longhi Colombina Class XL160.41 Bagged Electric Broom Vacuum Cleaner. Please read these instructions carefully before using the appliance and keep them for future reference.

2. Safety Instructions

- Ensure the power supply voltage matches the rating label on the appliance.
- Do not use the vacuum cleaner to pick up water or wet materials.
- Do not vacuum hot ashes, burning cigarette butts, or sharp objects.
- Always unplug the appliance before cleaning or performing maintenance.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not operate the vacuum cleaner without the dust bag and filters correctly installed.

3. Product Overview

The De'Longhi Colombina Class XL160.41 is a powerful and efficient bagged electric broom vacuum cleaner designed for various floor types, including hard floors and carpets. It features a HEPA H13 filter for improved air quality and specialized brushes for optimal cleaning.





Figure 1: Overall view of the De'Longhi Colombina Class XL160.41 electric broom vacuum cleaner, showcasing its sleek grey design and

upright structure.

Key Components:

- **Main Unit:** Contains the motor, dust bag compartment, and filter system.
- **Handle:** Ergonomically designed for comfortable grip, includes power control.
- **Floor Brush:** Multi-function brush suitable for hard floors and carpets, with a specialized parquet care brush.
- **Dust Bag:** Collects dust and debris.
- **HEPA H13 Filter:** High-efficiency filter for trapping fine particles.
- **Power Cord:** Long cord for extended reach, with a cord winder for storage.

4. Setup and Assembly

The De'Longhi Colombina Class XL160.41 typically comes partially assembled. Follow these steps for initial setup:

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Handle Attachment:** Insert the handle into the main unit until it clicks securely into place.
3. **Dust Bag Installation:** Ensure a dust bag is correctly installed in the compartment. Refer to Section 6.1 for detailed instructions on bag replacement.
4. **Filter Check:** Verify that the HEPA filter is properly seated. Refer to Section 6.2 for filter maintenance.
5. **Power Connection:** Unwind the power cord and plug it into a suitable electrical outlet.

5. Operating Instructions

5.1 Powering On and Off

To turn the vacuum cleaner on, press the power button located on the handle. Press it again to turn the appliance off.

5.2 Power Control

The appliance features electronic power control on the handle, allowing you to adjust the suction power according to the surface being cleaned. There are 3 speed settings available.



Figure 2: Detail of the power control dial, indicating adjustable suction settings for different cleaning needs.

5.3 Using the Floor Brush

The multi-function floor brush is designed for effective cleaning on various surfaces. For delicate surfaces like wood and hard floors, the specialized parquet care brush ensures maximum dust removal without damage. The brush also has a

specific option for carpets.



Figure 3: The multi-function floor brush, designed for efficient cleaning across various floor types, including a specialized parquet care feature.

5.4 Using Attachments

The vacuum cleaner includes a combined nozzle and flat crevice tool system for cleaning difficult-to-reach areas, upholstery, and corners.

5.5 Storage

The vacuum cleaner features a space-saving vertical parking system for convenient storage. The cord winder helps keep the power cord tidy.



Figure 4: The vacuum cleaner in operation, illustrating the extensive reach provided by its long power cord.

6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

6.1 Dust Bag Replacement

The Electronic Security System (EPS) indicator light will flash when the dust bag is full or if there is an abnormal operation. Replace the dust bag promptly when indicated.

1. Unplug the vacuum cleaner from the power outlet.
2. Locate the dust bag compartment. The Quick&Clean system allows for easy access.
3. Open the practical opening system to easily remove the full dust bag.
4. Dispose of the full bag responsibly.
5. Insert a new dust bag, ensuring it is correctly seated within the compartment.
6. Close the compartment securely.



Figure 5: Illustration of the Quick&Clean system for convenient and hygienic dust bag replacement.

6.2 HEPA Filter Maintenance

The HEPA H13 filter retains 99.98% of dust particles. Regular cleaning or replacement of the filter is crucial for maintaining suction power and air quality.

1. Unplug the vacuum cleaner.
2. Access the filter compartment, typically located near the dust bag.
3. Remove the HEPA filter.

4. Gently tap the filter to dislodge accumulated dust. If heavily soiled or damaged, replace it with a new HEPA H13 filter.
5. Reinsert the clean or new filter, ensuring it is properly sealed.



Figure 6: View of the filter access point, highlighting the importance of regular HEPA filter maintenance for optimal performance.

6.3 General Cleaning

- Wipe the exterior of the vacuum cleaner with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Periodically check the floor brush for tangled hair or debris and remove them to ensure smooth operation.

7. Troubleshooting

If you encounter issues with your De'Longhi Colombina Class XL160.41, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	Not plugged in; no power at outlet; power button not pressed.	Check power cord connection; test outlet with another appliance; press power button firmly.
Reduced suction power.	Full dust bag; clogged filter; blockage in hose/brush.	Replace dust bag (refer to Section 6.1); clean/replace HEPA filter (refer to Section 6.2); check for and remove blockages.
EPS indicator light flashing.	Dust bag is full or abnormal operation.	Replace dust bag; check for blockages or filter issues.
Unusual noise during operation.	Blockage in brush or hose; damaged motor.	Turn off and unplug, then check for and remove blockages. If noise persists, contact customer support.

If the problem persists after attempting these solutions, please contact De'Longhi customer support.

8. Specifications

Technical specifications for the De'Longhi Colombina Class XL160.41:

Feature	Specification
Brand	De'Longhi
Model Number	XL160.41
Color	Grey
Product Dimensions (L x W x H)	28 x 20 x 117 cm
Weight	3.65 Kilograms
Dust Bag Capacity	1 Litre
Power	450 Watts
Voltage	450 Volts
Number of Speeds	3
Noise Level	79 Decibels

Feature	Specification
Filter Type	HEPA H13
Special Feature	Bagged
Power Source	Corded Electric
Included Components	T-nozzle, Cord winder, Vertical position, Ergonomic handle

9. Warranty and Support

De'Longhi products are manufactured to high-quality standards and are covered by a limited warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including warranty period and coverage details.
For technical assistance, spare parts, or warranty claims, please contact De'Longhi customer support through their official website or the contact information provided in your product documentation.

© 2023 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07611YHSJ

More documents and user manuals: **https://manuals.plus/**