ZdalaMit EN-22653A

ZdalaMit EN-22653A Replacement Remote Control User Manual

Model: EN-22653A

Introduction

This manual provides instructions for the ZdalaMit EN-22653A Replacement Remote Control, designed for use with various Hisense TV models. This remote control offers direct functionality without the need for programming or pairing, ensuring a straightforward user experience.

Setup and Battery Installation

The EN-22653A remote control requires two AAA alkaline batteries for operation. No programming or pairing is necessary; simply install the batteries, and the remote will be ready for immediate use. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 1: Battery installation for the EN-22653A remote control. The image shows the back of the remote with the battery cover removed, revealing the slots for two AAA batteries.

Operating Instructions

This section details the functions of the buttons on your ZdalaMit EN-22653A remote control.




INPUT
TV
AV
VGA
USB
HDMI
PICTURE
COMPONENT
CCD
SOUND
ASPECT
FAV.CH
MTS/SAP
MENU
HOME
ENTER
EXIT
DISPLAY
VOL
MUTE
CH
CH.LIST
1
2
3
4
5
6
7
8
9
0
LAST
SLEEP
EN-22653A



Figure 2: Front view of the EN-22653A remote control with all buttons labeled.

- **POWER**: Turns the TV on or off.
- **INPUT**: Cycles through available input sources (HDMI, AV, Component, USB, VGA).
- **TV/AV**: Switches between TV and AV input modes.
- **VGA**: Selects the VGA input source.
- **USB**: Selects the USB input source.
- **HDMI**: Selects the HDMI input source.
- **PICTURE**: Adjusts picture settings.
- **COMPONENT**: Selects the Component input source.
- **CCD**: Activates Closed Captioning.
- **SOUND**: Adjusts sound settings.
- **ASPECT**: Changes the screen aspect ratio.
- *** (Asterisk)**: Function may vary by TV model, often for special features.
- **FAV.CH**: Accesses favorite channels.
- **MTS/SAP**: Selects Multi-channel Television Sound/Secondary Audio Program.
- **MENU**: Opens the main menu.
- **HOME**: Returns to the home screen or smart TV interface.
- **Navigation Buttons (Up, Down, Left, Right)**: Navigates through menus and options.
- **ENTER**: Confirms selections.
- **EXIT**: Exits the current menu or screen.
- **DISPLAY**: Shows current channel information or status.
- **VOL +/-**: Adjusts the volume level.
- **MUTE**: Mutes or unmutes the sound.
- **CH.LIST**: Displays the channel list.
- **CH ^/v**: Changes channels up or down.
- **Number Pad (0-9)**: Directly enters channel numbers.
- **- (Dash)**: Used for entering sub-channels (e.g., 7-1).
- **LAST**: Returns to the previously viewed channel.
- **Media Control Buttons (Rewind, Play/Pause, Fast Forward, Previous, Stop, Next)**: Controls media playback.
- **SLEEP**: Sets the sleep timer.

Compatibility

The ZdalaMit EN-22653A Replacement Remote Control is compatible with the following Hisense TV models:

- 32K20D
- 46K360M
- 32A320
- 39A320
- 40H3
- 40K360MN
- 46K360MN
- 46K360MV1
- 46K360MV2
- 40K24D
- 50H3B

- 40K360M
- 40K20D
- 50K20D
- 50H3
- 50K23DG

Specifications

Model Number	EN-22653A
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Dimensions	7 x 2 x 1 inches (approximately)
Item Weight	0.634 ounces (approximately)
Color	Black
Special Feature	Ergonomic design
Compatible Devices	Hisense Televisions

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new 1.5V AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared receiver.
  - Point the remote directly at the TV's IR sensor.
- **Buttons not working:**
  - Clean the remote control's surface and buttons with a soft, dry cloth to remove any dirt or residue.
  - If specific buttons are unresponsive, it might indicate a fault with the remote.

Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- Keep the remote control dry. Avoid exposure to liquids.
- Do not expose the remote to extreme temperatures or direct sunlight.
- Clean the remote with a soft, slightly damp cloth. Do not use harsh chemicals or abrasive cleaners.
- If the remote will not be used for an extended period, remove the batteries to prevent leakage.

Support

For any queries or further assistance regarding your ZdalaMit EN-22653A Replacement Remote Control, please contact the seller or manufacturer. Refer to your purchase documentation for specific contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question