De'Longhi 5511410141

De'Longhi Remote Control Instruction Manual

Model: 5511410141

1. Introduction

This instruction manual provides detailed guidance for the De'Longhi Remote Control, model 5511410141. This remote is specifically designed to operate various De'Longhi heaters, including the DCH7093, TCH8093, and DCH7993 series. It allows convenient control over your heater's functions, enhancing user comfort and energy efficiency. Please read this manual thoroughly before using your remote control.

2. Product Overview

The De'Longhi remote control is a compact, infrared device that provides access to your heater's primary functions. Familiarize yourself with the layout and function of each button.



Figure 1: De'Longhi Remote Control (Model 5511410141)

This image displays the De'Longhi remote control, a black rectangular device with a white border. It features several circular and oval-shaped buttons. On the left side, from top to bottom, are the power button, '+' and '-' buttons for adjustments, a 'MODE' button, and an 'ECO PLUS' button. On the right side, there are two additional circular buttons: one with a clock icon for the timer function and another with a circular arrow icon for oscillation or fan control. The De'Longhi logo is prominently displayed at the bottom right.

2.1 Button Functions

- **Power Button ( )**: Turns the heater on or off.
- **Temperature/Setting Adjustment Buttons (+ / -)**: Adjusts the desired temperature or other numerical settings on the heater.
- **Mode Button**: Cycles through available operating modes (e.g., fan, low heat, high heat, frost protection).
- **ECO Plus Button**: Activates the energy-saving ECO Plus function, which optimizes power consumption.
- **Timer Button ( )**: Sets or adjusts the heater's timer function for delayed start or automatic shutdown.
- **Oscillation/Fan Button (↻)**: Activates or deactivates the oscillation function (if available) or controls the fan speed.

3. Setup

3.1 Inserting Batteries

The remote control requires batteries for operation. Ensure correct polarity when inserting.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide or unclip the cover to open the compartment.
3. Insert the required batteries (typically AAA, refer to the compartment for specific type) according to the polarity indicators (+ and -).
4. Replace the battery compartment cover, ensuring it clicks securely into place.

Note: Remove batteries if the remote control will not be used for an extended period to prevent leakage.

4. Operating Instructions

Point the remote control directly at the infrared receiver on your De'Longhi heater for optimal performance.

4.1 Power On/Off

Press the **Power Button** ( ) once to turn the heater on. Press it again to turn the heater off.

4.2 Adjusting Temperature/Settings

Use the **'+'** and **'-'** buttons to increase or decrease the desired temperature setting. Each press typically adjusts the temperature by one unit.

4.3 Changing Mode

Press the **Mode Button** repeatedly to cycle through the available operating modes of your heater. The active mode will usually be displayed on the heater's control panel.

4.4 ECO Plus Function

Press the **ECO Plus Button** to activate or deactivate the energy-saving function. When active, the heater will automatically adjust its power output to maintain the set temperature with reduced energy consumption.

4.5 Timer Function

Press the **Timer Button** ( ) to access the timer settings. Use the **'+'** and **'-'** buttons to set the desired duration for delayed start or automatic shutdown. Refer to your heater's main instruction manual for specific timer programming details.

4.6 Oscillation/Fan Function

Press the **Oscillation/Fan Button** (↻) to activate or deactivate the heater's oscillation feature, which distributes heat more evenly. On some models, this button may also control fan speed settings.

5. Maintenance

5.1 Battery Replacement

When the remote control's range decreases or it becomes unresponsive, it is time to replace the batteries. Follow the steps outlined in Section 3.1 for inserting new batteries.

5.2 Cleaning

To clean the remote control, wipe it with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the remote in water.

6. Troubleshooting

- **Remote not responding**: Ensure the remote is pointed directly at the heater's infrared receiver. Check if the batteries are correctly inserted and not depleted. Replace batteries if necessary.
- **Limited range**: Replace the batteries. Ensure there are no obstructions between the remote and the heater.
- **Heater not responding to specific functions**: Verify that your heater model supports the specific function (e.g., oscillation, ECO Plus). Refer to your heater's main instruction manual.

7. Specifications

Feature	Detail
Model Number	5511410141
Connectivity Technology	Infrared
Compatible Devices	De'Longhi DCH7093, TCH8093, DCH7993 series heaters
Dimensions (L x W x H)	9.2 x 4.8 x 1.5 cm (approximately 3.6 x 1.9 x 0.6 inches)
Weight	30 grams (approximately 1.1 ounces)
Power Source	Batteries (type specified in compartment)

8. Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the documentation provided with your De'Longhi heater or visit the official De'Longhi website. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question