Whirlpool MWF 427 SL

Whirlpool MWF 427 SL Microwave Oven User Manual

Extra Space + Grill, 25 Liters, Silver

1. Introduction

This manual provides essential information for the safe and efficient operation of your new Whirlpool MWF 427 SL Microwave Oven. Please read these instructions carefully before using the appliance and retain them for future reference. This appliance combines microwave cooking with grill, crisp, and steam functions, offering versatile cooking options.



Image 1.1: Front view of the Whirlpool MWF 427 SL Microwave Oven, showcasing its sleek design and control panel.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, injury to persons, or exposure to excessive microwave energy.

- Do not attempt to operate this oven with the door open or if the door is damaged.
- Do not heat liquids or other foods in sealed containers as they are liable to explode.
- Do not use corrosive chemicals or vapors in this appliance.
- Ensure the appliance is properly grounded.
- Regularly inspect the power cord for damage.
- Only use utensils suitable for microwave ovens. Metal containers are not suitable for microwave cooking.
- Never operate the oven when empty.

3. Product Features

Your Whirlpool MWF 427 SL Microwave Oven is equipped with several advanced features designed for convenience and optimal cooking results:

- **Full Flat Technology:** This innovative design eliminates the traditional turntable, providing a flat cooking surface. This allows for the use of larger and varied dish shapes, increasing usable space by 20% (accommodating dishes up to 40 cm in diagonal). The 25-liter cavity offers space comparable to a 30-liter microwave with a turntable.
- **Grill Function:** Utilize the integrated grill for browning and crisping dishes, similar to a conventional oven grill.
- **Crisp Function:** Achieve perfectly crispy results for dishes like pizza, quiches, and fries using the dedicated Crisp plate.
- **Steam Function:** Prepare healthy steamed meals with the included steamer accessory.
- **Auto Clean:** A specialized function for easy cleaning of the oven interior.
- **ChefMenu:** Access a selection of pre-programmed recipes that automatically adjust cooking settings for optimal results.
- **Jet Start:** Provides a quick start for reheating or cooking at full microwave power.



Image 3.1: The interior of the microwave oven, highlighting the Full Flat Technology with no turntable, providing a spacious and easy-to-clean cooking area.

4. Setup and Installation

4.1 Unpacking

Carefully remove the microwave oven and all packaging materials. Check for any damage. Do not operate the appliance if it is damaged. Retain packaging for transport if needed.

4.2 Placement

Place the microwave oven on a flat, stable surface that can support its weight. Ensure adequate ventilation by leaving at least 10 cm of space at the back, 20 cm at the top, and 5 cm on each side. Do not block any ventilation openings.



Image 4.1: The microwave oven positioned on a kitchen counter, demonstrating appropriate clearance for ventilation.

4.3 Electrical Connection

Plug the power cord into a grounded electrical outlet. Ensure the voltage and frequency match the specifications on the appliance rating label (230 Volts).

4.4 Included Components

The following accessories are included with your microwave oven:

- Microwave Oven Unit
- Steamer
- High Rack (for grilling)
- Crisp Plate
- Handle (for Crisp Plate)



Image 4.2: Visual representation of the accessories provided with the microwave oven, including the steamer, high rack, crisp plate, and handle.

5. Operating Instructions

5.1 Basic Microwave Cooking

1. Place food in a microwave-safe container inside the oven.
2. Close the oven door securely.
3. Select the desired power level and cooking time using the control panel.
4. Press the Start button to begin cooking.

5.2 Grill Function

The grill function is ideal for browning and crisping the top of dishes.

1. Place food on the high rack provided.
2. Select the Grill function and set the desired cooking time.
3. Press Start. Monitor food to prevent over-browning.



Image 5.1: Corn on the cob placed on the high rack, illustrating the use of the grill function for even browning.

5.3 Crisp Function

Use the Crisp function with the Crisp plate for crispy results from the bottom and top.

1. Preheat the Crisp plate according to recipe instructions.
2. Place food directly on the hot Crisp plate.
3. Select the Crisp function and set the cooking time.
4. Press Start. Use the handle to safely remove the hot Crisp plate.



Image 5.2: A pizza cooking on the Crisp plate, demonstrating how the Crisp function provides even heating for a crispy base.



Image 5.3: Pears baking in a dish, showcasing the versatility of the Crisp function for various recipes.

5.4 Steam Function

For healthy steamed dishes, use the provided steamer accessory.

1. Add water to the bottom of the steamer, then place food in the steamer basket.
2. Place the steamer inside the microwave oven.
3. Select the Steam function and set the appropriate cooking time.
4. Press Start.

5.5 Auto Clean Function

To clean the oven interior:

1. Place a microwave-safe bowl with water and a few drops of lemon juice inside the oven.
2. Select the Auto Clean function.
3. Press Start. The steam generated will loosen food residues, making them easier to wipe away.

5.6 ChefMenu Function

The ChefMenu offers pre-programmed settings for various dishes.

1. Press the ChefMenu button.
2. Rotate the control knob to select the desired recipe from the display.
3. Confirm the selection and press Start. The oven will automatically set the cooking parameters.

5.7 Jet Start Function

For quick reheating at full power:

- Press the Jet Start button. The oven will immediately begin cooking at maximum microwave power for a preset duration (e.g., 30 seconds). Press again to add more time.

6. Maintenance and Cleaning

6.1 Exterior Cleaning

Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.

6.2 Interior Cleaning

After each use, wipe the interior with a damp cloth. For stubborn food residues, use the Auto Clean function (Section 5.5) or a mild detergent. Ensure the oven is cool before cleaning.

6.3 Accessories Cleaning

Wash the Crisp plate, high rack, and steamer with warm, soapy water or in a dishwasher if suitable.

7. Troubleshooting

If you encounter issues with your microwave oven, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Oven does not start	Power cord not plugged in; Door not closed properly; Fuse blown or circuit breaker tripped.	Ensure plug is firmly in outlet; Close door securely; Check household fuse/circuit breaker.
Food not cooking evenly	Incorrect power level or cooking time; Food not stirred or rearranged.	Adjust power/time; Stir or turn food halfway through cooking.
Excessive steam inside oven	High moisture content in food.	This is normal for foods with high moisture. Wipe interior after use.
Oven light not working	Light bulb needs replacement.	Contact qualified service personnel for bulb replacement.

If the problem persists after attempting these solutions, please contact Whirlpool customer service.

8. Specifications

Feature	Specification
Brand	Whirlpool
Model Number	MWF 427 SL
Capacity	25 Liters
Microwave Power	800 Watts
Grill Power	1000 Watts (inferred from product title)
Voltage	230 Volts
Color	Silver
Material	Plastic Glass
Installation Type	Freestanding
Noise Level	1 dB
Product Dimensions (L x W x H)	42.6 x 49 x 32 cm
Weight	15.5 Kilograms
Special Features	Crisp, Grill Function, Steam

9. Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official Whirlpool website. For technical support, spare parts, or service inquiries, please contact Whirlpool customer service in your region. Keep your purchase receipt as proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question