ONN ONA16AA008

Onn ONA16AA008 Amplified Stereo Speakers User Manual

Model: ONA16AA008

Introduction

Thank you for purchasing the Onn ONA16AA008 Amplified Stereo Speakers. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your new speakers. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

What's in the Box

Your package should contain the following items:

- 2 x Onn ONA16AA008 Amplified Stereo Speakers

Setup Guide

Follow these steps to set up your Onn Amplified Stereo Speakers:

1. Unpacking and Inspection

Carefully remove the speakers from their packaging. Inspect both speakers for any signs of damage. If any damage is found, do not proceed with setup and contact customer support.



This image displays the Onn ONA16AA008 Amplified Stereo Speakers inside their packaging. The box highlights key features: "3.5 mm Aux in plug" for audio input and "Requires 3 AAA batteries (not included)" for power.

2. Powering the Speakers

The speakers require 3 AAA batteries (not included) for operation. Locate the battery compartment on one of the speakers, insert the batteries according to the polarity indicators, and close the compartment securely. Alternatively, the speakers can be powered via a USB connection. Connect the USB cable from the speakers to an available USB port on your computer or a USB wall adapter (not included).

3. Connecting to an Audio Source

The Onn ONA16AA008 speakers connect via a 3.5 mm auxiliary (Aux) input. Plug the 3.5 mm audio cable from the speakers into the headphone jack or audio output port of your computer, smartphone, tablet, or other audio device.

4. Positioning the Speakers

Place the speakers on a flat, stable surface, ideally equidistant from your listening position for optimal stereo sound. Ensure there are no obstructions in front of the speakers.

Operating Instructions

Turning On/Off

Locate the power button, typically on the front or side of one of the speakers. Press the button to turn the speakers on. A power indicator light (often blue) will illuminate. Press the button again to turn them off.

Adjusting Volume

Use the volume control knob or buttons on the speaker to adjust the audio output level. You may also need to adjust the volume on your connected audio source (computer, phone, etc.) for the desired sound level.

Audio Playback

Once connected and powered on, begin playing audio from your source device. Sound will be output through the speakers.

Care and Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe down the exterior of the speakers. Do not use liquid cleaners, aerosols, or abrasive chemicals, as these can damage the finish or internal components.
- **Storage:** When not in use for extended periods, store the speakers in a cool, dry place away from direct sunlight and extreme temperatures. If using batteries, remove them before long-term storage to prevent leakage.
- **Handling:** Avoid dropping the speakers or subjecting them to strong impacts. Do not expose them to water or excessive moisture.

Troubleshooting

If you encounter issues with your speakers, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
No sound	Speakers not powered on. Low or no volume on speakers or source device. Audio cable not properly connected. Dead or incorrectly inserted batteries.	Ensure speakers are turned on and power indicator is lit. Increase volume on both speakers and the connected device. Check that the 3.5 mm audio cable is fully inserted into both the speakers and the audio source. Replace AAA batteries or ensure they are inserted with correct polarity. If using USB power, ensure the USB connection is secure.
Distorted sound	Volume set too high. Poor audio source quality. Loose cable connection.	Lower the volume on both the speakers and the audio source. Try a different audio source or file to check if the distortion persists. Ensure all cable connections are secure.

Problem	Possible Cause	Solution
Only one speaker working	Faulty audio cable. Issue with the speaker unit.	Try a different 3.5 mm audio cable. Ensure the connection between the two speakers (if applicable) is secure. If the problem persists, contact customer support.

Specifications

Feature	Detail
Model Name	ONA16AA008
Speaker Type	Stereo
Audio Output Mode	Stereo
Connectivity Technology	Auxiliary (3.5mm)
Speaker Maximum Output Power	10 Watts
Power Source	Corded Electric (USB) or 3x AAA Batteries (not included)
Color	Black
Included Components	2 Speakers
Product Dimensions	2 x 5.5 x 7 inches
Item Weight	14.3 ounces
Manufacturer	Onn
UPC	681131131445

Warranty Information

This product comes with a limited warranty. Please refer to the warranty card included with your purchase or contact Onn customer support for specific terms and conditions. The warranty typically covers defects in materials and workmanship under normal use.

Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact Onn customer support. Refer to the product packaging or the manufacturer's official website for the most current contact information.
Online Support: Visit the official Onn website for FAQs and support resources.
Phone Support: Check your product documentation for a customer service phone number.

© 2024 ONN. All rights reserved. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question