Lovehoney Mantric

Lovehoney Mantric Rechargeable G-Spot Vibrator User Manual

Model: Mantric

Introduction

Thank you for choosing the Lovehoney Mantric Rechargeable G-Spot Vibrator. This manual provides essential information for the safe and effective use, care, and maintenance of your device. Please read it thoroughly before first use and retain it for future reference.



Image: The Lovehoney Mantric G-Spot Vibrator, showcasing its ergonomic design and smooth silicone finish.

Safety Information

- This product is for adult use only.
- Consult a healthcare professional before use if you have any medical conditions or concerns.

- Discontinue use immediately if you experience any discomfort or pain.
- Do not use with silicone-based lubricants, as this may damage the silicone material. Always use water-based lubricants.
- Keep out of reach of children.

Package Contents

- Lovehoney Mantric Rechargeable G-Spot Vibrator
- USB Charging Cable
- User Manual (this document)

Setup

1. Initial Charging

Before first use, fully charge your Mantric vibrator. Connect the provided USB charging cable to the charging port on the base of the vibrator and plug the other end into a USB power source (e.g., computer, USB wall adapter). The LED indicator will show charging status and turn solid when fully charged. A full charge typically takes approximately 2-3 hours.

2. First Use Preparation

Clean the vibrator thoroughly before its first use and after every subsequent use. Refer to theMaintenance section for detailed cleaning instructions.

Operating Instructions

Power On/Off

To turn the vibrator on, press and hold the power button located on the base for 2 seconds. To turn it off, press and hold the power button again for 2 seconds.



Image: The vibrator highlighting its 7 modes of vibration for versatile use.

Changing Vibration Modes

Once powered on, press the power button repeatedly to cycle through the 7 distinct vibration modes. The LED panel colors on the base correspond to different modes, helping you identify your preferred settings.

Usage Tips

- Apply a generous amount of water-based lubricant to the vibrator and the desired area for comfortable use.
- The curved shaft and bulbous tip are designed for precise G-spot or prostate stimulation. Experiment with angles and pressure to find what feels best.
- The vibrator is 100% waterproof and submersible, allowing for use in baths or showers.



Image: A close-up view of the vibrator's curved length and bulbous tip, designed for precise stimulation.



Image: The vibrator shown in water, illustrating its fully submersible and waterproof design.

Maintenance and Care

Cleaning

Clean your Lovehoney Mantric vibrator thoroughly before and after each use. Wash with warm water and a toy cleaner or mild antibacterial soap. Rinse thoroughly and pat dry with a lint-free cloth. Ensure the charging port is dry before recharging.

Storage

Store the vibrator in a clean, dry, and dust-free place, away from direct sunlight and extreme temperatures. Keep it separate from other toys made of different materials to prevent potential reactions or damage.

Troubleshooting

Issue	Possible Cause	Solution
Vibrator does not turn on.	Low battery or not charged.	Ensure the device is fully charged. Press and hold the power button for 2 seconds to turn on.
Vibrations are weak or inconsistent.	Low battery.	Recharge the vibrator fully.
Device not responding to button presses.	Device may be locked or experiencing a temporary software glitch.	Try turning the device off and on again. Ensure it is fully charged.
Charging indicator not lighting up.	Charging cable or power source issue.	Check the USB cable connection. Try a different USB port or power adapter.

If you continue to experience issues, please contact Lovehoney customer support.

Specifications

Model Name: Mantric

Brand: Lovehoney

Material: Silicone

Color: Pink

Insertable Length: 5 inches

Product Dimensions: 7.87 x 3.94 x 2.36 inches

Weight: 7.05 ounces

Battery: 1 Product Specific battery (included), Rechargeable via USB

Waterproof: 100% Submersible

Vibration Modes: 7



Image: The vibrator with an overlay showing its 5-inch insertable length.

Warranty and Support

Lovehoney products are manufactured to high standards. For information regarding warranty coverage, returns, or technical support, please visit the official Lovehoney website or contact their customer service directly. Please retain your proof of purchase for any warranty claims.

Lovehoney Official Website: www.lovehoney.com

© 2023 Lovehoney. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question