Verbatim 99779

Verbatim Wireless Silent Mouse & Keyboard Combo User Manual

Model: 99779

Introduction

This user manual provides comprehensive instructions for the Verbatim Wireless Silent Mouse & Keyboard Combo. Designed for quiet operation, this combo features silent click switches and rubber covers for a truly noiseless experience. It utilizes 2.4GHz wireless technology for a lag-free connection and includes a compact nano receiver. The mouse incorporates Blue LED technology for versatile surface compatibility, while the keyboard offers a full numeric keypad and full-size function keys within a slim design.



Image: The Verbatim Wireless Silent Mouse and Keyboard Combo, showcasing both the full-size keyboard and the compact mouse.

Setup

Package Contents:

- Silent Wireless Keyboard
- Silent Wireless Mouse
- Nano Receiver

- 4 x AAA Batteries (included)

Installation Steps:

1. **Insert Batteries:** Locate the battery compartments on the underside of both the keyboard and the mouse. Insert the included 4 AAA batteries, ensuring correct polarity (+/-).
2. **Connect Nano Receiver:** Plug the small USB nano receiver into an available USB port on your computer. The system should automatically detect and install the necessary drivers.
3. **Power On:** Ensure the power switch on the mouse (usually on the underside) is in the "ON" position. The keyboard typically activates upon key press.
4. **Verify Connection:** Once the receiver is plugged in and devices are powered on, the keyboard and mouse should be ready for use. No additional software installation is required for most operating systems.



Image: The compact nano receiver inserted into a computer's USB port, enabling wireless connectivity for the keyboard and mouse.

Operating Instructions

Keyboard Features:

- **Silent Technology:** Equipped with silent click switches and rubber covers for a quiet typing experience.

- **Full Numeric Keypad:** Includes a dedicated numeric keypad for efficient data entry.
- **Full-Size Function Keys:** Standard F1-F12 function keys provide quick access to various commands.
- **Slim Design:** The keyboard features a slim profile for comfortable use and portability.



Image: A side profile view of the Verbatim Wireless Silent Keyboard, highlighting its slim and ergonomic design.

Mouse Features:

- **Silent Technology:** Features silent click switches for noiseless operation.
- **Blue LED Technology:** Allows the mouse to track on a wide variety of surfaces, including glass, wood, and granite, with precision.
- **Ergonomic Design:** Shaped for comfortable use during extended periods.



Image: A top-down view of the Verbatim Wireless Silent Mouse, showing its ergonomic shape and scroll wheel.



Image: The Verbatim Wireless Silent Mouse with its dimensions clearly marked, indicating its compact size.

Wireless Connection:

The combo operates on a 2.4GHz wireless frequency, providing a stable and lag-free connection up to a certain range (typically

10 meters or 33 feet, though not specified in product details). The nano receiver ensures a reliable link between your computer and the devices.

Maintenance

Battery Replacement:

When the keyboard or mouse performance degrades (e.g., lag, unresponsiveness), it is likely due to low battery power. Replace all 4 AAA batteries in both devices with new ones. Always ensure correct polarity when inserting new batteries.

Cleaning:

To clean the keyboard and mouse, use a soft, dry, lint-free cloth. For stubborn dirt or grime, a slightly damp cloth with a mild cleaning solution can be used, but ensure no liquid enters the devices. Avoid abrasive cleaners or solvents.

Troubleshooting

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	Low batteries; Nano receiver disconnected; Interference; Driver issue.	1. Replace batteries in both devices. 2. Ensure the nano receiver is securely plugged into a working USB port. Try a different USB port. 3. Move the devices closer to the receiver. 4. Restart your computer.
Lag or intermittent connection	Distance from receiver; Interference from other wireless devices; Low battery.	1. Reduce the distance between the devices and the receiver. 2. Avoid placing the receiver near other wireless devices (e.g., Wi-Fi routers, cordless phones). 3. Replace batteries.
Mouse tracking issues (inaccurate movement)	Dirty sensor; Unsuitable surface.	1. Clean the optical sensor on the underside of the mouse with a soft, dry cloth. 2. Ensure you are using the mouse on a suitable surface. While Blue LED technology is versatile, highly reflective or transparent surfaces can sometimes cause issues.
Keys sticking or not registering	Debris under keys; Mechanical issue.	1. Gently try to dislodge any debris around the affected keys. 2. If the issue persists, it may indicate a mechanical fault.

Specifications

Feature	Detail
Brand	Verbatim
Model Number	99779
Connectivity Technology	2.4GHz Wireless (USB Nano Receiver)
Operating System Compatibility	Windows XP (and newer, generally compatible with Mac)

Feature	Detail
Item Weight	1.06 pounds
Product Dimensions (LxWxH)	17.56 x 6.11 x 1.12 inches
Color	Graphite (Combo)
Power Source	Battery Powered
Batteries Required	4 AAA batteries (included)
Special Features	Numeric Keypad, Silent Click Switches, Blue LED Technology
Manufacturer	Verbatim Americas, LLC
Country of Origin	China

Warranty and Support

For warranty information and technical support, please refer to the official Verbatim website or contact Verbatim customer service. A user guide in PDF format is also available for download from the product's Amazon page or the manufacturer's support section.
Manufacturer: Verbatim Americas, LLC
User Guide (PDF): Download User Guide

Important Information

Legal Disclaimer:
This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

© 2024 Verbatim. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question