Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nikai UHD75SLED1

Nikai UHD75SLED1 75-inch 4K UHD Android Smart LED TV User Manual

Model: UHD75SLED1

Introduction

This manual provides essential information for the safe and efficient use of your Nikai UHD75SLED1 75-inch 4K UHD Android Smart LED TV. Please read these instructions thoroughly before operating the television and retain them for future reference.



Front view of the Nikai UHD75SLED1 75-inch 4K UHD Android Smart LED TV.

Setup

1. Unpacking and Component Check

Carefully remove the television from its packaging. Ensure all components are present:

- Nikai UHD75SLED1 75-inch TV
- Remote Control
- User Manual (this document)
- Power Cable
- TV Stand components (if included)

2. Stand Installation (Tabletop Mounting)

If placing the TV on a tabletop, attach the included stand according to the diagrams. Ensure the stand is securely fastened to

prevent the TV from tipping.



Side view of the TV, illustrating the stand attachment area.

3. Wall Mounting (Optional)

For wall mounting, use a VESA-compatible wall mount kit (not included) that supports a 400 x 400 mm pattern. Consult a professional for installation to ensure safety and proper mounting.



Rear view of the TV, highlighting VESA mounting points and various input ports.

4. Connecting Power

Connect the power cable to the TV's power input and then to a suitable 220V AC, 50Hz power outlet.

5. Connecting External Devices

Your TV features multiple ports for connecting external devices:

- **HDMI Ports (x2)**: For connecting Blu-ray players, gaming consoles, set-top boxes, etc. Supports HDCP.
- **USB Ports (x2)**: For connecting USB storage devices to play media or for software updates.
- **Other Ports**: Includes component/composite video inputs and audio outputs.

Close-up of the TV's multiple input/output ports.

6. Network Connection (Wi-Fi)

To access smart TV features, connect your TV to a wireless network. Navigate to the network settings menu, select your Wi-Fi network, and enter the password.

Operating Instructions

1. Remote Control Overview

The included remote control uses infrared technology and requires AA batteries. Familiarize yourself with the buttons for power, volume, channel, navigation, and smart TV functions.

2. Initial Setup and Android OS

Upon first power-on, the TV will guide you through an initial setup wizard. This includes language selection, network connection, and Google account setup for the Android 9.0 operating system.

3. Smart TV Features

Your Nikai Smart TV provides access to various internet services and applications.

- **Netflix**: Pre-installed for streaming movies and TV shows.
- **Other Apps**: Download additional applications from the Google Play Store.
- **Web Browsing**: Use the integrated web browser to access websites.



The Android TV home screen with access to streaming services and apps.

4. Screen Mirroring (Miracast)

The TV supports Miracast technology, allowing you to wirelessly mirror content from compatible mobile devices to the TV screen. Refer to your mobile device's instructions for initiating screen mirroring.

5. Input Selection

Use the "Input" or "Source" button on your remote control to switch between connected devices (HDMI 1, HDMI 2, USB, etc.) and the TV tuner.

Maintenance

1. Cleaning the Screen

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Avoid using harsh chemicals, abrasives, or direct spraying of liquids onto the screen.

2. General Care

- Keep the TV away from direct sunlight, heat sources, and excessive dust.
- Ensure proper ventilation around the TV to prevent overheating.
- Do not place heavy objects on top of the TV.
- Unplug the TV from the power outlet during lightning storms or when it will be unused for extended periods.

Troubleshooting

Before contacting support, please refer to the following common issues and solutions:

Problem	Possible Solution

Problem	Possible Solution
No Power	Ensure the power cable is securely connected to both the TV and the power outlet. Check if the outlet is functioning.
No Picture / Black Screen	Verify the correct input source is selected. Check all cable connections (HDMI, etc.). Try restarting the TV.
No Sound	Check the volume level and ensure the TV is not muted. Verify audio cable connections if using external speakers.
Wi-Fi Connection Issues	Ensure your router is on and within range. Re-enter the Wi-Fi password. Try restarting both the TV and your router.
Remote Control Not Working	Replace the AA batteries. Ensure there are no obstructions between the remote and the TV's IR sensor.

If the issue persists after trying these solutions, please contact Nikai customer support.

SPECIFICATIONS

Feature	Detail
Brand	Nikai
Model Name	UHD75SLED1
Screen Size	75 Inches
Display Technology	LED
Resolution	4K UHD (3840x2160)
Refresh Rate	60 Hz
Operating System	Android 9.0
Memory Storage	8 GB NAND Flash
Supported Internet Services	Netflix
Special Features	DLNA, HDR10, HLG
Connectivity Technology	HDMI, Wi-Fi, USB
Total HDMI Ports	2 (with HDCP support)
Total USB Ports	2 (USB 2.0)
Screen Mirroring	Miracast
Aspect Ratio	16:9
Product Dimensions (DxWxH)	31.8 x 166.8 x 104.1 cm
Item Weight	30.3 Kilograms
VESA Mounting Standard	400 x 400 mm
Included Components	User Manual, Remote Control
Power Supply	220V AC, 50Hz

Feature	Detail
Remote Battery Type	AA
Color	Silver

Warranty and Support

Warranty Information

This product is eligible for a two-year warranty provided by the manufacturer/brand from the date of purchase. For detailed terms and conditions, or to claim warranty service, please contact the manufacturer or seller directly.

Customer Support

For technical assistance, troubleshooting beyond this manual, or service inquiries, please contact Nikai customer support. Keep your purchase receipt and product model number (UHD75SLED1) ready when contacting support.

© 2025 Nikai. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B076T6M8LS

More documents and user manuals: **https://manuals.plus/**