Nestle MD9777DR

Nestle Dolce Gusto LUMIO MD9777-DR Capsule Coffee Maker User Manual

1. Introduction

This manual provides essential instructions for the safe and efficient use of your Nestle Dolce Gusto LUMIO MD9777-DR capsule coffee maker. Please read all instructions carefully before operating the appliance and retain this manual for future reference.

2. Safety Instructions

- Always connect the appliance to a grounded electrical outlet.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only Dolce Gusto capsules with this machine.
- Never open the capsule holder during brewing.

3. Product Overview

Familiarize yourself with the main components of your Dolce Gusto LUMIO coffee maker.





Figure 1: Front view of the Nestle Dolce Gusto LUMIO MD9777-DR coffee maker, showcasing its compact design and water tank.



Figure 2: Side view of the Nestle Dolce Gusto LUMIO MD9777-DR, highlighting the transparent water reservoir and capsule insertion area.

Key Components:

- **Water Tank:** Removable reservoir for fresh water.
- **Capsule Holder:** Where Dolce Gusto capsules are inserted.
- **Brew Head:** Dispenses hot or cold water through the capsule.
- **Control Panel:** Buttons and indicators for power, volume selection, and hot/cold brewing.
- **Drip Tray:** Collects excess liquid and can be adjusted for different cup sizes.

4. Setup

4.1 Unpacking

1. Remove all packaging materials from the coffee maker.
2. Place the appliance on a stable, flat, heat-resistant surface, away from water sources.

4.2 Initial Cleaning and Priming

1. Wash the water tank and drip tray with warm water and a mild detergent. Rinse thoroughly and dry.
2. Fill the water tank with fresh drinking water up to the MAX level.
3. Insert the water tank back into the machine.
4. Plug the power cord into a grounded electrical outlet. The power button will illuminate.
5. Without a capsule, place a container under the brew head.
6. Press the hot water button to run water through the system until the tank is empty. Repeat this process with cold water. This primes the pump and cleans the internal system.

5. Operating Instructions

5.1 Preparing a Beverage

1. Ensure the water tank is filled with fresh water.
2. Turn on the machine by pressing the power button. Wait for the indicator light to turn solid green, indicating it is ready.
3. Lift the locking handle and pull out the capsule holder.
4. Insert a Dolce Gusto capsule into the holder. Ensure it is seated correctly.
5. Push the capsule holder back into the machine and lower the locking handle until it clicks.
6. Adjust the drip tray height to match your cup size. Place your cup on the drip tray.
7. Select the desired water volume using the volume selector on the control panel (refer to capsule packaging for recommended volume).
8. Press the hot (red) or cold (blue) water button to start brewing. The machine will automatically stop when the selected volume is reached.
9. Once brewing is complete, wait a few seconds for any remaining drips.
10. Lift the locking handle, remove the used capsule, and dispose of it.

6. Maintenance and Cleaning

6.1 Daily Cleaning

- After each use, remove and empty the drip tray. Wash it with warm, soapy water and rinse.
- Wipe the exterior of the machine with a damp cloth.
- Rinse the capsule holder under running water.

6.2 Water Tank Cleaning

Clean the water tank weekly with warm, soapy water. Rinse thoroughly to remove any soap residue.

6.3 Descaling

Regular descaling is crucial for maintaining machine performance and beverage quality. The frequency depends on water hardness and usage. Refer to the official Dolce Gusto descaling kit instructions for the specific procedure. Generally, this involves using a descaling solution and running it through the machine without a capsule.

7. Troubleshooting

Problem	Possible Cause	Solution
Machine does not turn on.	No power supply.	Check if the power cord is securely plugged into a working outlet.
No water flow.	Water tank empty or improperly inserted. Machine needs priming.	Fill water tank. Ensure tank is correctly seated. Perform priming procedure (Section 4.2).
Coffee is cold or not hot enough.	Machine not preheated. Descaling needed.	Wait for the indicator light to turn solid green. Descale the machine.

Problem	Possible Cause	Solution
Water leaks from machine.	Water tank or capsule holder not correctly seated.	Ensure water tank and capsule holder are properly installed.

8. Specifications

- **Brand:** Nestle
- **Model:** MD9777DR
- **Product Dimensions:** 9.06 x 9.45 x 7.87 inches
- **Item Weight:** 6.7 pounds
- **Coffee Maker Type:** Espresso Machine
- **Coffee Input Type:** Capsule
- **Operation Mode:** Fully Automatic
- **Special Feature:** Thermal
- **Included Components:** Milk Frother (integrated via specific capsules)

9. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question