RemotesReplaced LD32C12

RemotesReplaced Remote Control Instruction Manual for Grandin LD32C12 TV

Model: LD32C12

1. Introduction

This document serves as an instruction manual for the RemotesReplaced remote control, specifically designed as a direct replacement for Grandin LD32C12 television models. This remote control provides full functionality without the need for complex setup or programming. It is engineered to replicate the original remote's features, ensuring seamless integration with your Grandin LD32C12 TV.

2. Setup: Battery Installation

The remote control requires two AAA batteries for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open the compartment.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

No additional setup or programming is required after battery installation. The remote is ready for immediate use.



Figure 1: Side view of the remote control, illustrating the battery compartment area.

3. Operating Instructions

To operate your Grandin LD32C12 TV, point the remote control directly at the television's infrared receiver. Ensure there are no obstructions between the remote and the TV.





Figure 2: Front view of the remote control with all buttons.

3.1. Key Functions

- **POWER** (Red Button): Turns the TV on or off.
- **MUTE**: Mutes or unmutes the TV sound.
- **TV** / **SAT** / **DVD** / **AUX**: Selects the input source.
- **MENU**: Accesses the TV's main menu.
- **EXIT**: Exits the current menu or on-screen display.
- **SHIFT**: (Functionality may vary based on TV model, typically for secondary button functions).
- **Number Buttons (0-9)**: Directly select channels.
- **SOURCE**: Cycles through available input sources.
- **-/--**: For entering two-digit or three-digit channel numbers.
- **GUIDE**: Displays the electronic program guide (EPG).
- **SUB**: Activates or deactivates subtitles.
- **SIZE**: Adjusts the screen display size/aspect ratio.
- **SETUP**: Accesses setup options.
- **TEXT**: Activates or deactivates Teletext.
- **Volume Up/Down (V+/V-)**: Adjusts the volume level.
- **Channel Up/Down (P+/P-)**: Changes the TV channel.
- **Navigation Buttons (Up, Down, Left, Right)**: Navigates through menus and options.
- **OK**: Confirms selections in menus.
- **BACK**: Returns to the previous menu or screen.
- **SLEEP**: Sets a sleep timer for the TV.
- **TV/DTV**: Switches between analog TV and digital TV modes.
- **INFO**: Displays information about the current program.
- **EPG**: Electronic Program Guide.
- **FAV**: Accesses favorite channels list.
- **NET TV** / **SMART**: Accesses smart TV features or internet-connected services (if supported by the TV).
- **Color Buttons (Red, Green, Yellow, Blue)**: Used for specific functions within menus or interactive services.

- **Playback Controls (Rewind, Play/Pause, Fast Forward)**: Controls media playback (e.g., from USB or connected devices).

4. Maintenance

To ensure the longevity and proper functioning of your remote control, observe the following maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new ones of the same type (AAA). Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal circuitry.

5. Troubleshooting

If you experience issues with your remote control, refer to the following common troubleshooting steps:

- **Remote Not Responding:**
  - Check if the batteries are correctly inserted with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Confirm you are pointing the remote directly at the TV.
- **Some Buttons Not Working:**
  - This may indicate low battery power. Try replacing the batteries.
  - Ensure the TV model is Grandin LD32C12, as this remote is specifically designed for this model.
- **TV Not Responding to Any Remote:**
  - Check if the TV itself is powered on and functioning correctly.
  - Unplug the TV from the power outlet for a few minutes, then plug it back in. This can reset the TV's internal systems.

6. Specifications

Feature	Detail
Brand	RemotesReplaced
Model Number	LD32C12
Compatible Devices	Grandin LD32C12 Television
Connectivity Technology	Infrared (IR)
Maximum Range	10 Meters

Feature	Detail
Batteries Required	2 x AAA (not included)
Item Weight	120 Grams
Manufacturer	Linkwebb

7. Warranty and Support

This RemotesReplaced remote control comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.
For technical support or warranty claims, please contact your retailer or the RemotesReplaced customer service. Please have your purchase receipt and product model number (LD32C12) available when contacting support.

© 2023 RemotesReplaced. All rights reserved.