Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced 46PFL3807H/12

RemotesReplaced TV Remote Control User Manual

For Philips 46PFL3807H/12 Television

Introduction

This manual provides comprehensive instructions for the RemotesReplaced TV Remote Control, designed as a direct replacement for Philips 46PFL3807H/12 television models. This remote control offers full functionality without the need for complex programming or setup codes. Simply insert batteries to begin operation.

Setup

Battery Installation

The remote control requires two (2) AAA batteries for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

After battery installation, the remote control is ready for immediate use with your compatible Philips television.



Image: Side view of the remote control, highlighting the infrared emitter at the top. This component transmits signals to the television.

Operating Instructions

This remote control is designed to replicate the functions of your original Philips TV remote. Point the remote control directly at your television's infrared receiver for optimal performance. The maximum effective range is approximately 10 meters.





Image: Front view of the RemotesReplaced TV remote control, showing the layout of all buttons.

Key Functions

- **POWER:** Turns the television on or off.
- **MUTE:** Mutes or unmutes the television audio.
- **TV/SAT/DVD/AUX:** Selects input sources.
- **MENU:** Accesses the television's main menu.
- **EXIT:** Exits the current menu or function.
- **SHIFT:** Provides access to secondary functions of certain buttons.
- **Number Buttons (0-9):** Directly selects channels or enters numerical input.
- **SOURCE:** Cycles through available input sources.
- **-/--:** Toggles between single and double-digit channel entry.
- **GUIDE:** Displays the electronic program guide (EPG).
- **SUB:** Activates or deactivates subtitles.
- **SIZE:** Adjusts the screen aspect ratio.
- **SETUP:** Accesses setup options.
- **TEXT:** Activates or deactivates Teletext.
- **Volume (+V / -V):** Increases or decreases the volume.
- **Channel (+P / -P):** Changes channels up or down.
- **Navigation (Up, Down, Left, Right, OK):** Navigates through menus and confirms selections.
- **BACK:** Returns to the previous screen or menu.
- **SLEEP:** Sets a sleep timer for the television.
- **TV/DTV:** Switches between analog and digital television modes.
- **INFO:** Displays information about the current program or input.
- **EPG:** Accesses the Electronic Program Guide.
- **FAV:** Accesses favorite channels.
- **NET TV:** Direct access to network television features.
- **SMART:** Direct access to smart TV features.

- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within menus or interactive services.
- **Playback Controls (Rewind, Play, Fast Forward, Stop):** Controls media playback.

Features

The RemotesReplaced TV Remote Control offers the following features:

- Direct replacement functionality for the original Philips remote control.
- No installation codes required; ready to use immediately after battery insertion.
- Access to all original remote control functions.
- Specifically manufactured for the Philips 46PFL3807H/12 model, ensuring full compatibility.

Troubleshooting

If you experience issues with your remote control, consider the following troubleshooting steps:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the television's infrared receiver.
  - Confirm the remote control is pointed directly at the television.
- **Limited Range:**
  - Ensure batteries are fresh. Low battery power can reduce the effective range.
  - Minimize bright light sources (e.g., direct sunlight, fluorescent lights) that might interfere with the infrared signal.
- **Specific Buttons Not Working:**
  - Clean the remote control surface and buttons to remove any dirt or debris that might be obstructing button presses.
  - If only a few buttons are unresponsive, it might indicate a specific internal issue.

Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the remote control's surface. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution, then wipe dry immediately. Avoid using abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the remote control's response becomes sluggish or inconsistent. Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Handling:** Avoid dropping the remote control or subjecting it to strong impacts, as this can damage internal components.

Specifications

Specification	Detail
Brand	RemotesReplaced
Compatible Devices	Philips Television (Model 46PFL3807H/12)
Connectivity Technology	Infrared (IR)
Maximum Range	10 Meters
Batteries Required	2 x AAA batteries
Item Weight	120 Grams
Manufacturer	Linkwebb

Warranty and Support

This RemotesReplaced TV Remote Control comes with a 1-year guarantee, ensuring reliable performance. For any issues or inquiries not covered in this manual, please refer to your purchase documentation for seller contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B076VF3B5W

More documents and user manuals: **https://manuals.plus/**