Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced HD87532B8

RemotesReplaced Remote Control for TELEFUNKEN HD87532B8 User Manual

1. Introduction

This user manual provides comprehensive instructions for the RemotesReplaced remote control, designed as a direct replacement for the TELEFUNKEN HD87532B8. It offers all original functions without requiring any setup codes. Simply insert batteries to begin use.

2. Safety Information

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if the remote control will not be used for an extended period.
- Keep the remote control away from direct sunlight, heat sources, and moisture.
- Avoid dropping or subjecting the remote control to strong impacts.

3. Package Contents

- 1 x RemotesReplaced Remote Control for TELEFUNKEN HD87532B8

4. Product Overview

The RemotesReplaced remote control is designed to replicate the full functionality of your original TELEFUNKEN HD87532B8 remote. It features a standard layout for intuitive operation.





Figure 1: Front view of the remote control, displaying the power button, channel and volume controls, number pad, and various function buttons including TV, SAT, DVD, AUX, Menu, Exit, Source, Guide, Info, EPG, FAV, NET TV, and Smart TV controls.

Button Functions

- **POWER:** Turns the device on or off.
- **MUTE:** Mutes or restores the audio.
- **TV/SAT/DVD/AUX:** Selects the input source.
- **Number Buttons (0-9):** Direct channel selection.
- **MENU:** Accesses the main menu.
- **EXIT:** Exits the current menu or function.
- **SOURCE:** Cycles through available input sources.
- **GUIDE:** Displays the electronic program guide.
- **VOL +/-:** Adjusts the volume level.
- **CH P +/-:** Changes the channel.
- **OK:** Confirms selections in menus.
- **Navigation Arrows (Up/Down/Left/Right):** Navigates through menus and options.
- **BACK:** Returns to the previous screen or menu.
- **INFO:** Displays information about the current program.
- **EPG:** Accesses the Electronic Program Guide.
- **FAV:** Accesses favorite channels.
- **NET TV/SMART:** Accesses internet-connected features or smart TV functions.
- **Playback Controls (Rewind, Play/Pause, Fast Forward):** Controls media playback.



Figure 2: Side view of the remote control, highlighting its ergonomic design and the infrared emitter at the top, which transmits signals to the television.

5. Setup

Battery Installation

The remote control requires two AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

No code setup is required. The remote is ready for use immediately after battery installation.

6. Operating Instructions

Basic Operation

- Point the remote control directly at the infrared receiver on your TELEFUNKEN device.
- Press the desired button firmly.
- Ensure there are no obstructions between the remote control and the device.

Specific Functions

- **Changing Channels:** Use the number buttons for direct access or the **CH P +/-** buttons to cycle through channels.
- **Adjusting Volume:** Press the **VOL +/-** buttons.
- **Accessing Menus:** Press the **MENU** button to open the main menu. Use the navigation arrows and **OK** button to browse and select options. Press **EXIT** or **BACK** to leave the menu.
- **Selecting Input Source:** Press the **SOURCE** button or the dedicated **TV**/**SAT**/**DVD**/**AUX** buttons to switch between connected devices.
- **Smart TV Features:** If your TELEFUNKEN device supports it, press the **NET TV** or **SMART** button to access internet-connected applications and services.

7. Troubleshooting

Problem	Possible Cause	Solution
Remote control not working.	Dead or incorrectly inserted batteries.	Replace batteries with new AAA batteries, ensuring correct polarity.
Remote control has limited range or intermittent response.	Obstruction between remote and device; low battery power.	Ensure a clear line of sight to the device's infrared receiver. Replace batteries if necessary.
Specific functions not working.	Device may not support the function; remote not pointed correctly.	Verify your device's capabilities. Ensure the remote is pointed directly at the device.

8. Specifications

- **Model:** HD87532B8
- **Brand:** RemotesReplaced
- **Compatible Devices:** TELEFUNKEN Television (HD87532B8)
- **Dimensions:** 21 x 5 x 2 cm
- **Weight:** 120 g
- **Batteries Required:** 2 x AAA (not included)
- **Special Feature:** Universal replacement, no setup required

9. Warranty and Support

This RemotesReplaced remote control comes with a 1-year warranty, covering manufacturing defects. For warranty claims or technical support, please refer to your purchase documentation or contact the seller directly.

For further assistance, please visit the RemotesReplaced support website or contact their customer service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B076VF3DWP

More documents and user manuals: **https://manuals.plus/**