RemotesReplaced UPPLEVA

RemotesReplaced Remote Control Instruction Manual for IKEA UPPLEVA

Model: UPPLEVA | Brand: RemotesReplaced

1. Product Overview

This instruction manual provides essential information for the proper use and maintenance of your RemotesReplaced remote control, designed as a direct replacement for IKEA UPPLEVA televisions. This remote offers full functionality without requiring complex setup procedures.





Image 1.1: Front view of the RemotesReplaced remote control. This image displays the full layout of the remote, including the power button, mute, TV/SAT/DVD/AUX inputs, menu navigation, number pad, volume and channel controls, and various function buttons like SOURCE, GUIDE, BACK, SLEEP, INFO, EPG, FAV, NET TV, and SMART. The brand "RemotesReplaced" and model "RRS41" are visible at the bottom.



Image 1.2: Side view of the RemotesReplaced remote control. This image shows the remote from a slight angle, emphasizing its ergonomic design and the infrared (IR) emitter located at the top front, which transmits signals to the television.

2. Setup and Initial Use

The RemotesReplaced remote control is designed for immediate use with your IKEA UPPLEVA television. No programming or code entry is required.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

Once batteries are installed, the remote control is ready for operation.

3. Operating Instructions

This section details the functions of the various buttons on your remote control.

POWER: Turns the television on or off.

MUTE: Mutes or unmutes the television audio.

TV / **SAT** / **DVD** / **AUX:** Selects the corresponding input source on your television.

MENU: Accesses the main menu of the television.

EXIT: Exits the current menu or on-screen display.

SHIFT: May provide access to secondary functions of certain buttons (refer to your TV's manual if applicable).

Number Buttons (0-9): Used for direct channel selection or numerical input.

SOURCE: Cycles through available input sources.

GUIDE: Displays the electronic program guide (EPG).

-/--: Toggles between single and double-digit channel entry.

SUB: Activates or deactivates subtitles.

SIZE: Adjusts screen size or aspect ratio.

SETUP: Accesses setup or settings menu.

TEXT: Activates or deactivates teletext.

Volume (+V / -V): Increases or decreases the volume.

Channel (+P / -P): Changes the television channel up or down.

Navigation (Up, Down, Left, Right, OK): Used to navigate menus and confirm selections.

BACK: Returns to the previous screen or menu.

SLEEP: Sets a sleep timer for the television.

TV/DTV: Switches between analog and digital television modes.

INFO: Displays information about the current program or input.

EPG: Electronic Program Guide.

FAV: Accesses favorite channels list.

NET TV / SMART: Accesses smart TV features or internet-connected services (functionality depends on TV model).

Color Buttons (Red, Green, Yellow, Blue): Used for specific functions within menus or interactive services, as indicated

on-screen.

Playback Controls (Rewind, Play/Pause, Fast Forward): Controls media playback if the TV supports it or when controlling a connected device.

The remote control operates using infrared technology with a maximum range of approximately 10 meters. Ensure a clear line of sight between the remote's emitter and the television's IR receiver for optimal performance.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

To clean the remote control, wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

4.3 Storage

When not in use for extended periods, remove the batteries to prevent leakage, which can damage the remote. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

Problem	Possible Cause	Solution
Remote control is not responding.	• Dead or incorrectly inserted batteries. • Obstruction between remote and TV. • Remote is out of range.	• Check battery orientation; replace with new AAA batteries. • Ensure a clear line of sight to the TV's IR receiver. • Move closer to the television (within 10 meters).
Some buttons are not working.	• Worn-out buttons or internal contact issues. • Specific TV model may not support all functions.	• Replace batteries. • Consult your IKEA UPPLEVA TV manual for supported features. • If issue persists, contact support.
Remote works intermittently.	• Low battery power. • Interference from other electronic devices.	• Replace batteries. • Ensure no strong light sources or other IR devices are interfering.

6. Specifications

- **Brand:** RemotesReplaced
- **Model Name:** UPPLEVA
- **Connectivity Technology:** Infrared (IR)
- **Compatible Devices:** IKEA UPPLEVA Televisions
- **Controller Type:** Infrared
- **Maximum Range:** 10 Meters

- **Batteries Required:** 2 x AAA (not included)
- **Item Weight:** 120 Grams
- **Special Features:** Direct replacement, no programming required.

7. Warranty and Support

7.1 Warranty Information

This RemotesReplaced remote control comes with a 1-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures the availability of spare parts for a period of 1 year. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact your retailer or the RemotesReplaced customer service. Refer to the contact information provided with your purchase or visit the official RemotesReplaced website for support details.

© 2024 RemotesReplaced. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question