Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced B236A207TC

RemotesReplaced Compatible Remote Control for BLAUPUNKT B236A207TC

User Instruction Manual

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your RemotesReplaced compatible remote control, specifically designed for BLAUPUNKT B236A207TC televisions. This remote is a direct replacement, offering all functionalities of the original remote without requiring any complex setup or programming.
Key Features:

- Direct replacement for the original remote control.
- No installation codes required; simply insert batteries and begin use.
- Accesses all functions of your BLAUPUNKT B236A207TC television.
- Designed specifically for this brand/model, not a generic universal remote.

Package Contents

Upon opening the package, please ensure all items are present and in good condition:

- 1 x RemotesReplaced Compatible Remote Control (Model B236A207TC)
- (Batteries are not included and must be purchased separately)

Product Overview

Familiarize yourself with the layout and functions of your new remote control.




MENU
EXIT
SHIFT
1
2
3
4
5
6
7
8
9
SOURCE
0
-/--
GUIDE
SUB
SIZE
SETUP
TEXT
V
P
OK
V
P
BACK
SLEEP
TV/DTV
INFO
EPG
FAV
NET TV
II
SMART
RemotesReplaced
RRS41

Image 1: Front View of Remote Control. This image displays the full front panel of the RemotesReplaced remote control. Key buttons visible include POWER, MUTE, TV, SAT, DVD, AUX, MENU, EXIT, SHIFT, numerical keys (0-9), SOURCE, GUIDE, SUB, SIZE, SETUP, TEXT, volume and channel controls, navigation pad with OK button, BACK, SLEEP, TV/DTV, INFO, EPG, FAV, NET TV, play/pause/stop/fast forward/rewind, and SMART buttons. The brand "RemotesReplaced" and model "RRS41" are printed at the bottom.



Image 2: Side View of Remote Control. This image shows the remote control from a side angle, highlighting its ergonomic design and slim profile. The infrared emitter, which sends signals to the television, is visible at the front end of the remote.

Button Functions:

Button	Function
POWER	Turns the television on or off.
MUTE	Mutes or unmutes the television sound.
TV/SAT/DVD/AUX	Selects the input source (Television, Satellite, DVD, Auxiliary).
MENU	Opens the television's main menu.
EXIT	Exits the current menu or on-screen display.
SHIFT	Activates secondary functions of certain buttons (if applicable).
0-9	Direct channel selection and numerical input.
SOURCE	Cycles through available input sources.
GUIDE	Displays the electronic program guide.
SUB	Activates or deactivates subtitles.
SIZE	Adjusts the screen aspect ratio or picture size.
SETUP	Accesses setup or settings menu.
TEXT	Activates or deactivates Teletext.
Volume (+V / -V)	Increases or decreases the volume.
Channel (+P / -P)	Changes the television channel up or down.
Navigation Pad (Up, Down, Left, Right, OK)	Navigates through menus and confirms selections.
BACK	Returns to the previous menu or screen.
SLEEP	Sets a sleep timer for the television.

Button	Function
TV/DTV	Switches between analog TV and digital TV modes.
INFO	Displays information about the current program or input.
EPG	Accesses the Electronic Program Guide.
FAV	Accesses favorite channels list.
NET TV / SMART	Accesses smart TV features or internet-connected services.
Color Buttons (Red, Green, Yellow, Blue)	Context-sensitive functions within menus or applications.
Media Control (Rewind, Play/Pause, Fast Forward)	Controls media playback (e.g., on a connected DVD player or smart TV app).

Setup

Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into place until it clicks securely.

Note: This remote control does not require any programming or code entry. Once batteries are installed, it is ready for immediate use with your BLAUPUNKT B236A207TC television.

Operating Instructions

This remote control is designed to function identically to your original BLAUPUNKT B236A207TC television remote. Simply point the remote control towards your television and press the desired button.

Basic Functions:

- **Power On/Off:** Press the **POWER** button.
- **Volume Control:** Use the **+V** and **-V** buttons.
- **Channel Change:** Use the **+P** and **-P** buttons, or enter channel numbers directly using the **0-9** numerical keys.
- **Input Source:** Press the **SOURCE** button to cycle through inputs (HDMI, AV, etc.) or use dedicated **TV/SAT/DVD/AUX** buttons if available.

Advanced Functions:

- **Menu Navigation:** Use the **MENU** button to open the main menu. Navigate using the **Navigation Pad** (Up, Down, Left, Right) and confirm selections with **OK**. Use **EXIT** or **BACK** to return.
- **Smart TV Features:** Press the **NET TV** or **SMART** button to access your television's internet-connected applications and services.
- **Media Playback:** Use the dedicated media control buttons (Rewind, Play/Pause, Fast Forward) when watching content from a connected device or a smart TV app.

Maintenance

Cleaning:

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's finish or internal components.

Battery Replacement:

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.
Dispose of used batteries according to local regulations.

Troubleshooting

Problem	Possible Cause	Solution
Remote not working.	Dead or incorrectly inserted batteries.	Replace batteries with new AAA batteries, ensuring correct polarity (+/-).
Remote works intermittently.	Low battery power; obstruction between remote and TV; remote sensor on TV is blocked.	Replace batteries. Ensure a clear line of sight to the TV's infrared sensor. Remove any obstructions.
Certain buttons do not respond.	Button malfunction; TV not supporting the specific function.	Test other buttons. If only specific buttons fail, contact support. Ensure your TV model supports the function (e.g., Smart TV features).
Remote does not control other devices (e.g., DVD player).	This remote is specifically for BLAUPUNKT B236A207TC TV.	This remote is not a universal remote and is designed only for the specified TV model.

Specifications

- **Brand:** RemotesReplaced
- **Model Number:** B236A207TC
- **Compatible Devices:** BLAUPUNKT B236A207TC Television
- **Connectivity Technology:** Infrared (IR)
- **Power Source:** 2 x AAA Batteries (not included)
- **Item Weight:** Approximately 120 Grams

Warranty and Support

This RemotesReplaced compatible remote control comes with a**1-year warranty** from the date of purchase, covering manufacturing defects.
For technical support, warranty claims, or further assistance, please contact your retailer or the manufacturer directly. Please have your purchase receipt and product model number (B236A207TC) available when contacting support.

For more information, you may visit the RemotesReplaced brand page.

© 2023 RemotesReplaced. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B076VK48ZR

More documents and user manuals: **https://manuals.plus/**