RemotesReplaced Q1390

RemotesReplaced Remote Control for QILIVE Q1390

User Manual

1. Product Overview

This document provides comprehensive instructions for the RemotesReplaced Q1390 replacement remote control. This remote is specifically designed to function as a direct replacement for the original QILIVE Q1390 television remote control, offering access to all original functions without the need for complex programming.

Key Features:

- Direct replacement for the original QILIVE Q1390 remote control.
- No setup codes required; ready for use immediately after battery insertion.
- Provides access to all functions of the original remote.
- Designed specifically for QILIVE Q1390 televisions.

2. Setup

2.1 Battery Installation

The remote control requires two (2) AAA batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Once batteries are installed, the remote control is ready for immediate use with your QILIVE Q1390 television. No additional programming or setup codes are required.



Figure 1: Side view of the remote control, illustrating the battery compartment area and the infrared emitter.

3. Operating Instructions

This section details the functions of the buttons on your RemotesReplaced Q1390 remote control. Refer to the image below for a visual guide to button placement.





Figure 2: Front view of the RemotesReplaced Q1390 remote control with all buttons labeled.

3.1 Power and Basic Controls

- **POWER (Red Button):** Turns the television on or off.
- **MUTE:** Mutes or unmutes the television audio.
- **0-9 (Number Buttons):** Directly select channels.
- **V+** / **V- (Volume Up/Down):** Adjusts the audio volume level.
- **P+** / **P- (Channel Up/Down):** Changes the television channel.
- **SOURCE:** Cycles through available input sources (e.g., HDMI 1, HDMI 2, AV).

3.2 Navigation and Menu Functions

- **MENU:** Opens the television's main menu.
- **EXIT:** Closes the current menu or on-screen display.
- **Arrow Buttons (Up, Down, Left, Right):** Navigate through menus and options.
- **OK:** Confirms a selection or enters a submenu.
- **BACK:** Returns to the previous menu or screen.

3.3 Input Selection and Special Functions

- **TV** / **SAT** / **DVD** / **AUX:** Selects specific input modes for connected devices.

- **SHIFT:** May activate secondary functions for certain buttons (refer to your TV's manual for specific uses).
- **-/--:** Toggles between single and double-digit channel entry.
- **GUIDE** / **EPG:** Displays the Electronic Program Guide.
- **INFO:** Shows information about the current program or input.
- **TEXT:** Activates or deactivates Teletext.
- **SUB:** Toggles subtitles on or off.
- **SIZE:** Adjusts the screen aspect ratio.
- **SETUP:** Accesses setup or settings menus.
- **SLEEP:** Sets a sleep timer for the television.
- **TV/DTV:** Switches between analog TV and digital TV modes.
- **FAV:** Accesses favorite channels list.
- **NET TV** / **SMART:** Accesses Smart TV features or internet-connected applications.

3.4 Media Playback Controls

- **Red, Green, Yellow, Blue Buttons:** Often used for specific functions within menus or interactive services (e.g., Teletext, Smart TV apps).
- **Rewind (Double Left Arrow):** Rewinds media playback.
- **Play/Pause (Two Vertical Bars):** Plays or pauses media playback.
- **Fast Forward (Double Right Arrow):** Fast forwards media playback.
- **Stop (Square):** Stops media playback.

4. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Avoid using liquid cleaners, aerosols, or abrasive materials, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries promptly when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** Store the remote control in a cool, dry place, away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal circuitry.

5. Troubleshooting

If you experience issues with your RemotesReplaced Q1390 remote control, please refer to the following common solutions:

- **Remote Not Responding:**
  - Ensure batteries are correctly inserted with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the television's infrared receiver.
  - Ensure you are within the effective operating range (up to 10 meters) and pointing the remote directly at the TV.

- **Specific Functions Not Working:**
  - Verify that the television is powered on and not in standby mode.
  - If using input selection buttons (TV, SAT, DVD, AUX), ensure the correct input mode is selected for the device you are trying to control.
  - Some advanced functions may require specific settings on your QILIVE Q1390 television; consult your TV's original user manual if necessary.
- **Interference:**
  - Bright light sources, especially fluorescent lights or direct sunlight, can sometimes interfere with infrared signals. Try operating the remote in different lighting conditions.

6. Specifications

Brand	RemotesReplaced
Model	Q1390
Compatibility	QILIVE Q1390 Televisions
Dimensions (L x W x H)	21 x 5 x 2 cm
Weight	120 g
Batteries Required	2 x AAA (not included)
Connectivity Technology	Infrared (IR)
Maximum Operating Range	10 meters

7. Warranty and Support

7.1 Warranty Information

This RemotesReplaced remote control comes with a **1-year guarantee** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or battery leakage.

7.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact the seller or manufacturer directly through your purchase platform. Please have your purchase details and product model number (Q1390) available when contacting support.

© 2023 RemotesReplaced. All rights reserved.