Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced T40FX275DLBP

RemotesReplaced Remote Control Instruction Manual

For Telefunken T40FX275DLBP Television

Introduction

This manual provides detailed instructions for the RemotesReplaced replacement remote control, specifically designed for the Telefunken T40FX275DLBP television. This remote is a direct replacement, offering all original functions without the need for complex setup codes. Simply insert batteries, and it is ready for use.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.



Figure 1: Side view of the remote control, illustrating the battery compartment area.

The remote control is now ready for immediate use with your Telefunken T40FX275DLBP television. No programming or pairing is required.

Operating Instructions

General Use

Point the remote control directly at your Telefunken T40FX275DLBP television. Ensure there are no obstructions between the remote and the TV's infrared receiver. Press the desired button to perform the corresponding function.

Button Functions





Figure 2: Front view of the RemotesReplaced remote control with button layout.

- **POWER:** Turns the television on or off.
- **MUTE:** Mutes or unmutes the television sound.
- **TV** / **SAT** / **DVD** / **AUX:**Selects the input source for TV, Satellite, DVD, or Auxiliary devices.
- **MENU:** Accesses the main menu of the television.
- **EXIT:** Exits the current menu or on-screen display.
- **SHIFT:** May provide access to secondary functions for certain buttons (refer to TV manual).
- **Number Buttons (0-9):** Directly selects channels or enters numerical values.
- **SOURCE:** Cycles through available input sources.
- **-/-:** Toggles between single and double-digit channel entry.
- **GUIDE:** Displays the electronic program guide (EPG).
- **SUB:** Activates or deactivates subtitles.
- **SIZE:** Adjusts the screen display size or aspect ratio.
- **SETUP:** Accesses setup or settings menu.
- **TEXT:** Activates or deactivates Teletext.
- **V+** / **V-:** Increases or decreases the volume level.
- **P+** / **P-:** Changes to the next or previous channel.
- **Navigation Arrows (Up, Down, Left, Right):** Navigates through menus and options.
- **OK:** Confirms a selection or enters a menu item.
- **BACK:** Returns to the previous screen or menu.
- **SLEEP:** Sets a sleep timer for the television.
- **TV/DTV:** Switches between analog and digital TV modes.
- **INFO:** Displays information about the current program or input.
- **EPG:** Accesses the Electronic Program Guide.
- **FAV:** Accesses favorite channels list.
- **NET TV (Red):** Accesses network-connected TV features or smart TV applications.
- **Colored Buttons (Green, Yellow, Blue):** Multi-functional buttons, often used for specific features within menus or smart TV apps.
- **Playback Controls (Rewind, Play, Fast Forward, Stop):** Controls media playback on compatible devices or within TV applications.
- **SMART:** Direct access to Smart TV features or applications.

Specifications

- **Brand:** RemotesReplaced
- **Model:** T40FX275DLBP
- **Compatible Devices:** Telefunken T40FX275DLBP Television
- **Connectivity Technology:** Infrared (IR)
- **Maximum Operating Range:** Approximately 10 meters (33 feet)
- **Battery Requirement:** 2 x AAA batteries (not included)
- **Item Weight:** Approximately 120 grams
- **Setup:** No programming or codes required; ready to use upon battery insertion.
- **Functionality:** Provides access to all functions of the original Telefunken T40FX275DLBP remote control.

Troubleshooting

- **Remote not responding:**
  - Ensure fresh AAA batteries are correctly installed with proper polarity.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Verify that you are pointing the remote directly at the TV.
- **Some functions not working:**
  - Ensure the TV is powered on and not in a standby mode that restricts certain commands.
  - Confirm the correct input source (e.g., TV, DVD) is selected on the television.
  - Some advanced TV features may require specific menu navigation that is not a direct button press.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

Warranty and Support

This RemotesReplaced remote control comes with a 1-year warranty, covering manufacturing defects from the date of purchase.

For warranty claims, technical support, or further assistance, please contact your retailer or the manufacturer, RemotesReplaced, through their official support channels. Please have your purchase details and product model number (T40FX275DLBP) available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B076VNB3ZW

More documents and user manuals: **https://manuals.plus/**