VQ 10070

VQ Monty Portable DAB Radio User Manual

Model: 10070
Brand: VQ

1. Introduction

Thank you for purchasing the VQ Monty Portable DAB Radio. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference. The VQ Monty combines classic design with modern functionality, offering DAB/DAB+ and FM radio, Bluetooth connectivity, and alarm clock features.





Figure 1.1: The VQ Monty Portable DAB Radio, showcasing its walnut wooden casing and front panel display.

2. Safety Information

- Do not expose the unit to rain or moisture to prevent fire or electric shock.
- Do not expose the unit to direct sunlight, heat sources, or extreme temperatures.
- Ensure proper ventilation; do not block ventilation openings.
- Use only the power adapter supplied with the unit.
- Do not attempt to disassemble or modify the unit. Refer all servicing to qualified personnel.
- Keep the unit away from strong magnetic fields.
- If a rechargeable battery is installed, ensure it is correctly inserted and charged according to instructions.

3. Package Contents

Please check that all items are present:

- VQ Monty Portable DAB Radio
- Power Adapter
- Owner's Manual (this document)

Note: A rechargeable battery is required for portable use but is not included in the package.

4. Product Features and Controls



Figure 4.1: Detail of the VQ Monty's premium PU leather handle and real wood casing, highlighting the quality materials.

4.1 Front Panel

- **LCD Display:** 2.4-inch screen for displaying station information, time, and menu options.
- **Control Buttons:** Play/Pause, Mode, Menu, OK, Navigation (Up/Down/Left/Right).
- **Speaker:** Integrated 10-watt full-range speaker for audio output.



Figure 4.2: Internal speaker components of the VQ Monty, illustrating the 10-watt driver, ultra-wide cone, and full-range speaker design for balanced acoustics.

4.2 Rear Panel and Connections

- **Power Input:** For connecting the supplied power adapter.
- **USB Charge Port:** For charging external devices (e.g., smartphones, tablets).
- **3.5mm Aux-in Port:** For connecting external audio sources.
- **Headphone Jack:** For private listening.
- **Telescopic Antenna:** For DAB/DAB+ and FM radio reception.
- **Battery Compartment:** For optional rechargeable battery (not included).



Figure 4.3: The rear panel of the VQ Monty, detailing the headphone jack, 3.5mm Aux-in port, and USB charging port for versatile connectivity.

5. Setup

5.1 Powering On

1. Connect the supplied power adapter to the DC input port on the rear of the radio.
2. Plug the power adapter into a wall socket.
3. Press the **Power** button on the front panel to turn on the radio.

5.2 Initial Setup (First Use)

Upon first power-on, the radio will automatically perform a full scan for DAB/DAB+ stations and set the time and date.

1. Extend the telescopic antenna fully for optimal reception.
2. The radio will display "Scanning..." and begin searching for available DAB/DAB+ stations.
3. Once the scan is complete, the radio will automatically set the time and date and tune to the first available station.

5.3 Battery Installation (Optional)

For portable use, a compatible rechargeable Lithium Ion battery (not included) can be installed.

1. Ensure the radio is powered off and disconnected from the mains.
2. Locate the battery compartment on the rear of the unit.
3. Open the compartment cover.
4. Insert the compatible Lithium Ion battery, observing correct polarity.
5. Close the battery compartment cover securely.
6. The battery will charge when the radio is connected to mains power.



Figure 5.1: The VQ Monty radio positioned outdoors next to a hot tub, illustrating its portable design for use in various environments.

6. Operating Instructions

6.1 Switching Modes

Press the **MODE** button to cycle through available modes: DAB Radio, FM Radio, Bluetooth, and Aux-in.

6.2 DAB/DAB+ Radio Operation

1. Ensure the radio is in DAB mode. If not, press **MODE** until "DAB" is displayed.
2. Use the **Up**/**Down** navigation buttons to browse available stations.
3. Press **OK** to select a station.
4. To perform a full scan, press **MENU**, navigate to "Full Scan", and press **OK**.
5. To save a preset: Tune to the desired station, press and hold **MENU**, select "Save Preset", choose a preset number (1-60), and press **OK**.
6. To recall a preset: Press **MENU**, select "Recall Preset", choose the desired preset number, and press **OK**.

6.3 FM Radio Operation

1. Press **MODE** until "FM" is displayed.
2. To auto-scan for the next available station, press and hold the **Up**/**Down** navigation buttons.
3. To manually tune, briefly press the **Up**/**Down** navigation buttons.
4. Saving and recalling presets works similarly to DAB mode.

6.4 Bluetooth Mode

1. Press **MODE** until "Bluetooth" is displayed. The radio will enter pairing mode.
2. On your Bluetooth-enabled device (smartphone, tablet), enable Bluetooth and search for "VQ Monty".
3. Select "VQ Monty" to pair. Once connected, the radio will confirm the connection.
4. You can now stream audio from your device to the VQ Monty.



Figure 6.1: The VQ Monty radio displaying the Bluetooth logo, signifying its capability to connect wirelessly with compatible devices for audio streaming.

6.5 Aux-in Mode

1. Press **MODE** until "Aux-in" is displayed.
2. Connect your external audio device (e.g., MP3 player) to the 3.5mm Aux-in port on the rear of the radio using a 3.5mm audio cable (not included).
3. Audio from your external device will now play through the VQ Monty.

6.6 Alarm Clock Functions

The VQ Monty features dual alarms with week and weekend settings, snooze, sleep, and countdown functions.

1. To set an alarm: Press **MENU**, navigate to "System Settings" > "Alarm", and select Alarm 1 or Alarm 2.
2. Follow the on-screen prompts to set the alarm time, source (DAB, FM, Buzzer), frequency (Daily, Weekdays, Weekends, Once), and volume.
3. To activate snooze: When an alarm sounds, press any button (except Power) to activate snooze.

4. To stop an alarm: Press the **Power** button.



Figure 6.2: The VQ Monty radio positioned on a bedside table, demonstrating its suitability as an alarm clock and bedside companion.

6.7 USB Charging

The USB port on the rear of the VQ Monty can be used to charge compatible external devices.

1. Connect your device's USB charging cable to the USB port on the VQ Monty.
2. Ensure the VQ Monty is connected to mains power for charging functionality.

6.8 Headphone Use

For private listening, connect standard 3.5mm headphones to the headphone jack on the rear of the unit. The internal speaker will automatically mute.

7. Maintenance

- **Cleaning:** Wipe the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Antenna:** Handle the telescopic antenna with care to avoid damage.
- **Storage:** If storing for an extended period, disconnect from power and remove any installed rechargeable battery. Store in a cool, dry place.

8. Troubleshooting

Problem	Possible Cause	Solution
No power	Power adapter not connected or faulty.	Check power connections. Ensure adapter is securely plugged in.
Poor radio reception	Antenna not extended or poor signal area.	Fully extend the telescopic antenna. Try repositioning the radio. Perform a full scan.
Bluetooth not connecting	Radio not in Bluetooth mode or device not discoverable.	Ensure radio is in Bluetooth mode. Make sure your device's Bluetooth is on and discoverable. Try unpairing and re-pairing.
No sound from Aux-in	Cable not connected or external device volume low.	Ensure Aux-in cable is fully inserted. Check volume on both the radio and the external device.
Display too bright at night	Display brightness setting is high.	Navigate to System Settings > Backlight and adjust the brightness level.

9. Specifications

Model:	10070 (Monty)
Tuner:	DAB/DAB+, FM
Connectivity:	Bluetooth, 3.5mm Aux-in, USB (charging only)
Speaker Output:	10 Watts
Display:	2.4-inch LCD
Power Source:	Mains (230V) or optional rechargeable Lithium Ion battery
Dimensions (L x W x H):	13.4L x 9.8W x 18.4H cm (approx.)
Weight:	1.4 kg
Material:	Real Wood (Walnut finish)



Figure 9.1: Dimensional overview of the VQ Monty radio, providing approximate measurements for height, length, and width.

10. Warranty and Support

The VQ Monty Portable DAB Radio comes with a standard warranty. An extended **three-year warranty** is available upon product registration.

- **Product Registration:** To register your product and activate the extended warranty, please visit the official VQ website.
- **Customer Support:** For technical assistance, troubleshooting, or warranty claims, please contact VQ customer support through their official website or the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question