Simac SC7214190

Simac Bravo Food Processor Bowl Instruction Manual

Model: SC7214190

1. Overview

This instruction manual provides essential information for the safe and effective use of your Simac Bravo Food Processor Replacement Bowl. This bowl is designed as a direct replacement part for various Simac Bravo food processor models.

Compatible Models:

- Bravo Simac 1S
- Bravo Simac 2S
- Bravo Simac 400 Electronic
- Bravo Simac 410 Electronic
- Bravo Simac 420 Electronic
- Bravo Simac 430 Electronic

Before installation and use, please read these instructions thoroughly and retain them for future reference.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances, especially when handling replacement parts. Failure to do so may result in injury or damage to the appliance.

- Ensure the food processor is unplugged from the power outlet before installing or removing the bowl.
- Do not operate the food processor with a damaged bowl. Inspect the bowl for cracks or damage before each use.
- Keep hands and utensils away from moving blades during operation.
- Do not overfill the bowl. Refer to the maximum fill lines indicated on the bowl.
- This bowl is designed for use with specified Simac Bravo food processors only. Do not attempt to use it with other appliances.
- Always ensure the bowl is securely locked into place on the motor base before operating the

appliance.

3. Package Contents

Upon opening the package, verify that all components are present and undamaged.

- 1 x Simac Bravo Food Processor Replacement Bowl (Model SC7214190)

Note: Lids, blades, and other accessories are typically sold separately and are not included with the replacement bowl.

4. Setup and Installation

Follow these steps to correctly install the replacement bowl onto your Simac Bravo food processor.

1. **Unplug the Appliance:** Ensure your Simac Bravo food processor is unplugged from the electrical outlet before beginning installation.
2. **Remove Old Bowl (if applicable):** If replacing an existing bowl, carefully remove it from the motor base.
3. **Position the New Bowl:** Place the new Simac Bravo replacement bowl onto the motor base of your food processor. Align the bottom of the bowl with the locking mechanism on the base.
4. **Lock into Place:** Rotate the bowl clockwise until it clicks securely into position. The handle of the bowl should typically align with the front or side of the motor base, depending on your specific model. Ensure it is firmly seated and does not wobble.
5. **Attach Accessories:** Once the bowl is installed, you can attach the appropriate blade assembly and lid (sold separately) according to your food processor's original instructions.



Image 1: Side view of the Simac Bravo Food Processor Bowl, showing the handle and base. This view helps in understanding how to align the bowl for installation.

5. Operating Instructions

This replacement bowl functions identically to the original bowl provided with your Simac Bravo food processor. Refer to your food processor's main instruction manual for detailed operating procedures, including specific functions, speed settings, and processing times for various ingredients.

General Usage Guidelines:

- Always ensure the bowl, blade, and lid are correctly assembled and locked before turning on the appliance.
- Do not exceed the maximum fill lines marked on the bowl. Overfilling can lead to inefficient processing, spills, or damage to the appliance.
- Use the appropriate blade or disc for the task (e.g., chopping, slicing, shredding).
- Process ingredients in batches if necessary to avoid overloading the motor.



Image 2: Top-down view of the Simac Bravo Food Processor Bowl, illustrating the measurement markings for cups, ounces, and liters. Observe the 'DO NOT FILL ABOVE THIS LEVEL' indicator.

6. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your replacement bowl and ensure hygienic food preparation.

- **Before Cleaning:** Always unplug the food processor from the power outlet. Remove the bowl, lid, and blade assembly.
- **Hand Washing:** Wash the bowl in warm, soapy water using a soft sponge or cloth. Rinse thoroughly and dry immediately to prevent water spots.
- **Dishwasher Safe:** The bowl is generally dishwasher safe. Place it on the top rack to avoid potential damage from heating elements. Avoid using abrasive cleaners or scouring pads, as these can scratch the plastic.
- **Drying and Storage:** Ensure the bowl is completely dry before storing. Store in a clean, dry place, preferably with the lid (if applicable) loosely placed to allow air circulation.
- **Stains:** For stubborn food stains, a paste of baking soda and water can be applied and left for a short

period before washing.

7. Troubleshooting

If you encounter issues with your replacement bowl, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bowl does not fit or lock onto the base.	Incorrect alignment; debris in locking mechanism; incompatible model.	Ensure the bowl is correctly aligned and rotated until it clicks. Check for any food debris. Verify your food processor model is listed as compatible.
Bowl leaks during operation.	Bowl not properly seated; lid not sealed; overfilling.	Ensure the bowl is securely locked. Check that the lid is correctly placed and sealed. Do not exceed the maximum fill line.
Food processor does not start with the new bowl.	Bowl or lid not correctly assembled; safety interlock not engaged.	Ensure both the bowl and the lid are fully locked into their operating positions. Most food processors have safety interlocks that prevent operation if components are not correctly assembled.

If the problem persists after attempting these solutions, please contact customer support.

8. Specifications

- **Product Type:** Replacement Food Processor Bowl
- **Brand:** Simac (Manufactured by De'Longhi)
- **Model Number:** SC7214190
- **Material:** Food-grade plastic
- **Compatibility:** Simac Bravo 1S, 2S, 400, 410, 420, 430 Electronic models
- **Automatic Shut-off:** Not applicable (component part)
- **First Available Date:** 22 November 2017

9. Warranty and Support

This Simac Bravo Food Processor Bowl (Model SC7214190) is covered by a manufacturer's warranty against defects in materials and workmanship. The specific terms and duration of the warranty may vary by region and retailer.

For warranty claims, technical assistance, or to purchase additional accessories, please contact the retailer where the product was purchased or visit the official De'Longhi (Simac) customer support website. Please have your proof of purchase and the model number (SC7214190) ready when contacting support.

Manufacturer: De'Longhi

Customer Support: Refer to your original food processor manual or the De'Longhi official website for contact information.

© 2026 Simac / De'Longhi. All rights reserved. This manual is for informational purposes only.