Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Holiday Living 10.5-ft Lighted Snowman Christmas Inflatable

Holiday Living 10.5-ft Lighted Snowman Christmas Inflatable Instruction Manual

Model: 10.5-ft Lighted Snowman Christmas Inflatable
Brand: Holiday Living

Introduction

This instruction manual provides essential information for the safe and proper setup, operation, maintenance, and storage of your Holiday Living 10.5-ft Lighted Snowman Christmas Inflatable. Please read all instructions carefully before assembly and use to ensure optimal performance and safety.

Important Safety Information

- This product is intended for seasonal outdoor use. Do not use it for purposes other than its intended design.
- Always unplug the inflatable from the power source when not in use or during strong winds and storms.
- Ensure all electrical connections are dry and protected from moisture. Use a Ground Fault Circuit Interrupter (GFCI) outlet for outdoor use.
- Do not operate the inflatable if the power cord, fan motor, or lights are damaged. Contact customer support for assistance.
- Keep the inflatable away from heat sources, open flames, and sharp objects to prevent damage.
- Securely anchor the inflatable using the provided stakes and tethers to prevent it from blowing away.
- Keep children and pets away from the inflatable during inflation and deflation to prevent entanglement.

Package Contents

Verify that all components are present before beginning assembly:

- 1 x 10.5-ft Lighted Snowman Christmas Inflatable
- 1 x Built-in Fan Motor
- Yard Stakes

- Tether Ropes

Setup Instructions

1. **Unpack the Inflatable:** Carefully remove the inflatable and all accessories from the packaging. Lay the inflatable flat on a clean, dry surface, ensuring there are no obstructions around the fan motor intake.
2. **Position the Inflatable:** Choose a suitable outdoor location that is flat, clear of debris, and away from any structures or objects that could obstruct the inflatable or pose a fire hazard.
3. **Secure the Inflatable:** Once positioned, use the provided yard stakes to anchor the base of the inflatable to the ground. Attach the tether ropes to the designated loops on the inflatable and secure them to additional stakes in the ground, pulling taut to provide stability.
4. **Inflate the Snowman:** Plug the power cord into a standard 110V outdoor electrical outlet. The built-in fan motor will begin to inflate the snowman automatically. Ensure the fan motor is clear of any fabric or obstructions during inflation.



Image: The Holiday Living 10.5-ft Lighted Snowman Christmas Inflatable fully inflated, showcasing its design and internal lighting.



Image: The Holiday Living 10.5-ft Lighted Snowman Christmas Inflatable displayed in a snowy outdoor setting in front of a house, demonstrating its scale and visual impact.

Operating Instructions

To operate your inflatable, simply plug it into a 110V electrical outlet. The internal fan will activate, inflating the snowman. The internal lights will also illuminate, providing nighttime display. To deflate, unplug the unit from the power source. The inflatable will slowly deflate on its own.

Maintenance and Storage

- **Cleaning:** If the inflatable becomes dirty, wipe it gently with a damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the inflatable is completely dry before storing.
- **Inspection:** Periodically inspect the inflatable, power cord, and fan motor for any signs of wear or damage. Address any issues promptly to ensure safe operation.
- **Storage:** Before storing, ensure the inflatable is completely deflated and dry. Fold it neatly and store it in its original packaging or a suitable storage bag in a cool, dry place, away from direct sunlight and pests.

Troubleshooting

Problem	Possible Cause	Solution
Inflatable does not inflate	Not plugged in; Power outage; Fan motor obstructed; Zipper open	Ensure power cord is securely plugged in; Check power source; Clear any obstructions from fan intake; Ensure all zippers/openings are closed.
Inflatable does not stand upright	Insufficient air; Not properly secured; Strong winds	Check for tears or openings; Ensure fan is running continuously; Re-position and re-secure stakes and tethers; Deflate during strong winds.
Lights are not working	Bulb failure; Loose connection	Check if the unit is powered; Inspect light connections; Contact customer support if lights are integrated and non-replaceable.

Product Specifications

- **Inflated Height:** 10.5 feet
- **Inflated Width:** 4.69 feet
- **Inflated Depth:** 7.22 feet
- **Material:** Fabric
- **Special Feature:** Internally Lighted
- **Power Source:** 110V AC Outlet
- **Item Weight:** Approximately 10.08 pounds
- **Manufacturer:** Gemmy
- **UPC:** 086786152478

Warranty and Customer Support

For warranty information or assistance with your Holiday Living 10.5-ft Lighted Snowman Christmas Inflatable, please refer to the warranty card included with your purchase or contact the manufacturer, Gemmy, directly. Keep your purchase receipt as proof of purchase.
For further support or inquiries, please visit the Holiday Living official website or contact their customer service department.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B076ZTRW2Z

More documents and user manuals: **https://manuals.plus/**