Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Capstone 4336302871

Capstone LED Indoor/Outdoor Motion Sensor Lights (Pack of 3)

Model: 4336302871

Introduction

Thank you for choosing the Capstone LED Indoor/Outdoor Motion Sensor Lights. This manual provides essential information for the safe and efficient operation of your new lighting system. Please read these instructions thoroughly before installation and use, and retain them for future reference.

Product Features

- **Waterproof Design:** Suitable for both indoor and outdoor environments.
- **Dusk-to-Dawn Functionality:** Automatically activates a low-level guide light at dusk and turns off at dawn.
- **Motion Activation:** Bright light activates when motion is detected, enhancing visibility and security.
- **Battery Powered:** No wiring required for installation, offering flexible placement options.
- **Easy Installation:** Includes mounting hardware for quick setup.
- **Energy Efficient:** LED technology ensures long battery life.

Package Contents

- 3 x Capstone LED Motion Sensor Lights
- 9 x AA Batteries (3 per light, pre-installed)
- Mounting Hardware (screws and anchors)
- Instruction Manual

Setup and Installation

Follow these steps to properly set up and install your motion sensor lights.

1. Battery Installation/Verification

The lights come with 3 AA batteries pre-installed in each unit. To access the battery compartment:

1. Locate the battery compartment cover on the back of the light unit.

2. Use a small screwdriver or your thumbnail to turn the lock screw counter-clockwise to open.
3. Ensure the 3 AA batteries are correctly inserted, matching the polarity indicators (+/-).
4. Replace the cover and turn the lock screw clockwise to secure it.



Image 1: Packaging showing the three Capstone LED Motion Sensor Lights and included AA batteries. This image illustrates the product as it appears in its retail packaging, highlighting the quantity and power source.

2. Selecting a Mounting Location

Choose a location that provides optimal motion detection and light coverage. Consider areas such as:

- Entrances (doors, gates)
- Staircases or steps
- Walkways, driveways, or patios
- Garages or sheds
- Any indoor or outdoor area requiring temporary illumination.

Ensure the chosen location allows for clear detection of movement within the desired range and is free from obstructions that might block the sensor.

3. Mounting the Lights

The lights can be mounted using the included screws and anchors, or placed on a flat surface.

1. Hold the light unit against the desired mounting surface and mark the screw holes.
2. For drywall or masonry, drill pilot holes and insert the plastic anchors.
3. Align the light unit with the holes and secure it using the provided screws. Do not overtighten.
4. Alternatively, the flat base allows for freestanding placement on shelves, tables, or other flat surfaces.



Image 2: Rear view of the Capstone LED Motion Sensor Light packaging, detailing mounting instructions, dual mode lighting, and waterproof features. This image provides visual guidance for installation and understanding the product's capabilities.

Operating Instructions

Each light unit features a three-position switch to select the desired operating mode.

1. **OFF:** The light is completely off and will not activate. This mode is useful for storage or when light is not needed.
2. **Motion Sensor Only (MS):** In this mode, the light will remain off during daylight hours. At night, it will activate to full brightness only when motion is detected within its sensor range. After a period of no motion, the light will turn off.
3. **Dusk-to-Dawn (D2D/MS):** This mode provides a low-level guide light that automatically turns on at dusk and remains on throughout the night. When motion is detected, the light will temporarily switch to full brightness. After motion ceases, it will return to the low-level guide light. This mode is ideal for continuous ambient lighting with bright bursts when needed.

To change the operating mode, simply slide the switch located on the side of the light unit to your preferred setting.

Maintenance

- **Battery Replacement:** When the light output diminishes or the unit stops functioning, replace all three AA batteries with new alkaline batteries. Refer to the "Battery Installation/Verification" section for instructions.
- **Cleaning:** Wipe the light's surface with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or electronic components.
- **Sensor Cleaning:** Ensure the motion sensor lens is clean and free from dust or debris to maintain optimal performance.
- **Water Resistance:** While designed for outdoor use, ensure the battery compartment cover is always securely fastened to maintain its waterproof integrity.

Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	Batteries are dead or incorrectly installed. Switch is in the "OFF" position. Insufficient darkness (for motion sensor modes).	Replace batteries and check polarity. Slide switch to "MS" or "D2D/MS" mode. Test in a darker environment.
Light stays on continuously.	Constant motion detected. Light is in "D2D/MS" mode (low-level guide light).	Relocate the light to an area with less constant activity. This is normal operation for "D2D/MS" mode. If not desired, switch to "MS" mode.
Motion sensor is not detecting.	Sensor lens is dirty or obstructed. Light is too far from motion source. Ambient light is too bright.	Clean the sensor lens. Adjust placement for closer proximity to detection area. Ensure the environment is dark enough for sensor activation.

Specifications

- **Brand:** Capstone
- **Model Number:** 4336302871
- **Power Source:** Battery Powered
- **Battery Type:** 3 x AA Alkaline batteries per light (9 total, included)
- **Mounting Type:** Wall Mount / Freestanding
- **Product Dimensions:** 14 x 1 x 14 inches (per unit, approximate)
- **Item Weight:** 1.4 pounds (per unit, approximate)
- **Color:** White or Gray (as per product variation)
- **UPC:** 631052004236

Warranty Information

Capstone products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Capstone website. Keep your purchase receipt as proof of purchase for any warranty claims.

Customer Support

If you have any questions, require assistance, or need to report an issue with your Capstone LED Motion Sensor Lights, please contact Capstone customer support. Contact information can typically be found on the product packaging or the official Capstone website.
For general inquiries, you may also visit the Capstone Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0771V3LT8

More documents and user manuals: **https://manuals.plus/**