**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### Hasbro Gaming Speech Breaker

# Hasbro Gaming Speech Breaker Game

**INSTRUCTION MANUAL**

Model: E1844

## About the Game

The Hasbro Gaming Speech Breaker Game is an electronic party game designed to challenge communication skills through a unique voice-jamming mechanism. Players wear a headset and speak into a microphone, which introduces a delay in their own voice feedback. This delay makes it difficult to speak clearly, creating a humorous challenge as players attempt to describe scenes or phrases to their teammates without using specific words.
The game is suitable for 2 or more players, aged 14 and up. It aims to improve communication skills under challenging conditions, promote creative thinking, language development, perseverance, and adaptability.

## What's Included

- 1 Electronic Game Microphone with Headset
- 200 Game Cards
- 1 Card Box
- Instructions

## Setup

1. Remove all components from the packaging.
2. **Battery Installation:** Insert 1 AAA battery into the microphone and 3 AA batteries into the headset. Ensure correct polarity. Batteries are not included and must be purchased separately.
3. Connect the headset to the microphone.
4. Place the game headset comfortably on your head.




Image: The Speech Breaker microphone and headset, ready for battery installation and connection.

## Operating Instructions

The objective of the Speech Breaker Game is for one player to describe a scene or phrase from a card while wearing the voice-jamming headset, and their teammates must guess it within a 30-second time limit. The voice-jamming effect makes speaking challenging, leading to humorous miscommunications.

1. Form teams of 2 or more players.
2. The active player puts on the headset and holds the microphone.
3. Turn on the microphone using the on/off switch.

4. Draw a game card. The active player must describe the scene or phrase on the card to their teammates without using any of the words printed on the card.
5. As the player speaks into the microphone, their voice will be played back through the headset with a slight delay, creating the voice-jamming effect. This makes it difficult to articulate words clearly.
6. Teammates listen and try to guess the phrase.
7. The microphone has a built-in timer for the 30-second round.
8. If the team guesses correctly within the time limit, they earn a point.
9. Players take turns being the active speaker. The team with the most points at the end of the game wins.




Image: A player demonstrating the use of the Speech Breaker microphone and headset during gameplay.




Image: Close-up of a player using the Speech Breaker microphone and headset, illustrating the voice-jamming experience.

Your browser does not support the video tag.

Video: An official demonstration of the Speech Breaker Game, showcasing the voice-jamming challenge and player reactions.

## Care and Maintenance

- Keep the game components clean and dry. Wipe with a soft, dry cloth if necessary.
- Store the game in its original box or a suitable container to protect it from dust and damage.
- Remove batteries from the microphone and headset if the game will not be used for an extended period to prevent battery leakage.
- Do not expose electronic components to extreme temperatures or moisture.

## Troubleshooting

- **No Sound or Voice Jamming Effect:** Ensure batteries are correctly installed and not depleted. Check that the

headset is securely plugged into the microphone. Verify the on/off switch is in the 'on' position.

- **Sound is Too Loud:** The game does not feature a volume adjustment. If the sound is uncomfortably loud, consider using the headset slightly off the ears or taking breaks.
- **Inconsistent Voice Delay:** Ensure the microphone is held close to the mouth and spoken into directly. Environmental noise can sometimes interfere with the effect.
- **Game Not Turning On:** Replace batteries with fresh ones. Check battery compartment for any corrosion.

## Specifications

| | |
|---|---|
| **Brand** | Hasbro Gaming |
| **Model Name** | Speech Breaker |
| **Model Number** | E1844 |
| **Item Dimensions** | 2.5 x 10.5 x 10.5 inches |
| **Item Weight** | 1.1 Pounds |
| **Number of Players** | 2+ |
| **Age Range** | 14 years and up |
| **Power Source** | Battery-powered |
| **Battery Requirements** | 1 AAA battery (microphone), 3 AA batteries (headset) - *not included* |

## Safety Information

- **Battery Safety:** Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Insert batteries with correct polarity. Remove exhausted batteries promptly. Do not short-circuit the supply terminals. Dispose of used batteries properly.
- **Choking Hazard:** The game contains small parts and is not suitable for children under 3 years.
- **Hearing Safety:** The headset produces sound. Avoid prolonged exposure to loud volumes to prevent hearing damage.

## Warranty and Support

For warranty information or product support, please refer to the contact details provided on the product packaging or visit the official Hasbro Gaming website. Keep your purchase receipt as proof of purchase.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B07721S4DC**

More documents and user manuals: **https://manuals.plus/**